

A1 REAR SIGHT APERATURE WITH WINDAGE SCREW - BROWNELLS BRN-16A1 REAR SIGHT APERTURE W/WINDAGE SCREW, BLACK

[Rifle Parts](#) > [Sights](#) > [Sight Parts](#) > [Apertures](#)

Replacement A1 Rear Aperture with Windage Screw for Brownells BRN16A1 Rifle.



Attributes

- Name: [BROWNELLS BRN-16A1 REAR SIGHT APERTURE W/WINDAGE SCREW, BLACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000681
- Mfr. No.:
- Colour: Black
- Model: BRN-16A1
- Style: Fixed
- Weapon type: Brownells
- Delivery weight: 0.091kg
- Shipping height: 3mm
- Shipping width: 89mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for A1 Rear Sight Aperture with Windage Screw
- About Us

Safety Instruction Guide for A1 Rear Sight Aperture with Windage Screw

Introduction

Thank you for choosing the A1 Rear Sight Aperture with Windage Screw for your Brownells BRN16A1 Rifle. This guide provides essential safety instructions to ensure the safe use and installation of your product. Please read these instructions carefully before use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for signs of wear or damage.
- In case of any malfunction or damage, discontinue use immediately and seek assistance.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always handle the sight aperture with care to avoid injury.
- Do not modify the product in any way; alterations can lead to unsafe conditions.
- Ensure that the sight is securely attached before using the rifle.
- Use only compatible components with your Brownells BRN16A1 Rifle.
- Avoid using the product in wet or extreme weather conditions unless specified otherwise.

Instructions for Installation and Usage

1. Installation:

- Ensure that the rifle is unloaded and pointed in a safe direction.
- Remove the existing rear sight aperture if applicable.
- Align the A1 Rear Sight Aperture with the mounting slot on the rifle.
- Secure the aperture using the windage screw provided.
- Tighten the screw gently to avoid stripping the threads.

2. Usage:

- Once installed, adjust the windage screw as needed for accurate aiming.
- Regularly check the tightness of the windage screw to ensure stability.
- Familiarize yourself with the functionality of the sight before using the rifle in the field.

Disposal Instructions

- When disposing of the product, follow local regulations for electronic and nonelectronic waste.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any questions or concerns regarding the product, please refer to the manufacturer's website or customer service for assistance. Ensure that you have the product details ready when seeking support.

Thank you for your attention to these safety instructions. Enjoy using your A1 Rear Sight Aperture with Windage Screw responsibly and safely.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk