

V3 BALLISTIC CHRONOGRAPH WITH HARD CASE - MAGNETOSPEED

V3 BALLISTIC CHRONOGRAPH W/ HARD CASE

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

The V3 MagnetoSpeed has: Improved Display A three-button menu system (replaces old toggle switch) Battery options are; (1) 9-Volt or (2) CR123s (replaces 4 AAA batteries) Easy access battery compartment, no need for screwdriver to swap batteries Improved shooting modes, with the ability to now operate with air guns Downloadable firmware updates Advanced data logging and troubleshooting capabilities More compact and rugged display housing Rapid-fire mode with rate-of-fire Re-designed Bayonet Ruggedized strapping system; with metal buckle and triad thumb nut Same proven MagnetoSpeed technology, but with updated sensor design Sleek new profile and color scheme New strap bracket to allow for future alternative attachment options Added dual/redundant data connection points



Attributes

- Name: [MAGNETOSPEED V3 BALLISTIC CHRONOGRAPH W/ HARD CASE](#)
- Manufacturer: [MAGNETOSPEED](#)
- Product no.: 100014631
- Mfr. No.: MS_V3_HC
- Style: Chronograph
- Delivery weight: 1.315kg
- UPC: 855036004023

Item details

Made in USA

Table of Contents

- Startpage
- V3 Ballistic Chronograph Safety Instruction Guide
- About Us

V3 Ballistic Chronograph Safety Instruction Guide

Introduction

Thank you for choosing the V3 Ballistic Chronograph with Hard Case by MagnetoSpeed. This guide provides essential safety instructions and information to ensure the safe use and maintenance of your chronograph. Please read this guide carefully before using the product.

General Safety Guidelines

- **Product Safety:** This product is designed for safe use. Ensure you follow all instructions and guidelines to minimize any potential risks.
- **Enhanced Recalls:** In the unlikely event of a product recall, you will receive standardized notices and remedies at no cost.
- **Online Shopping:** If purchased online, you are entitled to the same safety protections as if you bought it in a physical store.
- **Special Consumer Focus:** Extra precautions should be taken when using this product around children and vulnerable individuals.
- **EU Contact Point:** For any safety inquiries, please refer to the designated EU contact point for assistance.
- **Rapid Alerts:** Stay informed about product safety updates through the EU's Safety Gate system.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is not intended for use by children under the age of 14 without adult supervision.
- **Battery Safety:**
 - Use only the specified battery types (1 x 9Volt or 2 x CR123).
 - Do not mix old and new batteries or different battery types.
 - Dispose of batteries properly according to local regulations.
- **Environmental Considerations:**
 - Avoid using the chronograph in extreme weather conditions (e.g., heavy rain, snow, or extreme heat).
 - Keep the device away from moisture and direct sunlight.
- **Physical Safety:**
 - Ensure the chronograph is securely mounted and stable during use.
 - Do not point the device at people or animals when in operation.
- **Handling Precautions:**
 - Handle the device with care to avoid damage.
 - Do not attempt to disassemble or repair the product yourself.

Instructions for Installation and Usage

1. **Unpacking:** Carefully remove the chronograph and accessories from the packaging. Check for any visible damage.
2. **Battery Installation:**
 - Open the battery compartment.
 - Insert the 9Volt battery or two CR123 batteries, ensuring correct polarity.
 - Close the battery compartment securely.
3. **Setup:**
 - Place the chronograph on a stable surface away from any obstructions.
 - Ensure the display is facing the user for easy visibility.
4. **Operation:**
 - Turn on the device using the threebutton menu system.

- Select the desired shooting mode using the menu options.
- Ensure the chronograph is properly aligned with the projectile path for accurate readings.

5. Data Logging:

- Utilize the advanced data logging feature for tracking performance.
- Connect to a compatible device for firmware updates and troubleshooting if necessary.

Disposal Instructions

- **Battery Disposal:** Dispose of batteries according to local regulations. Do not throw batteries in household waste.
- **Product Disposal:** When the chronograph reaches the end of its life, dispose of it in accordance with local electronic waste disposal regulations. Do not dispose of it in regular trash.

Contact Information for Further Support

For any questions, concerns, or safety inquiries, please reach out to the designated EU contact point for assistance. Ensure you have your product details ready for a more efficient response.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and enjoyable experience with your V3 Ballistic Chronograph.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu