

OPERATOR PACK-COYOTE BROWN

The Best Scout/Sniper Pack on the Market

The Eberlestock G4 Operator Pack is the culmination of years of effort on the company's part to produce the ideal pack needed for the sniper community. In designing the Eberlestock G4 Operator Pack, the company looked to its Phantom and Gunslinger pack designs and took elements from those bags to make the ultimate deployment-ready pack chosen by elite special-operations units. The bag features a fold-away rifle scabbard and has an internal space that allows for radios, laptops, satellite-communication gear or even mortar rounds. Features 4,100 cubic inches of storage space Weighs in at 10.3 pounds Measures 27 inches x 12 inches x 10 inches The Eberlestock G4 Operator Pack comes equipped with the company's Intex II frame for added stability and security.



Attributes

- Name: OPERATOR PACK-COYOTE BROWN
- Manufacturer: EBERLESTOCK
- Product no.: 100016115
- Mfr. No.: G4MC
- Color: Coyote Brown
- Cubic Inches: 4700
- Dimensions: 27"L x 12"W x 10"D
- Size: -
- Weight: 10 lbs 3 oz
- Delivery weight: 5.443kg
- Shipping height: 203mm
- Shipping width: 483mm
- Shipping length: 762mm
- UPC: 812028011605

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Eberlestock G4 Operator Pack](#)
- [English: Eberlestock G4 Operator Pack Safety Instruction Guide](#)

Sicherheitshinweise für den Eberlestock G4 Operator Pack

Einleitung

Willkommen beim Eberlestock G4 Operator Pack. Dieser Rucksack wurde speziell für die Bedürfnisse der ScharfschützenCommunity entwickelt. Um sicherzustellen, dass Sie diesen Rucksack sicher und effektiv nutzen können, beachten Sie bitte die folgenden Sicherheitshinweise.

Allgemeine Sicherheitsrichtlinien

- Der Rucksack ist für den vorgesehenen Gebrauch konzipiert. Verwenden Sie ihn nicht für andere Zwecke.
- Überprüfen Sie regelmäßig den Zustand des Rucksacks auf Risse, Abnutzung oder andere Schäden.
- Halten Sie den Rucksack von Feuer und extremen Temperaturen fern.
- Lagern Sie den Rucksack an einem kühlen, trockenen Ort, um Schäden durch Feuchtigkeit zu vermeiden.
- Verwenden Sie den Rucksack nicht, wenn Sie unter dem Einfluss von Alkohol oder Drogen stehen.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Achten Sie darauf, dass der Rucksack richtig auf Ihrem Rücken sitzt, um Verletzungen zu vermeiden.
- Tragen Sie den Rucksack nicht über längere Zeiträume, wenn er überladen ist. Dies kann zu Rückenschmerzen führen.
- Verwenden Sie die zusammenklappbare Gewehrtasche nur für den vorgesehenen Zweck. Stellen Sie sicher, dass das Gewehr sicher verstaut ist.
- Halten Sie den Rucksack von Kindern fern, wenn er mit gefährlichen Gegenständen wie Mörsergranaten beladen ist.
- Überprüfen Sie, ob alle Gurte und Schnallen fest und sicher sind, bevor Sie den Rucksack tragen.

Anweisungen zur Installation und Nutzung

- Stellen Sie sicher, dass der Rucksack vollständig entleert ist, bevor Sie ihn anlegen.
- Passen Sie die Schultergurte und den Hüftgurt an Ihre Körpergröße und form an, um den besten Tragekomfort zu gewährleisten.
- Nutzen Sie die verschiedenen Fächer des Rucksacks, um Ihr Equipment ordentlich und sicher zu verstauen. Vermeiden Sie Überladung.
- Achten Sie darauf, dass alle Reißverschlüsse und Schnallen ordnungsgemäß geschlossen sind, bevor Sie sich bewegen.
- Bei Bedarf können Sie die Tasche reinigen. Verwenden Sie dazu ein mildes Reinigungsmittel und Wasser. Lassen Sie den Rucksack an der Luft trocknen.

Entsorgungsanweisungen

- Entsorgen Sie den Rucksack gemäß den lokalen Vorschriften für Textilabfälle.
- Wenn der Rucksack beschädigt ist und nicht mehr verwendet werden kann, stellen Sie sicher, dass alle gefährlichen Inhalte sicher entfernt werden, bevor Sie ihn entsorgen.
- Informieren Sie sich über Recyclingmöglichkeiten in Ihrer Nähe, um die Umwelt zu schonen.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zur Sicherheit Ihres Eberlestock G4 Operator Pack wenden Sie sich bitte an den Kundenservice des Herstellers oder an die nächstgelegene Verkaufsstelle.

Eberlestock G4 Operator Pack Safety Instruction Guide

Introduction

Thank you for choosing the Eberlestock G4 Operator Pack. This guide provides important safety instructions and guidelines to ensure the safe use and maintenance of your pack. Please read this document carefully to maximize your safety and the performance of your product.

General Safety Guidelines

- Ensure the pack is used for its intended purpose as specified by the manufacturer.
- Regularly inspect the pack for signs of wear, damage, or malfunction before each use.
- Keep the pack away from fire, extreme heat, and sharp objects to prevent damage.
- Do not overload the pack beyond its capacity of 4,100 cubic inches or 10.3 pounds.
- Store the pack in a cool, dry place when not in use to prevent mold and deterioration.
- If you notice any unusual sounds, smells, or performance issues, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- When using the foldaway rifle scabbard, ensure that the firearm is unloaded and secured properly.
- Avoid using the pack in hazardous environments where it may become entangled or caught on obstacles.
- Use caution when accessing internal compartments to prevent injury from sharp edges or equipment.
- Ensure that all straps and buckles are securely fastened before moving to maintain stability and prevent accidents.
- Be aware of your surroundings and avoid using the pack in crowded or confined spaces.

Instructions for Installation and Usage

- **Adjusting the Straps**
 - Loosen the shoulder straps and hip belt before putting on the pack.
 - Slip the pack over your shoulders and adjust the straps for a snug fit.
 - Ensure the hip belt is positioned above your hips and securely fastened.
- **Using the FoldAway Rifle Scabbard**
 - Open the scabbard compartment and place the rifle inside.
 - Ensure the rifle is secured and the scabbard is closed properly before moving.
- **Accessing Internal Compartments**
 - Open the main compartment zipper slowly to avoid snagging.
 - Organize items inside to prevent shifting during movement.
 - Use the designated pockets for radios, laptops, or other equipment to ensure proper fit and safety.
- **Cleaning and Maintenance**
 - Clean the external surface with a damp cloth and mild soap as needed.
 - Avoid using harsh chemicals or bleach that may damage the fabric.
 - Allow the pack to air dry completely before storing.

Disposal Instructions

- When the pack reaches the end of its life cycle, dispose of it responsibly.
- Do not dispose of the pack in regular household waste if it contains hazardous materials.
- Check with local waste management authorities for specific disposal guidelines for outdoor gear and materials.

Contact Information for Further Support

For any inquiries related to safety, usage, or product concerns, please refer to the official Eberlestock website or contact your local distributor for assistance.