

SPORTER CHRONOGRAPH - MAGNETOSPEED SPORTER CHRONOGRAPH

[Shooting Accessories](#) > [Range Gear](#) > [Chronographs](#)

The MagnetoSpeed Sporter chronograph kit was designed to be used on barrels from 1/2 inch up to 1 inch in diameter. It can also accommodate muzzle brakes, flash hiders, etc, up to 2.7 inches in length. Ideal for contoured rifle barrels (sporter barrels). MagnetoSpeed Sporter features: Simple, one-button cycling display (shows recent shot velocity and statistics, plug in to turn on) Battery : 9-Volt (included) Easy access battery compartment, no need for screwdriver to swap batteries Three sensitivity settings for fine-tuning Integral, quick-attach strapping system; with metal buckle and triad thumb nut Proven technology with updated sensor design Integral 3.5 foot sensor cord Kit includes: Display Unit Bayonet-style sensor (Bayo) Thick and thin rubber V-block spacers Heavy duty strap with thumb nut tightener Ultra-compact storage container.



The MagnetoSpeed Sporter chronograph kit was designed to be used on barrels from 1/2 inch up to 1 inch in diameter. It can also accommodate muzzle brakes, flash hiders, etc, up to 2.7 inches in length. Ideal for contoured rifle barrels (sporter barrels). MagnetoSpeed Sporter features: Simple, one-button cycling display (shows recent shot velocity and statistics, plug in to turn on) Battery : 9-Volt (included) Easy access battery compartment, no need for screwdriver to swap batteries Three sensitivity settings for fine-tuning Integral, quick-attach strapping system; with metal buckle and triad thumb nut Proven technology with updated sensor design Integral 3.5 foot sensor cord Kit includes: Display Unit Bayonet-style sensor (Bayo) Thick and thin rubber V-block spacers Heavy duty strap with thumb nut tightener Ultra-compact storage container.

Attributes

- Name: [MAGNETOSPEED SPORTER CHRONOGRAPH](#)
- Manufacturer: [MAGNETOSPEED](#)
- Product no.: 100017022
- Mfr. No.: MS_SPT
- Style: Chronograph
- Delivery weight: 0.431kg
- Shipping height: 43mm
- Shipping width: 53mm
- Shipping length: 325mm
- UPC: 855036004054

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [MagneSpeed Sporter Chronograph Safety Instructions](#)
- [About Us](#)

MagnetoSpeed Sporter Chronograph Safety Instructions

Introduction

Thank you for choosing the MagnetoSpeed Sporter Chronograph. This guide provides important safety instructions and usage guidelines to ensure a safe and effective experience with your new chronograph. Please read all instructions carefully before use.

General Safety Guidelines

- Ensure that the MagnetoSpeed Sporter Chronograph is used only as intended, following all provided instructions.
- Keep the chronograph out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the device for any signs of damage or wear. Do not use if damaged.
- Use the chronograph in a safe environment, away from obstructions and potential hazards.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always use the device in a wellventilated area to avoid inhalation of any fumes or gases.
- Do not point the sensor at any person or animal while in operation.
- Ensure that the chronograph is securely attached to the firearm barrel to prevent it from falling or being dislodged during use.
- Avoid using the chronograph in wet or damp conditions to prevent electrical hazards.
- Do not attempt to modify or disassemble the chronograph, as this may lead to malfunction or safety risks.

Instructions for Installation and Usage

1. Installation:

- Ensure the chronograph is compatible with your firearm barrel (1/2 inch to 1 inch in diameter).
- Attach the bayonetstyle sensor securely to the barrel.
- Use the integral strapping system with the metal buckle and triad thumb nut to ensure a tight fit.
- Plug in the sensor cord to the display unit.

2. Usage:

- Turn on the display unit by plugging in the sensor cord.
- The display will show recent shot velocity and statistics after each shot.
- Use the onebutton cycling display for easy navigation through the data.
- Adjust sensitivity settings as needed for optimal performance.

3. Battery Replacement:

- The device uses a 9Volt battery, which is included.
- To replace the battery, open the easyaccess battery compartment without the need for a screwdriver.
- Ensure the device is turned off before replacing the battery.

Disposal Instructions

- Dispose of the MagnetoSpeed Sporter Chronograph in accordance with local regulations for electronic waste.
- Remove the battery before disposing of the device and recycle it according to local battery recycling guidelines.
- Do not dispose of the chronograph in regular household waste.

Contact Information for Further Support

For questions or concerns regarding the MagnetoSpeed Sporter Chronograph, please refer to the included documentation or visit the official website for support resources.

Thank you for choosing MagnetoSpeed. Enjoy your chronograph safely and responsibly!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk