

PMAG® GL9® 9X19 MAGAZINE FOR GLOCK® 19 - PMAG 15 GL9 9MM LUGER 15RD FOR GLOCK 19 BLACK 10/PACK

Double Stack Mag for Glock 19

The PMAG® GL9® is a Glock® 19 9mm handgun magazine featuring a proprietary all-polymer construction for flawless reliability and durability over thousands of rounds. High visibility anti-tilt follower, stainless steel spring, easily removable floorplate for cleaning, paint pen dot matrix for mag marking, ridged floorplate edges for better grip, and round indicator windows. Drops free loaded or unloaded. All with the same boring reliability you expect from an OEM magazine. The PMAG 15 GL9 is compatible with Glock G19 handguns as well as sub-compact variants with some protrusion below the grip. Available in 15 and 10 round capacities.



Attributes

- Name: PMAG 15 GL9 9MM LUGER 15RD FOR GLOCK 19 BLACK 10/PACK
- Manufacturer: MAGPUL
- Product no.: 100024593
- Mfr. No.:
- Capacity: 15-Round
- Cartridge: 9 mm Luger
- Finish: Black
- Make: Glock
- Material: Polymer
- Model: 19
- Quantity: 10
- Delivery weight: 0.907kg

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- English: PMAG® GL9® 9X19 MAGAZINE FOR GLOCK® 19 Safety Instruction Guide
- Italiano: ISTRUZIONI DI SICUREZZA PER IL CARICATORE PMAG® GL9® 9X19 PER GLOCK® 19

PMAG® GL9® 9X19 MAGAZINE FOR GLOCK® 19

Safety Instruction Guide

Introduction

Thank you for choosing the PMAG® GL9® 9X19 Magazine for your Glock® 19 handgun. This guide provides essential safety instructions to ensure safe usage, installation, and disposal of the magazine. By following these guidelines, you can help prevent accidents and ensure the safe operation of your firearm.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Store the magazine and firearm in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the magazine for signs of wear or damage before use.
- Follow all local laws and regulations regarding firearms and ammunition.
- Use only compatible ammunition (9 mm Luger) to prevent malfunctions or accidents.
- Be aware of your surroundings and ensure a clear line of sight when handling firearms.

Specific Safety Precautions for Use

- Do not exceed the magazine's capacity of 15 rounds to ensure proper function.
- Avoid using the magazine in extreme temperatures or environments that may affect performance.
- Ensure the magazine is properly seated in the firearm before firing.
- Do not attempt to disassemble the magazine unless following the manufacturer's instructions for cleaning.
- If the magazine fails to feed or eject properly, stop using it immediately and inspect for obstructions or damage.
- Always keep the muzzle pointed in a safe direction when loading or unloading the magazine.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded before attaching the magazine.
- Align the magazine with the magazine well of the Glock® 19.
- Firmly push the magazine into the well until you hear a click, indicating it is securely in place.

2. Loading the Magazine:

- Hold the magazine in one hand and use the other hand to load 9 mm Luger ammunition.
- Press down on the follower with your thumb while inserting each round, ensuring they are seated properly.
- Do not exceed the maximum capacity of 15 rounds.

3. Using the Magazine:

- Insert the loaded magazine into the firearm as described in the installation section.
- Pull back the slide of the firearm to chamber a round.
- Fire the firearm only in a safe and controlled environment, following all local firearm safety regulations.

4. Unloading the Magazine:

- Point the firearm in a safe direction.
- Remove the magazine by pressing the magazine release button and pulling the magazine out of the well.
- To unload, press the follower down and remove each round carefully.

Disposal Instructions

- Dispose of the magazine in accordance with local waste management regulations.
- If the magazine is damaged or no longer functional, consider recycling it if possible, following local guidelines for metal and plastic recycling.
- Do not dispose of the magazine in a manner that could pose a danger to others.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please contact the manufacturer or your local dealer. Always ensure you have the product details ready when seeking assistance.

By adhering to these guidelines, you can ensure the safe operation of your PMAG® GL9® magazine and enhance your overall shooting experience. Stay safe and responsible.

ISTRUZIONI DI SICUREZZA PER IL CARICATORE PMAG® GL9® 9X19 PER GLOCK® 19

Introduzione

Grazie per aver scelto il caricatore PMAG® GL9® 9X19 per la tua Glock® 19. Questa guida fornisce istruzioni di sicurezza essenziali per garantire l'uso e la gestione sicura del tuo caricatore. Ti preghiamo di leggere attentamente questo documento e di seguire le linee guida per evitare potenziali pericoli.

Linee Guida Generali di Sicurezza

- Maneggia sempre armi da fuoco e munizioni con cura e rispetto.
- Assicurati che il caricatore sia compatibile con il tuo modello specifico di arma Glock®.
- Conserva il caricatore in un luogo sicuro e protetto, fuori dalla portata di bambini e utenti non autorizzati.
- Ispeziona regolarmente il caricatore per segni di usura, danni o malfunzionamenti.
- Riporta eventuali prodotti non sicuri o incidenti alle autorità competenti.
- Rimani informato sugli aggiornamenti delle revoche tramite la piattaforma Safety Gate dell'UE.

Precauzioni di Sicurezza Specifiche per l'Uso

- Non superare la capacità massima del caricatore di 15 colpi.
- Assicurati che il caricatore sia completamente inserito nell'arma prima dell'uso.
- Evita di utilizzare caricatori danneggiati o modificati, poiché ciò potrebbe portare a malfunzionamenti.
- Usa solo munizioni 9mm Luger in questo caricatore.
- Non puntare mai l'arma da fuoco verso qualcosa che non intendi colpire.
- Tieni il dito lontano dal grilletto fino a quando non sei pronto a sparare.
- Tratta sempre ogni arma da fuoco come se fosse carica.

Istruzioni per l'Installazione e l'Uso

1. Caricamento del Caricatore:

- Tieni il caricatore con le labbra di alimentazione rivolte verso l'alto.
- Usa il pollice per premere verso il basso sul follower e inserire il primo colpo nel caricatore.
- Continua ad aggiungere colpi fino a quando il caricatore è pieno, assicurandoti che ogni colpo sia posizionato correttamente.

2. Inserimento del Caricatore nell'Arma:

- Assicurati che l'arma da fuoco sia puntata in una direzione sicura e sia in modalità sicura.
- Allinea il caricatore con il pozzetto del caricatore dell'arma.
- Spingi fermamente il caricatore nel pozzetto fino a sentire un clic, che indica che è bloccato in posizione.

3. Rimozione del Caricatore:

- Assicurati che l'arma da fuoco sia puntata in una direzione sicura.
- Premi il pulsante di rilascio del caricatore per staccare il caricatore dall'arma.
- Tira il caricatore dritto fuori dal pozzetto del caricatore.

4. Pulizia e Manutenzione:

- Pulisci regolarmente il caricatore per garantire un funzionamento corretto.
- Rimuovi il fondo premendo la linguetta di rilascio e facendolo scorrere via.
- Pulisci l'interno del caricatore con un panno morbido e un solvente delicato.
- Rimonta il caricatore facendo scorrere il fondo di nuovo fino a quando non scatta in posizione.

Istruzioni per lo Smaltimento

- Smaltisci il caricatore in conformità con le normative locali.
- Non smaltire il caricatore nei rifiuti domestici regolari se è danneggiato o non più funzionante.
- Controlla con le strutture di gestione dei rifiuti locali per i metodi di smaltimento appropriati.

Informazioni di Contatto per Ulteriore Supporto

Per eventuali domande o preoccupazioni riguardanti il caricatore PMAG® GL9® 9X19, ti preghiamo di fare riferimento alle informazioni di contatto del produttore fornite sulla confezione o di visitare il sito web ufficiale.