

PMAG® GL9® 9X19 MAGAZINE FOR GLOCK® 17 - PMAG 17 GL9 9MM LUGER 17RD FOR GLOCK 17 BLACK 10/PACK

Durable Double Stack Mag for Glock

Constructed of a proprietary polymer, these durable PMAG® GL9® magazines fit 9mm Glock® 17 handguns, including Gen 4 models. Reinforced feed lips, a stainless-steel spring and a high visibility anti-tilt follower ensure reliable feeding. Pushbutton release on the floorplate allows the magazine to be easily disassembled without tools. Floorplate also has a pen dot matrix on the bottom for marking and identifying magazines. The GL9 consistently drops clear and free when released; loaded or empty. 17 GL9 fits flush at the base of the Glock® 17 grip, with some minor protrusion on compact and subcompact models. Available in 17 and 10 round capacities.



Attributes

- Name: PMAG 17 GL9 9MM LUGER 17RD FOR GLOCK 17 BLACK 10/PACK
- Manufacturer: MAGPUL
- Product no.: 100024594
- Mfr. No.:
- Capacity: 17-Round
- Cartridge: 9 mm Luger
- Finish: Black
- Make: Glock
- Material: Polymer
- Model: 17
- Quantity: 10
- Delivery weight: 0.272kg

Item details

Made in USA

US export classification: 0A501.d

Table of Contents

- Startpage
- English: PMAG® GL9® 9X19 MAGAZINE FOR GLOCK® 17 Safety Instruction Guide
- Italiano: Istruzioni di Sicurezza per il Caricatore PMAG® GL9® 9X19 per Glock® 17

PMAG® GL9® 9X19 MAGAZINE FOR GLOCK® 17

Safety Instruction Guide

Introduction

Thank you for choosing the PMAG® GL9® 9X19 Magazine for Glock® 17. This guide provides essential safety information to ensure the safe use and handling of your magazine. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the magazine is compatible with your firearm model.
- Always treat every firearm as if it is loaded.
- Store magazines and firearms securely and out of reach of children and unauthorized users.
- Regularly inspect your magazine for signs of wear or damage.
- Use only the recommended ammunition type specified for your magazine.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Always check that the magazine is empty before disassembly or cleaning.
- Do not attempt to modify the magazine in any way.
- Avoid exposing the magazine to extreme temperatures or harsh chemicals.
- Do not use the magazine if it appears damaged or malfunctioning.
- Keep the magazine away from moisture to prevent corrosion.

Instructions for Installation and Usage

1. Installation:

- Ensure your Glock® 17 is pointed in a safe direction and is unloaded.
- Insert the PMAG® GL9® magazine into the magazine well until it clicks into place.
- Confirm that the magazine is securely seated by giving it a gentle tug.

2. Usage:

- Load the magazine by pressing down on the follower and inserting cartridges, ensuring they are aligned correctly.
- Always check the magazine capacity; do not overload beyond the specified limit (17 rounds).
- When ready to fire, ensure the firearm is in a safe condition before chambering a round.
- To remove the magazine, press the magazine release button and pull the magazine out of the magazine well.

Disposal Instructions

- Dispose of the magazine in accordance with local regulations.
- Do not dispose of the magazine in regular household waste if it is damaged or contains hazardous materials.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For safety inquiries or concerns regarding the PMAG® GL9® magazine, please consult the manufacturer's website or contact your local retailer for assistance.

Conclusion

Your safety is paramount. By following the guidelines and instructions provided in this manual, you can ensure the safe and effective use of your PMAG® GL9® magazine. Always stay informed about safety practices and regulations related to firearm usage. Thank you for your commitment to safety.

Istruzioni di Sicurezza per il Caricatore PMAG® GL9® 9X19 per Glock® 17

Introduzione

Grazie per aver scelto il caricatore PMAG® GL9® 9X19 per la tua Glock® 17. Questa guida alle istruzioni di sicurezza è progettata per fornirti informazioni essenziali per garantire un uso, un'installazione e un smaltimento sicuri del tuo caricatore. Ti preghiamo di leggere attentamente questa guida prima di utilizzare il prodotto.

Linee Guida Generali di Sicurezza

- Assicurati che il caricatore sia compatibile con il tuo modello di Glock® 17 prima dell'uso.
- Maneggia sempre il caricatore con cura per prevenire scariche accidentali.
- Tieni il caricatore fuori dalla portata di bambini e utenti non autorizzati.
- Conserva il caricatore in un luogo fresco e asciutto, lontano dalla luce diretta del sole e dall'umidità.
- Ispeziona regolarmente il caricatore per segni di usura o danni. Non utilizzare se danneggiato.
- Segui le leggi e i regolamenti locali riguardanti l'uso e lo stoccaggio dei caricatori per armi da fuoco.

Precauzioni di Sicurezza Specifiche per l'Utilizzo

- Assicurati sempre che l'arma sia scarica prima di inserire o rimuovere il caricatore.
- Non tentare di smontare il caricatore mentre è carico.
- Utilizza solo munizioni 9mm Luger con questo caricatore. Altri calibri possono causare malfunzionamenti o infortuni.
- Sii consapevole dell'ambiente circostante e assicurati che l'area sia sicura prima di caricare o utilizzare il caricatore.
- Se riscontri malfunzionamenti, interrompi immediatamente l'uso e consulta un armaiolo qualificato.

Istruzioni per l'Installazione e l'Utilizzo

Installazione

1. Assicurati che la tua Glock® 17 sia puntata in una direzione sicura e sia scarica.
2. Allinea il caricatore con il pozzetto del caricatore dell'arma.
3. Premi saldamente il caricatore nel pozzetto fino a quando non scatta in posizione.

Utilizzo

- Per caricare il caricatore:
 - Tieni il caricatore con le labbra di alimentazione rivolte verso l'alto.
 - Inserisci i colpi nel caricatore uno alla volta, assicurandoti che siano ben sistemati.
- Per rimuovere il caricatore:
 - Premi il pulsante di rilascio del caricatore sull'arma.
 - Tira verso il basso il caricatore e fallo uscire dal pozzetto.
- Per smontare il caricatore:
 - Assicurati che il caricatore sia scarico.
 - Usa il pulsante di rilascio sul fondo per smontare senza attrezzi.
 - Pulisci regolarmente il caricatore per garantire prestazioni ottimali.

Istruzioni per lo Smaltimento

- Quando il caricatore raggiunge la fine del suo ciclo di vita o è danneggiato oltre la riparazione, smaltiscilo in conformità alle normative locali.
- Non gettare il caricatore nei rifiuti normali.
- Contatta le autorità locali per la gestione dei rifiuti per i metodi di smaltimento appropriati degli accessori per armi da fuoco.

Informazioni di Contatto per Ulteriore Supporto

Per qualsiasi domanda o preoccupazione sulla sicurezza riguardante il caricatore PMAG® GL9® 9X19, ti preghiamo di fare riferimento al sito web del produttore o di contattare il loro team di supporto.

Ti ricordiamo che la sicurezza è fondamentale quando si maneggiano accessori per armi da fuoco. Segui sempre le linee guida fornite in questo documento per garantire un'esperienza sicura.