

FLASH HIDER FOR RUGER™ 10/22™ - SAMSON MANUFACTURING CORP FLASH HIDER FOR RUGER 10/22 BLACK OXIDE

[Rifle Parts](#) > [Muzzle Devices](#) > [Flash Hiders](#)

This flash hider slips on to the standard 10/22® rifle barrel is secured with a single set screw... no gunsmithing required.



Attributes

- Name: [SAMSON MANUFACTURING CORP FLASH HIDER FOR RUGER 10/22 BLACK OXIDE](#)
- Manufacturer: [SAMSON MANUFACTURING CORP](#)
- Product no.: 100047443
- Mfr. No.: 04-06062-03
- Caliber: 22 Caliber (.223-.224)
- Finish: Black
- Material: Stainless Steel
- Model: 10/22
- Weapon type: Ruger
- Delivery weight: 0.091kg
- Shipping height: 38mm
- Shipping width: 127mm
- Shipping length: 127mm
- UPC: 850006871629

Item details

Made in USA

Table of Contents

- Startpage
- **FLASH HIDER FOR RUGER™ 10/22™**
- About Us

FLASH HIDER FOR RUGER™ 10/22™

Safety Instruction Guide

Introduction

Thank you for choosing the FLASH HIDER FOR RUGER™ 10/22™ by SAMSON MANUFACTURING CORP. This guide provides essential safety instructions and guidelines to ensure the safe use, installation, and disposal of your flash hider. Please read this document carefully before using the product.

General Safety Guidelines

- Always treat firearms and accessories as if they are loaded.
- Ensure that the flash hider is compatible with your Ruger 10/22 rifle before use.
- Keep the product out of reach of children and unauthorized users.
- Use the flash hider only for its intended purpose.
- Regularly inspect the flash hider for any signs of wear or damage before each use.
- If you notice any defects or issues, discontinue use immediately and seek advice from a qualified professional.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before installing or removing the flash hider.
- Do not attempt to modify the flash hider in any way.
- Use only the recommended tools for installation to avoid damage.
- Never point the firearm at anything you do not intend to shoot.
- Always wear appropriate eye and ear protection when using firearms.
- Be aware of your surroundings and ensure a safe shooting environment.
- Follow all local laws and regulations regarding the use of firearms and accessories.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded.
- Gather necessary tools: a suitable wrench and the provided set screw.

2. Installation:

- Align the flash hider with the muzzle of the Ruger 10/22 rifle barrel.
- Slide the flash hider onto the barrel until it is fully seated.
- Secure the flash hider using the provided set screw. Tighten the screw firmly, but do not overtighten to avoid damage.

3. Usage:

- After installation, verify that the flash hider is securely attached.
- Use the firearm in accordance with standard safety practices.
- Regularly check the flash hider for any looseness or wear during use.

Disposal Instructions

- Dispose of the flash hider in accordance with local regulations regarding metal waste.
- If the product is damaged or no longer usable, do not attempt to repair it. Dispose of it responsibly.

Contact Information for Further Support

For any inquiries or concerns regarding the FLASH HIDER FOR RUGER™ 10/22™, please reach out to your local retailer or the manufacturer for assistance.

Conclusion

Your safety is our top priority. By following the guidelines outlined in this document, you can ensure the safe and effective use of your FLASH HIDER FOR RUGER™ 10/22™. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk