

VICKERS PUSH BUTTON SLING WITH SWIVELS - BLUE FORCE GEAR

VICKERS PUSH BUTTON SLING W/SWIVELS COYOTE

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Slings](#)

The Vickers Push Button Sling You asked and we listened. Prompted by a flood of requests and the growing popularity of push button sockets on premium rifles, we have reintroduced the Vickers Push Button Slings. The Vickers Push Button Sling combines premium American-made push button swivels with the world class Vickers Sling™ to make the finest combat weapon sling on the planet. The Vickers Push Button Sling starts with Vickers Combat Applications Slings - trusted by over 500,000 Marines, Soldiers, and Airmen - the tactical sling can instantly lengthen or shorten by the patented Quick Adjuster. This allows the user to have the weapon secure in a hands free carry and quickly lengthen the sling into a shooting position with no moving parts, clips, springs, or other awkward parts. The Quick Adjuster - Contrasting Pull Tab Able to quickly transition from carrying a slung rifle comfortably to combat ready, the patent pending Quick Adjuster has bridged the gap between the two primary uses of weapon slings - from transporting to fighting. All Vickers Push Button Slings™ are built with precision and pride right here at home in the US with superior materials. Attachment Hardware: Push Buttons A 1" push button "QD" swivel is sewn to the front of the sling and another 1.25" push button "QD" swivel is "captive" at the rear. This creates a simple, streamlined, lightweight sling that can mount to any weapon with quick release sockets. The push button swivels are not removable preventing them from being lost or the sling misconfigured. Adjuster & Triglides Build This Nylon Hardware version features all DuPont Zytel® nylon - which is lighter, stronger, and more flexible than traditional plastic sling hardware. The majority of the BFG slings shipped to the US Military feature Nylon Hardware. Specifications Compatibility - Weapons with two Push Button Sling Swivel sockets at the front and rear of the weapon Installation - Two Push Button Sockets (front and rear of weapon) Size - 1.25" sling webbing Hardware Build - Glass reinforced DuPont Zytel® Nylon hardware Sling Build - Invista solution dyed CORDURA® webbing Length - Overall sling length is adjustable from 36" to 62"



Attributes

- Name: [BLUE FORCE GEAR VICKERS PUSH BUTTON SLING W/SWIVELS COYOTE](#)
- Manufacturer: [BLUE FORCE GEAR](#)
- Product no.: 430100697
- Mfr. No.: VCAS-PB-125-AA-CB
- Colour: Coyote Brown
- Material: Nylon
- Style: 2-point Sling
- Width: 1.25
- Delivery weight: 0.15kg
- Shipping height: 32mm
- Shipping width: 133mm
- Shipping length: 127mm
- UPC: 814520018250

Item details

Made in USA

Table of Contents

- Startpage
- Vickers Push Button Sling Safety Instruction Guide
- About Us

Vickers Push Button Sling Safety Instruction Guide

Introduction

Thank you for choosing the Vickers Push Button Sling. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your sling. Please read this guide carefully to understand how to use the product safely and responsibly.

General Safety Guidelines

- Ensure the sling is compatible with your weapon before use.
- Always inspect the sling for any signs of wear or damage before each use.
- Do not exceed the recommended weight limit of the sling.
- Keep the sling away from children and vulnerable individuals.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- **Proper Usage:** Always use the sling as intended. Do not modify or alter the sling in any way.
- **Secure Attachment:** Ensure that the push button swivels are securely attached to the weapon before use.
- **HandsFree Carry:** When using the sling for handsfree carry, ensure that the weapon is secured and cannot fall or be accidentally discharged.
- **Transitioning:** When transitioning from carrying to shooting position, make sure the sling is adjusted properly to avoid entanglement or obstruction.
- **Environmental Considerations:** Be cautious of environmental factors such as weather conditions that may affect the performance of the sling.

Instructions for Installation and Usage

1. Installation:

- Locate the push button swivel sockets on your weapon.
- Attach the 1" push button "QD" swivel at the front of the sling to the corresponding socket.
- Attach the 1.25" push button "QD" swivel at the rear of the sling to the corresponding socket.
- Ensure both swivels are securely locked in place.

2. Adjusting the Sling:

- To adjust the length of the sling, use the Quick Adjuster.
- Pull the contrasting pull tab to lengthen or shorten the sling as needed.
- Ensure the sling is adjusted to a comfortable length for your use.

3. Using the Sling:

- To carry the weapon, position the sling over your shoulder, allowing the weapon to rest securely against your body.
- When ready to shoot, quickly adjust the sling to the desired length for optimal aiming and stability.

Disposal Instructions

- Dispose of the sling responsibly at a designated waste disposal facility.
- Do not dispose of the sling in regular household waste or in a manner that could harm the environment.
- Consider recycling options for the nylon and plastic components where available.

Contact Information for Further Support

For any questions or concerns regarding the Vickers Push Button Sling, please refer to the product packaging for contact details. It is important to have an EUbased contact for safety inquiries and support.

By following this guide, you can ensure the safe and effective use of your Vickers Push Button Sling. Thank you for your attention to safety, and enjoy your product responsibly.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk