

HUNTER DETACHABLE MAGAZINE BOTTOM METAL LONG ACTION AICS - CHRISTENSEN ARMS HUNTER DETACHABLE MAGAZINE BOTTOM METAL LONG ACTION AICS

[Rifle Parts](#) > [Receiver Parts](#) > [Bottom Metals](#)

This Remington 700 long or short action compatible bottom metal allows quick loading/unloading via removable AICS patterned magazines (Not included). The Hunter version uses a magazine release inside the trigger guard.



Attributes

- Name: [CHRISTENSEN ARMS HUNTER DETACHABLE MAGAZINE BOTTOM METAL LONG ACTION AICS](#)
- Manufacturer: [CHRISTENSEN ARMS](#)
- Product no.: 430102950
- Mfr. No.: 8100002902
- Finish: Black
- Model: 700
- Weapon type: Remington
- Delivery weight: 0.454kg
- Shipping height: 236mm
- Shipping width: 30mm
- Shipping length: 84mm
- UPC: 691328233104

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for HUNTER Detachable Magazine Bottom Metal Long Action AICS
- About Us

Safety Instruction Guide for HUNTER Detachable Magazine Bottom Metal Long Action AICS

Introduction

Thank you for choosing the HUNTER Detachable Magazine Bottom Metal Long Action AICS. This product is designed for use with Remington 700 long or short action firearms and allows for quick loading and unloading via removable AICS patterned magazines. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle firearms with care and follow all safety rules.
- Ensure that the firearm is unloaded before installing or handling the bottom metal.
- Keep the product away from children and unauthorized users.
- Store the product in a secure location when not in use.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the magazine release is functioning properly before use.
- Do not attempt to modify the bottom metal in any way.
- Only use AICS patterned magazines that are compatible with the product.
- Avoid using the product in wet or damp conditions to prevent corrosion.
- Do not exceed the recommended capacity of the magazine.
- Always keep your finger off the trigger until ready to shoot.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is completely unloaded.
- Remove the existing bottom metal from the firearm.
- Align the HUNTER detachable magazine bottom metal with the action of the firearm.
- Securely fasten the bottom metal using the provided screws.
- Ensure that the magazine release is properly installed and functioning.

2. Usage

- Insert the compatible AICS magazine into the bottom metal until it clicks into place.
- To release the magazine, press the magazine release located inside the trigger guard.
- Always verify that the magazine is securely in place before firing.
- After use, remove the magazine and ensure the firearm is unloaded.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the HUNTER Detachable Magazine Bottom Metal Long Action AICS, please consult your retailer or manufacturer's support resources. Ensure you have the product details ready for efficient assistance.

By following these safety instructions, you can ensure a safer experience with the HUNTER Detachable Magazine Bottom Metal Long Action AICS. Always prioritize safety and responsible usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk