

TACTICAL ADJUSTABLE REAR BATTLESIGHT FOR 1911 - WILSON COMBAT TACTICAL ADJUSTABLE REAR BATTLESIGHT FOR 1911

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

The Tactical Adjustable Battlesight for 1911's makes quickly adjusting your 1911 pistol's elevation a simple task. This streamlined, low-profile sight fits the standard Wilson Combat Battlesight dovetail and locks into place with two massive set screws. The machined steel blade pivots on a hardened slotted adjustment screw that easily moves your pistol's point of impact with crisp, click adjustments. The Tactical Adjustable Battlesight is solidly constructed of solid billet steel and black parkerized for rust resistance. Unlike many adjustable sights, The Tactical Adjustable Battlesight will easily stand up to the rigors of competition and tactical use. The rear blade is the Wilson Battlesight design with serrated rear blade and low-glare, pocketed sight picture with a .140" deep and .160" wide U-Notch sighting aperture for excellent performance when speed shooting and even in low light. A rear shelf enables one-handed emergency slide manipulation. Windage is adjusted by drifting the sight body in the same fashion as a traditional fixed sight-NOTE-side hex "screws" are caps that cover and lock the sight's main pin-it is not necessary to remove these cap screws. Crisp, click adjustable elevation (.056" range of adjustment) Drop-in installation on guns with proper 65° x .495" rear dovetail (Wilson 463/Novak Lo-Mount) One click = (3/4" for compact) (5/8" for full size) at 25 yards Turn elevation screw clockwise to move rear sight and point of impact UP, counterclockwise for DOWN. Ideal sight picture for poorly lit shooting conditions, dynamic shooting situations or for those with aging eyesight .160" wide and deeper U-notch for optimum sighting in low-light, dynamic range conditions Serrated 40 lpi for a non-glare surface in the brightest outdoor range conditions Pyramid shaped rear occludes less of the target while shooting External shelf enables easy one-hand cycling or malfunction clearance All edges radiused for smooth, comfortable gun-handling Black parkerized, hardened carbon steel for a lifetime of use



Attributes

- Name: [WILSON COMBAT TACTICAL ADJUSTABLE REAR BATTLESIGHT FOR 1911](#)
- Manufacturer: [WILSON COMBAT](#)
- Product no.: 430103874
- Mfr. No.: 860
- Sight Color: Black
- Style: Serrated
- Weapon type: 1911
- Delivery weight: 0.038kg
- Shipping height: 25mm
- Shipping width: 83mm
- Shipping length: 140mm
- UPC: 811826022943

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Tactical Adjustable Rear Battlesight for 1911
- About Us

Safety Instruction Guide for Tactical Adjustable Rear Battlesight for 1911

Introduction

Thank you for choosing the Tactical Adjustable Rear Battlesight for your 1911 pistol. This guide provides essential safety instructions to ensure the safe use and installation of your product. Please read this document carefully before using the battlesight.

General Safety Guidelines

- Ensure the battlesight is installed correctly to avoid misalignment that could affect accuracy.
- Always handle your firearm responsibly and in accordance with local laws and regulations.
- Keep the battlesight and your firearm out of reach of children and unauthorized users.
- Regularly inspect the battlesight for any signs of wear or damage before use.
- If you notice any defects or issues with the battlesight, do not use it and seek professional assistance.

Specific Safety Precautions for Use

- Only use the Tactical Adjustable Battlesight with compatible 1911 models.
- Do not attempt to modify or alter the battlesight in any way, as this could compromise safety and performance.
- When adjusting the elevation or windage, do so with care to prevent unintended changes in your point of impact.
- Ensure that the firearm is unloaded and pointed in a safe direction when installing or adjusting the battlesight.
- Be aware of your surroundings and ensure a safe shooting environment, especially under lowlight conditions.

Instructions for Installation and Usage

1. Installation:

- Ensure your firearm is unloaded.
- Remove the existing sight from the rear dovetail of your 1911.
- Align the Tactical Adjustable Battlesight with the dovetail, ensuring it fits securely.
- Lock the sight into place using the two set screws provided. Ensure they are tightened adequately.
- Check for proper alignment and adjust as necessary.

2. Adjusting Elevation and Windage:

- For elevation adjustments, turn the elevation screw clockwise to raise the rear sight and counterclockwise to lower it.
- For windage adjustments, drift the sight body left or right as needed, similar to a traditional fixed sight.
- Each click of adjustment will change your point of impact by 3/4" for compact models and 5/8" for fullsize models at 25 yards.

3. Usage:

- Familiarize yourself with the sight picture before engaging in live firing.
- Practice shooting in various lighting conditions to ensure optimal performance.
- Utilize the rear shelf for onehanded slide manipulation if necessary.

Disposal Instructions

- At the end of the product's life cycle, dispose of the Tactical Adjustable Battlesight in accordance with local regulations for electronic waste and metal recycling.
- Do not throw the battlesight in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Tactical Adjustable Rear Battlesight, please reach out to your point of purchase or consult a qualified gunsmith.

By following these safety instructions, you contribute to a safer shooting experience. Always prioritize safety and enjoy your time at the range.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk