

# **NO. 3 BIPOD ADAPTER FOR REMINGTON MODELS 4, 74 & 7400 - HARRIS NO. 3 ADAPTER FOR REMINGTON MODELS 4, 74 & 7400**

[Shooting Accessories](#) > [Bipods, Monopods & Accessories](#) > [Bipod Accessories](#)

No. 3 Adapter Fits Remington Semi-automatic rifles, Models No. 4, 74 and 7400 The adapter consists of two-parts, the base and the fore-end screw Made in the USA



## **Attributes**

- Name: [HARRIS NO. 3 ADAPTER FOR REMINGTON MODELS 4, 74 & 7400](#)
- Manufacturer: [HARRIS](#)
- Product no.: 430104206
- Mfr. No.: NO. 3
- Attachment: Direct Mount
- Delivery weight: 0.086kg
- Shipping height: 51mm
- Shipping width: 127mm
- Shipping length: 127mm
- UPC: 051156000307

## **Item details**

Made in USA

# Table of Contents

- Startpage
- NO. 3 BIPOD ADAPTER FOR REMINGTON MODELS 4, 74 & 7400 Safety Instruction Guide
- About Us

# NO. 3 BIPOD ADAPTER FOR REMINGTON MODELS 4, 74 & 7400 Safety Instruction Guide

## Introduction

Thank you for choosing the NO. 3 Bipod Adapter for Remington Models 4, 74 & 7400. This product is designed to enhance your shooting experience by providing a stable platform for your rifle. To ensure your safety and the safe use of this product, please read and follow the instructions and safety guidelines outlined in this manual.

## General Safety Guidelines

- Always handle firearms and accessories with care and responsibility.
- Ensure that the bipod adapter is compatible with your specific Remington model before use.
- Regularly inspect the bipod adapter for any signs of wear or damage. Do not use if damaged.
- Keep the bipod adapter out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding firearm accessories.

## Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or removing the bipod adapter.
- Do not attempt to modify or alter the bipod adapter in any way.
- Always use the bipod adapter in a safe and controlled environment, such as a shooting range.
- Be aware of your surroundings and ensure there is a clear line of sight before using the firearm with the bipod adapter attached.
- Use appropriate protective gear, including eye and ear protection, when using firearms.

## Instructions for Installation and Usage

### Installation

1. **Prepare the Firearm:** Ensure that the firearm is unloaded and pointed in a safe direction.
2. **Remove Existing ForeEnd Screw:** Using the appropriate tool, carefully remove the existing foreend screw from your Remington model.
3. **Attach the Adapter Base:** Align the base of the bipod adapter with the mounting point on your rifle. Insert the foreend screw through the base and tighten securely.
4. **Check Stability:** Ensure that the adapter is firmly attached and does not wobble. If it feels loose, recheck the installation steps.

### Usage

- When using the bipod adapter, ensure that it is set up on a flat and stable surface.
- Adjust the legs of the bipod to achieve the desired height and stability before taking aim.
- Always maintain control of your firearm while using the bipod adapter.

## Disposal Instructions

- Dispose of the bipod adapter in accordance with local regulations for nonhazardous waste.
- Do not throw the bipod adapter in regular household trash if it is damaged or broken. Check with local waste management for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the NO. 3 Bipod Adapter for Remington Models 4, 74 & 7400, please refer to the manufacturer's website or customer support resources.

By following these safety instructions, you can ensure a safe and enjoyable experience with your NO. 3 Bipod Adapter. Thank you for your attention to safety, and happy shooting!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)