

AR-15 PIN KIT - LUTH-AR AR-15 PIN KIT

[Rifle Parts](#) > [Bolt Parts](#) > [Bolt Carrier Parts](#) > [Bolt Carrier Hardware](#)

Pin Kit for AR-15 Keep your AR running smoothly with our pin repair kit. It includes everything you need to fix common issues and get your rifle back to peak performance. With durable materials and easy-to-use instructions, this kit is a must-have for any AR owner. Don't let a broken pin slow you down - get your repair kit today. Contains: LR-30 Rear Takedown Pin LR-18 Pivot Pin BT-14 Firing Pin BT-16 Firing Pin Retaining Pin LR-28 Hammer/Trigger Pin(x2) LR-15 Takedown/Pivot Pin Detent (x2) LR-27 Selector Detent BL-03 Gas Tube Roll Pin LR-12 Bolt Catch Roll Pin UR-06 Forward Assist Roll Pin BT-03 Extractor Pin BT-04 Ejector Pin UR-03 Ejection Port Cover Pin with C-Clip LR-04 Trigger Guard Roll Pin



Attributes

- Name: [LUTH-AR AR-15 PIN KIT](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 430107615
- Mfr. No.: AR-PK
- Weapon type: AR-15
- Delivery weight: 0.454kg
- Shipping height: 76mm
- Shipping width: 178mm
- Shipping length: 178mm
- UPC: 812058031604

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- AR15 Pin Kit Safety Instructions
- About Us

AR15 Pin Kit Safety Instructions

Introduction

Thank you for choosing the AR15 Pin Kit by LUTHAR. This kit is designed to help you maintain your AR15 rifle's performance by providing essential components for repair. To ensure your safety and the proper functioning of your firearm, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always follow local laws and regulations regarding firearms and their components.
- Store all firearm parts, including this pin kit, in a secure location away from children and unauthorized users.
- Inspect all components of the pin kit before use to ensure they are free from damage.
- Use appropriate personal protective equipment (PPE) such as safety glasses when handling firearm components.
- Be aware of your surroundings and ensure you are in a safe environment when performing maintenance on your firearm.

Specific Safety Precautions for Use

- Ensure that your firearm is unloaded before beginning any maintenance or repairs.
- Keep your fingers away from the trigger until you are ready to fire.
- Do not attempt to modify or alter any components of the pin kit unless you are a qualified gunsmith.
- Always follow the manufacturer's instructions for installation and usage.
- If you experience any difficulties during installation or usage, seek assistance from a qualified professional.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded and pointed in a safe direction.
- Gather all necessary tools for installation, including a punch tool and a hammer.

2. Component Identification:

- Familiarize yourself with the components included in the AR15 Pin Kit:
 - LR30 Rear Takedown Pin
 - LR18 Pivot Pin
 - BT14 Firing Pin
 - BT16 Firing Pin Retaining Pin
 - LR28 Hammer/Trigger Pin (x2)
 - LR15 Takedown/Pivot Pin Detent (x2)
 - LR27 Selector Detent
 - BL03 Gas Tube Roll Pin
 - LR12 Bolt Catch Roll Pin
 - UR06 Forward Assist Roll Pin
 - BT03 Extractor Pin
 - BT04 Ejector Pin
 - UR03 Ejection Port Cover Pin with CClip
 - LR04 Trigger Guard Roll Pin

3. Installation Steps:

- **Rear Takedown Pin:**

- Remove the old rear takedown pin using a punch tool.
- Insert the new LR30 Rear Takedown Pin into the designated slot and secure it.

- **Pivot Pin:**

- Follow the same procedure to replace the LR18 Pivot Pin.

- **Firing Pin and Retaining Pin:**

- Remove the old firing pin and replace it with the BT14 Firing Pin.
- Secure it with the BT16 Firing Pin Retaining Pin.

- **Hammer/Trigger Pin:**

- Replace the hammer/trigger pin with the LR28 Hammer/Trigger Pin, ensuring both pins are secure.

- **Detents:**

- Install the LR15 Takedown/Pivot Pin Detents and LR27 Selector Detent as per the instructions.

- **Roll Pins:**

- Install the roll pins (BL03, LR12, UR06, LR04) using a punch tool to ensure they are properly seated.

- **Extractor and Ejector Pins:**

- Replace the BT03 Extractor Pin and BT04 Ejector Pin following the same method.

- **Ejection Port Cover Pin:**

- Install the UR03 Ejection Port Cover Pin with the CClip.

4. Final Check:

- Once all components are installed, conduct a thorough inspection to ensure everything is secure and properly aligned.
- Test the functionality of the firearm in a safe environment.

Disposal Instructions

- Dispose of any damaged or unused components in accordance with local regulations.
- Ensure that all components are disposed of in a manner that prevents unauthorized access.

Contact Information for Further Support

For any inquiries regarding the AR15 Pin Kit or safety concerns, please consult your local firearms dealer or a qualified gunsmith. Always prioritize safety and adhere to the guidelines provided.

Thank you for your attention to these safety instructions. Enjoy your AR15 and the enhanced performance that comes with proper maintenance!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk