

# **DUSK 19 9MM LUGER NON-THREADED BARREL SEMI-AUTO HANDGUN - DUSK 19 9MM LUGER 3.9" BBL (1)15RD MAG BRONZE/BROWN**

Lone Wolf Arms, a company known as a leader of innovation in the Glock aftermarket, is proud to announce the DUSK19 pistol line. With more than two decades of experience providing aftermarket solutions to enhance both the performance and aesthetics of the Glock-pattern pistol, Lone Wolf Arms has implemented these years of development into the DUSK19. The upper includes a DUSK19 profile slide made of 17-4SS and finished in either an attractive black nitride or a selection of great PVD options such as flat dark earth, oil rubbed bronze, or graphite gray. Front and rear serrations on the slide provide ease of chambering and press-check. The slide is reflex sight-ready with the DUSK19 optic cover plate included, which is compatible with both Trijicon RMR/SRO and Holosun 407/507/508 (Non-K Models) footprints. Additionally, this slide includes a ? co-witness Night Fision Stealth Series sight with a Tritium insert for clear sight vision from DUSK to dawn. The upper also includes a 416 stainless-steel PVD coated barrel with the DUSK 19 profile and is available in either threaded or non-threaded. The hood pocket and lateral ribs reduce bearing surface for faster cycling and coating wear resistance. The CCS frame features a 19° grip angle for improved point ability and interchangeable flat & rounded backstraps to allow the shooter the most comfortable choice of grip. The integrated take-down frame scallops for ease of function as well as integrated grip panels with a textured grip for an ergonomic, stable grip. The grip includes an integrated, flared magwell with a grip textured toe kick and an enlarged trigger guard to prevent "Glock knuckle". The trigger is a new flat enhanced system with improved geometry for trigger take-up and decreased energy to actuate. The trigger also offers a 30% reduction in Peak Force from the OEM trigger for smooth and efficient shooting. Additionally, the DUSK19 is light, weighing in at 19.8 oz without a magazine, and is the perfect EDC size at an overall length of 6.95". The DUSK19 Handgun combines the shootability and convenience you look for in a Glock-pattern pistol with the premium, trusted Lone Wolf Arms parts you know and love, engineering a truly unique handgun that is comfortable to shoot and built to last. Key Features: Reflex Sight Ready with DUSK optic cover plate included Interchangeable flat & rounded backstraps for comfortable, customized grip and integrated grip panels with form-fitting texture Stainless steel PVD coated barrel with DUSK profile New enhanced flat trigger system and ergonomic guard profile to reduce "Glock knuckle" Front & rear serrations for ease of chambering and press check Specs: OAL: 6.95" Non-Threaded Barrel Length (breach – muzzle): 3.90" Height (without sights): 4.61" Non-Threaded Barrel Height (with sights): 4.94" Upper Width: 1.00" Lower Width: 1.14" Magwell Width: 1.23" Weight (without magazine): 19.8/oz. Chamber: 9x19



## Attributes

- Name: DUSK 19 9MM LUGER 3.9" BBL (1)15RD MAG BRONZE/BROWN
- Manufacturer: LONE WOLF DIST.
- Product no.: 430107750
- Mfr. No.: LWD-DUSK19-ORB
- Action Type: Semi-Auto
- Barrel Length: 3.9"
- Capacity: 15+1-Round
- Cartridge: 9 mm Luger
- Finish: Bronze/Brown
- Front Sight: Night Sight
- Length: 6.95"
- Magazine Included: 1 x 15-Round
- Magazine Type: Removable
- Make: Lone Wolf
- Model: Dusk 19
- Muzzle: Non-Threaded
- Rear Sight: Tritium
- Safety: No
- Stock Material: Polymer
- Weight: 1.238 lbs
- Delivery weight: 0.726kg
- Shipping height: 89mm
- Shipping width: 260mm
- Shipping length: 216mm
- UPC: 840235900450

## Item details

Made in USA

US export classification: 0A507.a

# Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN](#)
- [English: DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTIONS](#)
- [Italiano: Guida di Sicurezza per l'Utilizzo della Pistola DUSK 19 9MM LUGER](#)

# Sicherheitshinweise für die DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN

## Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN. Diese Anleitung bietet wichtige Sicherheitsinformationen, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden. Bitte lesen Sie die folgenden Informationen sorgfältig durch.

## Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Waffe nur in Übereinstimmung mit den geltenden Gesetzen und Vorschriften verwenden.
- Halten Sie die Waffe immer in einem sicheren Zustand, bis Sie bereit sind zu schießen.
- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Bewahren Sie die Waffe außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Überprüfen Sie vor jeder Benutzung die Waffe auf Beschädigungen oder Mängel.

## Besondere Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Achten Sie darauf, dass der Lauf frei von Hindernissen ist, bevor Sie schießen.
- Halten Sie den Abzug nicht gedrückt, während Sie die Waffe laden oder entladen.
- Tragen Sie beim Schießen immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Seien Sie sich der Umgebung bewusst, in der Sie schießen, und stellen Sie sicher, dass sich keine Personen oder Tiere im Schussfeld befinden.

## Anweisungen zur Installation und Nutzung

1. **Waffe entladen:** Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie sie handhaben.
2. **Magazin einsetzen:** Führen Sie das Magazin in den Magazinschacht ein, bis es einrastet.
3. **Waffe laden:** Ziehen Sie den Schlitten zurück und lassen Sie ihn los, um eine Patrone in die Kammer zu laden.
4. **Zielen und Schießen:** Richten Sie die Waffe auf das Ziel und drücken Sie den Abzug sanft, um zu schießen.
5. **Nach dem Schießen:** Entladen Sie die Waffe, indem Sie den Schlitten zurückziehen und das Magazin entfernen. Überprüfen Sie die Kammer, um sicherzustellen, dass keine Patrone verbleibt.

## Entsorgungsanweisungen

- Entsorgen Sie die Waffe nicht in den normalen Hausmüll.
- Befolgen Sie die örtlichen Vorschriften zur Entsorgung von Waffen und Munition.
- Wenden Sie sich an autorisierte Stellen oder Fachhändler, um Informationen zur sicheren Entsorgung zu erhalten.

## Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung bezüglich der DUSK 19 9MM LUGER HANDGUN wenden Sie sich bitte an den Händler oder Hersteller, bei dem Sie das Produkt erworben haben.

## Schlussfolgerung

Die Sicherheit hat oberste Priorität. Indem Sie die oben genannten Richtlinien befolgen, können Sie die Sicherheit und Leistung Ihrer DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN gewährleisten. Bei Fragen oder Bedenken zur Sicherheit zögern Sie nicht, Unterstützung zu suchen.

# DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the DUSK 19 9MM Luger SemiAuto Handgun. This guide provides important safety instructions and guidelines to ensure the safe use of your firearm. It is essential to familiarize yourself with these instructions to promote safety for yourself and others.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Always wear eye and ear protection when shooting.
- Store the firearm securely and out of reach of children and unauthorized users.
- Regularly inspect the handgun for any signs of damage or wear.
- Follow all local laws and regulations regarding firearm ownership and use.

## Specific Safety Precautions for Use

- Ensure that the firearm is in good working condition before use.
- Only use ammunition that is specifically designed for the DUSK 19 9MM Luger.
- Do not attempt to modify or alter the firearm in any way.
- Avoid using the handgun in wet or damp conditions to prevent corrosion.
- Be cautious of the muzzle when loading and unloading the firearm.
- If a round does not fire, wait at least 30 seconds before attempting to eject it.
- If you experience any malfunctions, cease use immediately and consult a qualified gunsmith.

## Instructions for Installation and Usage

### 1. Loading the Magazine:

- Ensure the firearm is pointed in a safe direction.
- Insert the magazine into the magazine well until it clicks into place.
- Pull the slide back and release it to chamber a round.

### 2. Firing the Handgun:

- Assume a proper shooting stance with a firm grip on the firearm.
- Aim at your target while keeping your finger off the trigger.
- When ready, apply pressure to the trigger to fire.
- After firing, keep the firearm pointed downrange until you are finished shooting.

### 3. Unloading the Handgun:

- Point the firearm in a safe direction.
- Remove the magazine from the magazine well.
- Pull the slide back to ensure the chamber is empty.
- Visually and physically inspect the chamber to confirm it is clear.

### 4. Cleaning and Maintenance:

- Regularly clean the firearm using appropriate cleaning supplies.
- Lubricate moving parts as recommended in the product manual.
- Store the firearm in a cool, dry place when not in use.

## Disposal Instructions

- Dispose of any spent ammunition and firearm components in accordance with local regulations.
- If the handgun is no longer in use, consider turning it in to a licensed dealer or local law enforcement for safe disposal.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the DUSK 19 9MM Luger SemiAuto Handgun, please consult the manufacturer or a qualified firearms expert. It is essential to ensure that you have the most accurate and up-to-date information regarding your firearm.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your DUSK 19 9MM Luger SemiAuto Handgun. Always prioritize safety and stay informed about best practices for firearm use.

# Guida di Sicurezza per l'Utilizzo della Pistola DUSK 19 9MM LUGER

## Introduzione

Grazie per aver scelto la pistola DUSK 19 9MM Luger. Questa guida di sicurezza è progettata per garantire un utilizzo sicuro e responsabile del prodotto. Si prega di leggere attentamente tutte le istruzioni e le avvertenze prima di utilizzare la pistola.

## Linee Guida Generali di Sicurezza

- Seguire sempre le istruzioni del produttore e le normative locali riguardanti la detenzione e l'uso delle armi.
- Tenere la pistola lontano dalla portata di bambini e persone non autorizzate.
- Utilizzare solo munizioni appropriate per il modello DUSK 19 9MM Luger.
- Controllare sempre che l'arma sia scarica quando non è in uso o prima di effettuare operazioni di manutenzione.
- Non puntare mai l'arma verso qualcosa che non si intende colpire.
- Indossare sempre occhiali protettivi e protezioni per le orecchie durante l'uso.

## Precauzioni di Sicurezza Specifiche per l'Uso

- Assicurarsi che la pistola sia in buone condizioni e che tutte le parti siano correttamente assemblate prima dell'uso.
- Non modificare la pistola in alcun modo che possa comprometterne la sicurezza o le prestazioni.
- Durante il caricamento o lo scaricamento, mantenere sempre la canna puntata in una direzione sicura.
- Non utilizzare la pistola se si è sotto l'influenza di alcol o sostanze stupefacenti.
- In caso di malfunzionamenti, seguire le istruzioni del produttore per la risoluzione dei problemi e non tentare riparazioni non autorizzate.

## Istruzioni per l'Installazione e l'Uso

### 1. Installazione del Mirino Reflex:

- Rimuovere la piastra di copertura ottica DUSK19.
- Montare il mirino reflex compatibile seguendo le istruzioni del produttore.
- Ripristinare la piastra di copertura ottica se non si utilizza il mirino.

### 2. Caricamento della Pistola:

- Assicurarsi che la pistola sia scarica.
- Inserire il caricatore da 15 colpi nella pistola finché non scatta in posizione.
- Tirare indietro il carrello e rilasciarlo per caricare un colpo in camera.

### 3. Sparare:

- Assumere una posizione di tiro sicura.
- Mirare al bersaglio e premere il grilletto con un movimento fluido.
- Dopo aver sparato, controllare sempre l'area circostante per garantire la sicurezza.

### 4. Scaricamento:

- Rimuovere il caricatore dalla pistola.
- Tirare indietro il carrello per espellere eventuali colpi in camera.
- Controllare visivamente che la camera sia vuota.

## Istruzioni per lo Smaltimento

- Non smaltire la pistola o le munizioni nell'immondizia domestica.
- Seguire le normative locali per lo smaltimento delle armi e delle munizioni.
- Contattare le autorità competenti per informazioni su come smaltire in modo sicuro.

## **Informazioni di Contatto per Ulteriore Supporto**

Per domande o preoccupazioni riguardanti la sicurezza del prodotto, si prega di contattare il rivenditore presso il quale è stata acquistata la pistola o consultare il sito web ufficiale di Lone Wolf Arms per ulteriori informazioni.

## **Conclusione**

La sicurezza è la massima priorità quando si utilizza un'arma da fuoco. Seguendo queste linee guida e precauzioni, si può contribuire a garantire un utilizzo sicuro e responsabile della pistola DUSK 19 9MM Luger.