

DUSK 19 9MM LUGER NON-THREADED BARREL SEMI-AUTO HANDGUN - DUSK 19 9MM LUGER 3.9" BBL (1)15RD MAG FDE/BLACK

Lone Wolf Arms, a company known as a leader of innovation in the Glock aftermarket, is proud to announce the DUSK19 pistol line. With more than two decades of experience providing aftermarket solutions to enhance both the performance and aesthetics of the Glock-pattern pistol, Lone Wolf Arms has implemented these years of development into the DUSK19. The upper includes a DUSK19 profile slide made of 17-4SS and finished in either an attractive black nitride or a selection of great PVD options such as flat dark earth, oil rubbed bronze, or graphite gray. Front and rear serrations on the slide provide ease of chambering and press-check. The slide is reflex sight-ready with the DUSK19 optic cover plate included, which is compatible with both Trijicon RMR/SRO and Holosun 407/507/508 (Non-K Models) footprints. Additionally, this slide includes a ? co-witness Night Fision Stealth Series sight with a Tritium insert for clear sight vision from DUSK to dawn. The upper also includes a 416 stainless-steel PVD coated barrel with the DUSK 19 profile and is available in either threaded or non-threaded. The hood pocket and lateral ribs reduce bearing surface for faster cycling and coating wear resistance. The CCS frame features a 19° grip angle for improved point ability and interchangeable flat & rounded backstraps to allow the shooter the most comfortable choice of grip. The integrated take-down frame scallops for ease of function as well as integrated grip panels with a textured grip for an ergonomic, stable grip. The grip includes an integrated, flared magwell with a grip textured toe kick and an enlarged trigger guard to prevent "Glock knuckle". The trigger is a new flat enhanced system with improved geometry for trigger take-up and decreased energy to actuate. The trigger also offers a 30% reduction in Peak Force from the OEM trigger for smooth and efficient shooting. Additionally, the DUSK19 is light, weighing in at 19.8 oz without a magazine, and is the perfect EDC size at an overall length of 6.95". The DUSK19 Handgun combines the shootability and convenience you look for in a Glock-pattern pistol with the premium, trusted Lone Wolf Arms parts you know and love, engineering a truly unique handgun that is comfortable to shoot and built to last. Key Features: Reflex Sight Ready with DUSK optic cover plate included Interchangeable flat & rounded backstraps for comfortable, customized grip and integrated grip panels with form-fitting texture Stainless steel PVD coated barrel with DUSK profile New enhanced flat trigger system and ergonomic guard profile to reduce "Glock knuckle" Front & rear serrations for ease of chambering and press check Specs: OAL: 6.95" Non-Threaded Barrel Length (breach – muzzle): 3.90" Height (without sights): 4.61" Non-Threaded Barrel Height (with sights): 4.94" Upper Width: 1.00" Lower Width: 1.14" Magwell Width: 1.23" Weight (without magazine): 19.8/oz. Chamber: 9x19



Attributes

- Name: DUSK 19 9MM LUGER 3.9" BBL (1)15RD MAG FDE/BLACK
- Manufacturer: LONE WOLF DIST.
- Product no.: 430107751
- Mfr. No.: LWD-DUSK19-FDE-
- Action Type: Semi-Auto
- Barrel Length: 3.9"
- Capacity: 15+1-Round
- Cartridge: 9 mm Luger
- Finish: Black/Flat Dark Earth
- Front Sight: Night Sight
- Length: 6.95"
- Magazine Included: 1 x 15-Round
- Magazine Type: Removable
- Make: Lone Wolf
- Model: Dusk 19
- Muzzle: Non-Threaded
- Rear Sight: Tritium
- Safety: No
- Stock Material: Polymer
- Weight: 1.238 lbs
- Delivery weight: 0.726kg
- Shipping height: 89mm
- Shipping width: 260mm
- Shipping length: 216mm
- UPC: 840235900474

Item details

Made in USA

US export classification: 0A507.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN](#)
- [English: DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTIONS](#)
- [Italiano: Istruzioni di Sicurezza per l'Uso della Pistola DUSK 19 9MM LUGER](#)

Sicherheitshinweise für die DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN

Einführung

Herzlichen Glückwunsch zum Kauf Ihrer DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN. Diese Anleitung bietet wichtige Sicherheitsinformationen, um eine sichere Verwendung des Produkts zu gewährleisten. Bitte lesen Sie alle Anweisungen sorgfältig durch, bevor Sie das Produkt verwenden.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt nur von Personen verwendet wird, die mit der Handhabung von Schusswaffen vertraut sind.
- Halten Sie die Waffe immer in einem sicheren Zustand, bis Sie bereit sind zu schießen.
- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Bewahren Sie die Waffe an einem sicheren Ort auf, der für Kinder unzugänglich ist.
- Überprüfen Sie regelmäßig auf Abnutzung oder Beschädigungen und lassen Sie die Waffe bei Bedarf von einem Fachmann warten.
- Melden Sie unsichere Produkte und Unfälle umgehend den Behörden.

Spezifische Sicherheitsvorkehrungen zur Nutzung

- Verwenden Sie nur die empfohlenen Munitionstypen, um Fehlfunktionen zu vermeiden.
- Tragen Sie immer Gehörschutz und Schutzbrille beim Schießen.
- Achten Sie darauf, dass sich niemand in der Schusslinie befindet.
- Überprüfen Sie vor dem Laden der Waffe, ob sie entladen ist.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind zu schießen.
- Achten Sie darauf, dass der Lauf frei von Hindernissen ist, bevor Sie abdrücken.

Anweisungen zur Installation und Nutzung

1. Laden der Waffe:

- Stellen Sie sicher, dass die Waffe entladen ist.
- Führen Sie das Magazin in den Magazinschacht ein, bis es einrastet.
- Ziehen Sie den Schlitten zurück und lassen Sie ihn los, um eine Patrone in die Kammer zu laden.

2. Entladen der Waffe:

- Richten Sie die Waffe in eine sichere Richtung.
- Ziehen Sie den Schlitten zurück, um die Patrone aus der Kammer zu entfernen.
- Entfernen Sie das Magazin aus dem Magazinschacht.

3. Reinigung und Wartung:

- Reinigen Sie die Waffe regelmäßig, um ihre Funktionsfähigkeit zu gewährleisten.
- Verwenden Sie geeignete Reinigungsmittel und Werkzeuge.
- Überprüfen Sie die Waffe auf Abnutzung oder Beschädigungen und lassen Sie sie bei Bedarf von einem Fachmann warten.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährlichen Abfall.
- Entsorgen Sie die Waffe nur durch autorisierte Fachleute oder gemäß den geltenden Gesetzen und Vorschriften.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrer DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben.

Bitte beachten Sie, dass die Sicherheit an erster Stelle steht. Halten Sie sich an alle Anweisungen und Richtlinien, um eine sichere und verantwortungsvolle Nutzung Ihrer DUSK 19 Handfeuerwaffe zu gewährleisten.

DUSK 19 9MM LUGER NONTHREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the DUSK 19 9MM Luger SemiAuto Handgun. This safety instruction guide is designed to help you use your handgun safely and responsibly, in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using your firearm.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the firearm in a safe direction, away from yourself and others.
- Be aware of your target and what is beyond it.
- Store your handgun in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your handgun for any signs of wear or damage.
- Use only the recommended ammunition specified for your handgun.
- Follow all local and national laws regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure the handgun is unloaded before cleaning or performing maintenance.
- Do not attempt to modify or alter the handgun in any way.
- Always wear appropriate eye and ear protection when shooting.
- Be cautious of environmental conditions that may affect shooting, such as wind or poor visibility.
- Avoid using the handgun under the influence of alcohol or drugs.
- Use a proper shooting stance and grip to ensure control and accuracy.
- Be aware of the potential for ricochet and take necessary precautions.

Instructions for Installation and Usage

1. Preparation:

- Ensure the handgun is pointed in a safe direction.
- Check that the magazine is removed and the chamber is empty.

2. Loading the Handgun:

- Insert the magazine into the grip until it clicks into place.
- Pull the slide back to chamber a round, ensuring it locks into place.

3. Firing the Handgun:

- Aim at your target while maintaining a proper grip.
- Place your finger on the trigger only when ready to fire.
- Squeeze the trigger smoothly and steadily to fire.

4. Unloading the Handgun:

- Remove the magazine from the grip.
- Pull the slide back to eject any chambered round.
- Visually and physically inspect the chamber to ensure it is empty.

5. Cleaning and Maintenance:

- Follow the manufacturer's instructions for cleaning and maintenance.
- Use appropriate cleaning supplies and tools.
- Store the handgun in a clean, dry place after maintenance.

Disposal Instructions

When disposing of your handgun, follow these steps: * Consult local laws and regulations regarding the disposal of firearms. * If applicable, contact local law enforcement or a licensed dealer for safe disposal options. * Never dispose of firearms in regular trash or recycling.

Contact Information for Further Support

For any safety inquiries or concerns regarding your DUSK 19 handgun, please refer to the manufacturer's contact information provided in the product documentation.

Conclusion

By following these safety instructions, you can help ensure a safe and enjoyable experience with your DUSK 19 9MM Luger SemiAuto Handgun. Always prioritize safety and responsibility in your use of firearms. Thank you for your attention to these important guidelines.

Istruzioni di Sicurezza per l'Uso della Pistola DUSK 19 9MM LUGER

Introduzione

Grazie per aver scelto la pistola DUSK 19 9MM LUGER. Questo manuale fornisce istruzioni di sicurezza essenziali per garantire un uso corretto e sicuro del prodotto. Si prega di leggere attentamente queste istruzioni prima di utilizzare la pistola.

Linee Guida Generali di Sicurezza

- Assicurarsi di maneggiare sempre la pistola come se fosse carica.
- Tenere la pistola lontano dalla portata di bambini e persone non autorizzate.
- Utilizzare solo munizioni appropriate per il modello DUSK 19 9MM LUGER.
- Non puntare mai la pistola verso qualcosa che non si intende colpire.
- Indossare sempre occhiali di protezione e protezioni per le orecchie durante l'uso.
- Seguire tutte le leggi locali e nazionali relative alla detenzione e all'uso di armi da fuoco.

Precauzioni di Sicurezza Specifiche per l'Uso

- **Controllo della Camera:** Prima di ogni utilizzo, controllare sempre che la camera sia vuota e che non ci siano munizioni nel caricatore.
- **Caricamento e Scaricamento:** Effettuare il caricamento e lo scaricamento in un'area sicura e lontano da altre persone.
- **Uso del Mirino:** Assicurarsi che il mirino sia correttamente installato e regolato prima dell'uso.
- **Manutenzione:** Effettuare regolarmente la manutenzione della pistola per garantire il suo corretto funzionamento. Consultare il manuale per le procedure specifiche di pulizia e manutenzione.

Istruzioni per l'Installazione e l'Uso

1. Installazione del Mirino:

- Rimuovere la piastra di copertura ottica DUSK19.
- Installare il mirino reflex compatibile seguendo le istruzioni del produttore.
- Riapplicare la piastra di copertura se non si utilizza un mirino reflex.

2. Caricamento della Pistola:

- Assicurarsi che la pistola sia in posizione di sicurezza (canna puntata in basso).
- Inserire il caricatore nella pistola fino a sentire un clic.
- Tirare indietro il carrello per caricare una munizione nella camera.

3. Scaricamento della Pistola:

- Puntare la pistola in un'area sicura.
- Rimuovere il caricatore.
- Tirare indietro il carrello per espellere eventuali munizioni dalla camera.
- Controllare visivamente e fisicamente che la camera sia vuota.

4. Utilizzo della Pistola:

- Posizionarsi in una postura stabile e sicura.
- Inquadrare il bersaglio utilizzando il mirino.
- Premere il grilletto in modo controllato e uniforme.

Istruzioni per lo Smaltimento

- Non smaltire la pistola o le munizioni nell'immondizia domestica.
- Seguire le leggi locali per lo smaltimento delle armi da fuoco e delle munizioni.
- Contattare un rivenditore autorizzato o un servizio di smaltimento di armi per la corretta procedura di smaltimento.

Informazioni di Contatto per Ulteriori Supporto

Per domande relative alla sicurezza o alla manutenzione del prodotto, si prega di contattare il rivenditore presso il quale è stata acquistata la pistola o un centro di assistenza autorizzato.

Conclusione

La sicurezza è fondamentale quando si utilizza una pistola. Seguire queste istruzioni e le linee guida di sicurezza per garantire un'esperienza di utilizzo sicura e responsabile della DUSK 19 9MM LUGER.