

DUSK 19 9MM LUGER THREADED BARREL SEMI-AUTO HANDGUN - DUSK 19 9MM LUGER 3.9" THREAD BBL (1)15RD MAG GRAPHITE/GRAY

Lone Wolf Arms, a company known as a leader of innovation in the Glock aftermarket, is proud to announce the DUSK19 pistol line. With more than two decades of experience providing aftermarket solutions to enhance both the performance and aesthetics of the Glock-pattern pistol, Lone Wolf Arms has implemented these years of development into the DUSK19. The upper includes a new DUSK19 profile slide made of 17-4SS and finished in either an attractive black nitride or a selection of great PVD options such as flat dark earth, oil rubbed bronze, or graphite gray. Front and rear serrations on the slide provide ease of chambering and press-check. The slide is reflex sight-ready with the DUSK19 optic cover plate included, which is compatible with both Trijicon RMR/SRO and Holosun 407/507/508 (Non-K Models) footprints. Additionally, this slide includes a suppressor height Night Fision Stealth Series sight with a Tritium insert for clear sight vision from DUSK to dawn. The upper also includes a 416 stainless-steel PVD coated barrel with the new DUSK 19 profile and is available in either threaded or non-threaded. The hood pocket and lateral ribs reduce bearing surface for faster cycling and coating wear resistance. The CCS frame features a 19° grip angle for improved point ability and interchangeable flat & rounded backstraps to allow the shooter the most comfortable choice of grip. The integrated take-down frame scallops for ease of function as well as integrated grip panels with a textured grip for an ergonomic, stable grip. The grip includes an integrated, flared magwell with a grip textured toe kick and an enlarged trigger guard to prevent "Glock knuckle". The trigger is a new flat enhanced system with improved geometry for trigger take-up and decreased energy to actuate. The trigger also offers a 30% reduction in Peak Force from the OEM trigger for smooth and efficient shooting. Additionally, the DUSK19 with a threaded barrel is light, weighing in at 20.0 oz without a magazine, and is the perfect EDC size at an overall length of 7.655". The DUSK19 Handgun combines the shootability and convenience you look for in a Glock-pattern pistol with the premium, trusted Lone Wolf Arms parts you know and love, engineering a truly unique handgun that is comfortable to shoot and built to last. Key Features: Reflex Sight Ready with DUSK optic cover plate included Interchangeable flat & rounded backstraps for comfortable, customized grip and integrated grip panels with form-fitting texture Stainless steel PVD coated barrel with DUSK profile New enhanced flat trigger system and ergonomic guard profile to reduce "Glock knuckle" Front & rear serrations for ease of chambering and press check Specs: OAL (w/ threaded barrel): 7.655" Threaded Barrel Length (breach – muzzle): 4.60" Height (without sights): 4.61" Threaded Barrel Height (with sights): 5.08" Upper Width: 1.00" Lower Width: 1.14" Magwell Width: 1.23" Weight (without magazine): 19.8/oz. Chamber: 9x19



Attributes

- Name: DUSK 19 9MM LUGER 3.9" THREAD BBL (1)15RD MAG GRAPHITE/GRAY
- Manufacturer: LONE WOLF DIST.
- Product no.: 430107759
- Mfr. No.: LWD-DUSK19-GG-G
- Action Type: Semi-Auto
- Barrel Length: 3.9"
- Capacity: 15+1-Round
- Cartridge: 9 mm Luger
- Finish: Gray
- Front Sight: Night Sight
- Length: 7.655"
- Magazine Included: 1 x 15-Round
- Magazine Type: Removable
- Make: Lone Wolf
- Model: Dusk 19
- Muzzle: Threaded
- Rear Sight: Tritium
- Safety: None
- Stock Material: Polymer
- Weight: 1.25 lbs
- Delivery weight: 0.635kg
- Shipping height: 89mm
- Shipping width: 260mm
- Shipping length: 216mm
- UPC: 840235900498

Item details

Made in USA

US export classification: 0A507.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN](#)
- [English: DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTION GUIDE](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN](#)

Sicherheitshinweise für die DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN

Einführung

Vielen Dank, dass du dich für die DUSK 19 9MM LUGER entschieden hast. Diese Anleitung bietet wichtige Informationen zur sicheren Verwendung und Wartung deiner Handfeuerwaffe. Bitte lies die folgenden Sicherheitsrichtlinien sorgfältig durch, um sicherzustellen, dass du die Waffe sicher und verantwortungsbewusst verwendest.

Allgemeine Sicherheitsrichtlinien

- Halte die Waffe immer in einem sicheren Zustand, bis du bereit bist zu schießen.
- Behandle jede Waffe so, als ob sie geladen wäre.
- Richte die Mündung niemals auf etwas, das du nicht treffen möchtest.
- Halte deinen Finger außerhalb des Abzugsbügels, bis du bereit bist, abzugeben.
- Verwende nur die empfohlenen Munitionstypen für deine Waffe.
- Bewahre die Waffe an einem sicheren Ort auf, außerhalb der Reichweite von Kindern und unbefugten Personen.
- Überprüfe regelmäßig den Zustand deiner Waffe und führe Wartungsarbeiten durch, um ihre Sicherheit zu gewährleisten.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwende beim Schießen immer Gehörschutz und Schutzbrillen.
- Achte auf deine Umgebung, um sicherzustellen, dass keine unbefugten Personen in der Nähe sind.
- Überprüfe vor dem Laden der Waffe, ob sie sauber und funktionsfähig ist.
- Vermeide es, die Waffe während des Schießens zu überladen.
- Wenn die Waffe nicht richtig funktioniert, lade sie sofort ab und überprüfe sie, bevor du sie erneut verwendest.
- Lass die Waffe niemals unbeaufsichtigt, insbesondere in der Nähe von Kindern.

Anweisungen zur Installation und Verwendung

1. Installation des Zubehörs:

- Stelle sicher, dass die Waffe entladen ist, bevor du Zubehör installierst.
- Befolge die Anweisungen des Herstellers für die Installation von Optiken oder anderen Zubehörteilen.

2. Laden der Waffe:

- Öffne das Magazin und lade die Munition gemäß den Anweisungen.
- Setze das Magazin in die Waffe ein, bis es einrastet.
- Ziehe den Schlitten nach hinten und lasse ihn los, um die erste Patrone in die Kammer zu laden.

3. Benutzung der Waffe:

- Finde eine sichere Schießposition und ziele auf die Zielscheibe.
- Drücke gleichmäßig auf den Abzug, um den Schuss abzugeben.
- Nach dem Schießen, halte die Waffe auf die Zielscheibe gerichtet, bis du sicher bist, dass es keine weiteren Schüsse mehr gibt.

4. Entladen der Waffe:

- Ziehe den Schlitten zurück, um die Patrone aus der Kammer zu entfernen.
- Entnehme das Magazin und überprüfe, ob die Waffe vollständig entladen ist.

Entsorgungsanweisungen

- Entsorge leere Munition und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Wenn die Waffe nicht mehr funktionsfähig ist, bringe sie zu einem autorisierten Fachmann zur sicheren Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung bezüglich der DUSK 19 9MM LUGER wende dich bitte an den Hersteller oder einen autorisierten Fachhändler. Stelle sicher, dass du alle erforderlichen Informationen bereithältst, um deine Anfrage zu bearbeiten.

Schlussfolgerung

Die Sicherheit hat oberste Priorität. Durch das Befolgen dieser Sicherheitsrichtlinien kannst du sicherstellen, dass du die DUSK 19 9MM LUGER verantwortungsbewusst und sicher verwendest. Bei Fragen oder Unsicherheiten konsultiere immer einen Fachmann oder die entsprechenden Ressourcen. Schieße verantwortungsbewusst und genieße die Leistung deiner Handfeuerwaffe.

DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the DUSK 19 9MM Luger Threaded Barrel SemiAuto Handgun. This guide provides important safety instructions to ensure the safe and effective use of your handgun. Please read all instructions carefully before use.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store your firearm securely and out of reach of children and unauthorized users.
- Regularly inspect your firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure that you are familiar with the operation of the DUSK 19 before using it.
- Use only the recommended 9mm Luger ammunition for this handgun.
- Do not modify the handgun or use aftermarket parts that are not approved by the manufacturer.
- Wear appropriate eye and ear protection when shooting.
- Practice safe handling techniques when loading, unloading, and cleaning your firearm.
- If the firearm fails to fire, keep the muzzle pointed in a safe direction and wait at least 30 seconds before attempting to clear the malfunction.
- Be cautious of the recoil and muzzle rise when firing the handgun.

Instructions for Installation and Usage

1. Loading the Handgun:

- Ensure the handgun is pointed in a safe direction.
- Check that the firearm is unloaded by visually inspecting the chamber and magazine.
- Insert the magazine into the grip until it clicks into place.
- Pull the slide to the rear and release it to chamber a round.

2. Firing the Handgun:

- Hold the handgun with a firm grip, ensuring your finger is off the trigger until ready to shoot.
- Aim at your target, ensuring the firearm is pointed in a safe direction.
- Gently squeeze the trigger to fire.

3. Unloading the Handgun:

- Point the handgun in a safe direction.
- Remove the magazine by pressing the magazine release button.
- Pull the slide to the rear to eject any chambered round.
- Visually inspect the chamber to ensure it is empty.

4. Cleaning and Maintenance:

- Disassemble the handgun according to the manufacturer's instructions.
- Clean all components using appropriate cleaning supplies.
- Regularly lubricate the moving parts as recommended in the product manual.

Disposal Instructions

- Dispose of the handgun in accordance with local laws and regulations.
- If you need to dispose of ammunition, contact your local law enforcement agency or a licensed firearms dealer for guidance on safe disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the DUSK 19, please refer to the manufacturer's resources or contact your local firearms dealer. Always ensure that you are following all local laws and regulations regarding firearm use and safety.

Conclusion

Safety is paramount when handling firearms. By following the guidelines and precautions outlined in this instruction guide, you can ensure a safer shooting experience with your DUSK 19 9MM Luger Threaded Barrel SemiAuto Handgun. Thank you for your attention to safety, and enjoy your shooting experience responsibly.

Guida alle Istruzioni di Sicurezza per DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN

Introduzione

Grazie per aver scelto la pistola DUSK 19 9MM LUGER. Questa guida fornisce informazioni importanti sulla sicurezza, l'uso corretto e la manutenzione del prodotto, in conformità con le normative europee sulla sicurezza dei prodotti. È fondamentale seguire queste istruzioni per garantire un utilizzo sicuro e responsabile.

Linee Guida Generali di Sicurezza

- Assicurati di leggere attentamente tutte le istruzioni prima dell'uso.
- Mantieni la pistola sempre in sicurezza, trattandola come se fosse carica.
- Non puntare mai la pistola verso qualcosa che non si intende colpire.
- Tieni la pistola lontana dalla portata dei bambini e di persone non autorizzate.
- Utilizza solo munizioni appropriate per il modello DUSK 19 9MM LUGER.
- Non modificare mai la pistola o utilizzare accessori non approvati.
- Segui sempre le leggi locali riguardanti la detenzione e l'uso delle armi da fuoco.

Precauzioni di Sicurezza Specifiche per l'Uso

- Prima di utilizzare la pistola, assicurati che sia completamente scarica.
- Indossa sempre occhiali e protezioni per le orecchie quando si spara.
- Non utilizza la pistola in condizioni di scarsa visibilità o in ambienti non controllati.
- Non sparare mai in direzione di persone o animali.
- In caso di inceppamenti, segui le procedure di sicurezza per la risoluzione dei problemi e non tentare di smontare la pistola mentre è carica.
- Non lasciare mai la pistola incustodita, anche se è scarica.

Istruzioni per l'Installazione e l'Uso

Installazione

1. **Controllo Iniziale:** Assicurati che la pistola sia scarica.
2. **Montaggio del Mirino:** Se desideri installare un mirino reflex, utilizza la piastra di copertura ottica DUSK inclusa. Segui le istruzioni del produttore per il montaggio.
3. **Controllo della Canne:** Verifica che la canna sia correttamente installata e che non ci siano ostruzioni.

Uso

- **Caricamento:** Carica il caricatore con le munizioni appropriate. Assicurati che il caricatore sia inserito correttamente nella pistola.
- **Sparare:** Tieni la pistola con entrambe le mani e punta verso il bersaglio. Premi il grilletto lentamente per sparare.
- **Scarico:** Dopo aver finito di sparare, scarica la pistola e controlla che non ci siano munizioni nel caricatore o nella camera.

Istruzioni per lo Smaltimento

- Segui le leggi locali riguardanti lo smaltimento delle armi da fuoco e delle munizioni.
- Non smaltire la pistola in modo irresponsabile. Rivolgiti a un professionista autorizzato per la dismissione.

Informazioni di Contatto per Ulteriori Supporto

Per domande riguardanti la sicurezza, l'uso o la manutenzione della pistola DUSK 19 9MM LUGER, contatta il tuo rivenditore o il produttore per ricevere assistenza. Assicurati di avere il numero di serie e la prova di acquisto a portata di mano.

Conclusione

Seguendo queste linee guida di sicurezza, contribuirai a garantire un utilizzo sicuro e responsabile della tua pistola DUSK 19 9MM LUGER. Ricorda sempre di esercitare cautela e responsabilità quando maneggi armi da fuoco.