

DUSK 19 9MM LUGER THREADED BARREL SEMI-AUTO HANDGUN - DUSK 19 9MM LUGER 3.9" THREADED BBL (1)15RD MAG BLACK/GRAY

Lone Wolf Arms, a company known as a leader of innovation in the Glock aftermarket, is proud to announce the DUSK19 pistol line. With more than two decades of experience providing aftermarket solutions to enhance both the performance and aesthetics of the Glock-pattern pistol, Lone Wolf Arms has implemented these years of development into the DUSK19. The upper includes a new DUSK19 profile slide made of 17-4SS and finished in either an attractive black nitride or a selection of great PVD options such as flat dark earth, oil rubbed bronze, or graphite gray. Front and rear serrations on the slide provide ease of chambering and press-check. The slide is reflex sight-ready with the DUSK19 optic cover plate included, which is compatible with both Trijicon RMR/SRO and Holosun 407/507/508 (Non-K Models) footprints. Additionally, this slide includes a suppressor height Night Fision Stealth Series sight with a Tritium insert for clear sight vision from DUSK to dawn. The upper also includes a 416 stainless-steel PVD coated barrel with the new DUSK 19 profile and is available in either threaded or non-threaded. The hood pocket and lateral ribs reduce bearing surface for faster cycling and coating wear resistance. The CCS frame features a 19° grip angle for improved point ability and interchangeable flat & rounded backstraps to allow the shooter the most comfortable choice of grip. The integrated take-down frame scallops for ease of function as well as integrated grip panels with a textured grip for an ergonomic, stable grip. The grip includes an integrated, flared magwell with a grip textured toe kick and an enlarged trigger guard to prevent "Glock knuckle". The trigger is a new flat enhanced system with improved geometry for trigger take-up and decreased energy to actuate. The trigger also offers a 30% reduction in Peak Force from the OEM trigger for smooth and efficient shooting. Additionally, the DUSK19 with a threaded barrel is light, weighing in at 20.0 oz without a magazine, and is the perfect EDC size at an overall length of 7.655". The DUSK19 Handgun combines the shootability and convenience you look for in a Glock-pattern pistol with the premium, trusted Lone Wolf Arms parts you know and love, engineering a truly unique handgun that is comfortable to shoot and built to last. Key Features: Reflex Sight Ready with DUSK optic cover plate included Interchangeable flat & rounded backstraps for comfortable, customized grip and integrated grip panels with form-fitting texture Stainless steel PVD coated barrel with DUSK profile New enhanced flat trigger system and ergonomic guard profile to reduce "Glock knuckle" Front & rear serrations for ease of chambering and press check Specs: OAL (w/ threaded barrel): 7.655" Threaded Barrel Length (breach – muzzle): 4.60" Height (without sights): 4.61" Threaded Barrel Height (with sights): 5.08" Upper Width: 1.00" Lower Width: 1.14" Magwell Width: 1.23" Weight (without magazine): 19.8/oz. Chamber: 9x19



Attributes

- Name: DUSK 19 9MM LUGER 3.9" THREADED BBL (1)15RD MAG BLACK/GRAY
- Manufacturer: LONE WOLF DIST.
- Product no.: 430107760
- Mfr. No.: LWD-DUSK19-BLK-
- Action Type: Semi-Auto
- Barrel Length: 3.9"
- Capacity: 15+1-Round
- Cartridge: 9 mm Luger
- Finish: Black/Gray
- Front Sight: Night Sight
- Length: 7.655"
- Magazine Included: 1 x 15-Round
- Magazine Type: Removable
- Make: Lone Wolf
- Model: Dusk 19
- Muzzle: Threaded
- Rear Sight: Tritium
- Safety: No
- Stock Material: Polymer
- Weight: 1.25 lbs
- Delivery weight: 0.635kg
- Shipping height: 89mm
- Shipping width: 260mm
- Shipping length: 216mm
- UPC: 840235900535

Item details

Made in USA

US export classification: 0A507.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN](#)
- [English: DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTIONS](#)
- [Italiano: Istruzioni di Sicurezza per il DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN](#)

Sicherheitshinweise für die DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN von Lone Wolf Arms. Diese Anleitung bietet wichtige Sicherheitsinformationen und Anweisungen, um eine sichere Verwendung des Produkts zu gewährleisten. Bitte lesen Sie die folgenden Informationen sorgfältig durch, um sicherzustellen, dass Sie die Handfeuerwaffe sicher und verantwortungsbewusst nutzen.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die gesetzlichen Bestimmungen zum Besitz und Gebrauch von Feuerwaffen in Ihrem Land oder Ihrer Region kennen und befolgen.
- Bewahren Sie die Waffe immer entladen und sicher auf, wenn sie nicht in Gebrauch ist.
- Halten Sie die Waffe immer in Richtung einer sicheren Richtung, auch wenn sie entladen ist.
- Lassen Sie die Waffe niemals in der Nähe von Kindern oder unbefugten Personen.
- Verwenden Sie die Waffe nur mit der für sie vorgesehenen Munition (9mm Luger).
- Überprüfen Sie vor jedem Schuss die Waffe auf mögliche Mängel oder Beschädigungen.
- Tragen Sie immer Augen und Gehörschutz, wenn Sie die Waffe abfeuern.
- Halten Sie den Finger vom Abzug, bis Sie bereit sind zu schießen.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Verwenden Sie die DUSK 19 Handfeuerwaffe nur für den vorgesehenen Zweck.
- Achten Sie darauf, dass der Lauf frei von Hindernissen ist, bevor Sie feuern.
- Vermeiden Sie es, die Waffe in feuchten oder extremen Umgebungen zu verwenden, um Korrosion oder Funktionsstörungen zu verhindern.
- Überprüfen Sie regelmäßig die Funktionstüchtigkeit der Waffe, insbesondere nach längeren Lagerzeiten.
- Verwenden Sie nur Zubehörteile und Aufsätze, die von Lone Wolf Arms empfohlen werden, um die Sicherheit und Leistung zu gewährleisten.
- Befolgen Sie die Anweisungen zur Verwendung des Schalldämpfers, falls vorhanden, und stellen Sie sicher, dass er korrekt montiert ist.

Anweisungen zur Installation und Nutzung

Installation

1. Montage des Schalldämpfers (falls zutreffend):

- Stellen Sie sicher, dass die Waffe entladen ist.
- Schrauben Sie den Schalldämpfer vorsichtig auf das Gewinde des Laufs.
- Überprüfen Sie, ob der Schalldämpfer sicher und fest sitzt.

2. Montage der Optik:

- Entfernen Sie die DUSKOptikabdeckung.
- Befestigen Sie die Optik gemäß den Anweisungen des Herstellers.
- Stellen Sie sicher, dass die Optik ordnungsgemäß ausgerichtet ist.

Nutzung

- Laden Sie die Waffe nur in einer sicheren Umgebung.
- Halten Sie die Waffe mit beiden Händen fest, um eine stabile Schussposition zu gewährleisten.
- Zielen Sie immer auf ein sicheres Ziel und seien Sie sich der Umgebung bewusst.
- Nach dem Schießen, überprüfen Sie die Waffe und entladen Sie sie, bevor Sie sie ablegen oder reinigen.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Wenn Sie die Waffe nicht mehr verwenden möchten, wenden Sie sich an einen autorisierten Händler oder eine Behörde, um die sichere Entsorgung zu gewährleisten.
- Halten Sie alle Teile der Waffe von Kindern und unbefugten Personen fern, bis sie sicher entsorgt sind.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zu Ihrer DUSK 19 Handfeuerwaffe wenden Sie sich bitte an den Händler, bei dem Sie das Produkt gekauft haben, oder an den Hersteller. Achten Sie darauf, alle Sicherheitsrichtlinien zu befolgen und die Waffe verantwortungsvoll zu nutzen.

Bitte beachten Sie, dass diese Sicherheitsanweisungen nicht alle möglichen Gefahren abdecken können. Es liegt in Ihrer Verantwortung, die Waffe sicher zu verwenden und sich über die besten Praktiken im Umgang mit Feuerwaffen zu informieren.

DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the DUSK 19 9MM Luger Threaded Barrel SemiAuto Handgun. This product is designed with safety and performance in mind. Please read this safety instruction guide carefully to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat the handgun as if it is loaded.
- Keep the handgun pointed in a safe direction at all times.
- Store the handgun unloaded and in a secure location.
- Ensure that the handgun is not accessible to children or unauthorized users.
- Regularly inspect the handgun for any signs of wear or damage.
- Use only the recommended ammunition type (9mm Luger).
- Always wear appropriate eye and ear protection when using the handgun.
- Be aware of your surroundings and ensure that you have a clear and safe shooting area.

Specific Safety Precautions for Use

- Ensure the handgun is unloaded before cleaning or performing maintenance.
- Do not place your finger on the trigger until you are ready to shoot.
- Avoid using the handgun under the influence of drugs or alcohol.
- Be cautious of the firearm's muzzle and ensure it is clear of any obstructions before firing.
- Do not modify the handgun in any way that could affect its safety or performance.
- Always follow local laws and regulations regarding handgun ownership and use.
- In case of a misfire or hangfire, wait at least 30 seconds before attempting to eject the cartridge.

Instructions for Installation and Usage

1. Loading the Handgun:

- Ensure the handgun is pointed in a safe direction.
- Insert the magazine into the magazine well until it clicks into place.
- Pull the slide back and release it to chamber a round.

2. Firing the Handgun:

- Ensure the handgun is aimed at the target.
- Place your finger on the trigger only when you are ready to fire.
- Squeeze the trigger smoothly to fire.

3. Unloading the Handgun:

- Point the handgun in a safe direction.
- Press the magazine release button to remove the magazine.
- Pull the slide back to eject any chambered round.
- Visually and physically inspect the chamber to ensure it is empty.

4. Cleaning and Maintenance:

- Unload the handgun before cleaning.
- Use a cleaning kit designed for firearms to clean the barrel and other components.
- Store the handgun in a secure and dry location after cleaning.

Disposal Instructions

- Dispose of any used ammunition casings and packaging in accordance with local regulations.
- Do not dispose of the handgun in regular household waste.
- Contact a licensed firearms dealer or local authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or issues regarding the DUSK 19 9MM Luger Handgun, please refer to the contact information provided with your product or consult your local firearms dealer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your DUSK 19 9MM Luger Threaded Barrel SemiAuto Handgun. Always prioritize safety and responsibility when handling firearms.

Istruzioni di Sicurezza per il DUSK 19 9MM LUGER THREADED BARREL SEMIAUTO HANDGUN

Introduzione

Grazie per aver scelto la pistola DUSK 19 9MM LUGER. Questo documento fornisce importanti linee guida di sicurezza per garantire un uso corretto e sicuro del prodotto. Si prega di leggere attentamente queste istruzioni prima dell'uso.

Linee Guida di Sicurezza Generali

- Assicurarsi che la pistola sia sempre trattata come se fosse carica.
- Tenere la pistola lontano dalla portata dei bambini e di persone non autorizzate.
- Utilizzare solo munizioni appropriate per il modello DUSK 19 9MM LUGER.
- Non puntare mai la pistola verso qualcosa che non si intende colpire.
- Indossare sempre occhiali e protezioni per l'udito durante l'uso.
- Non modificare mai la pistola o i suoi componenti senza l'assistenza di un professionista qualificato.
- Seguire sempre le leggi e i regolamenti locali riguardanti la detenzione e l'uso di armi da fuoco.

Precauzioni di Sicurezza Specifiche per l'Uso

- Assicurarsi che l'arma sia scarica prima di effettuare qualsiasi manutenzione o pulizia.
- Controllare regolarmente il funzionamento della pistola e dei suoi componenti, inclusi il grilletto e il sistema di sicurezza.
- Non utilizzare la pistola in condizioni meteorologiche avverse, come pioggia intensa o neve, che potrebbero comprometterne il funzionamento.
- Non utilizzare la pistola se si è sotto l'influenza di alcol o droghe.
- Evitare di utilizzare la pistola in luoghi affollati o non controllati.
- Assicurarsi che il mirino e la canna siano sempre puliti e privi di ostruzioni.

Istruzioni per l'Installazione e l'Uso

1. Controllo Iniziale:

- Assicurarsi che la pistola sia scarica.
- Controllare che non ci siano ostruzioni nella canna.

2. Montaggio del Mirino Reflex:

- Rimuovere la piastra di copertura ottica DUSK.
- Installare il mirino reflex compatibile seguendo le istruzioni del produttore.
- Riposizionare la piastra di copertura ottica se non si utilizza un mirino.

3. Caricamento del Caricatore:

- Utilizzare solo caricatori originali o compatibili.
- Caricare il caricatore con le munizioni appropriate, assicurandosi che siano inserite correttamente.

4. Sparare:

- Prendere una posizione stabile e controllata.
- Mantenere il dito lontano dal grilletto fino a quando non si è pronti a sparare.
- Puntare in sicurezza e premere il grilletto con una pressione costante.

5. Scarico della Pistola:

- Rimuovere il caricatore.
- Controllare che la camera sia vuota prima di riporre la pistola.

Istruzioni per lo Smaltimento

- Non gettare la pistola o i suoi componenti nel normale spazzatura.
- Contattare un professionista autorizzato per lo smaltimento sicuro dell'arma e delle munizioni.
- Seguire le normative locali riguardanti lo smaltimento delle armi da fuoco.

Informazioni di Contatto per Ulteriore Supporto

Per ulteriori informazioni o domande relative alla sicurezza, si prega di contattare il proprio rivenditore autorizzato o un professionista del settore.

Si prega di conservare questo documento per riferimento futuro. La sicurezza è la priorità numero uno quando si utilizza un'arma da fuoco.