

# **UXR ELITE RIFLE SYSTEM 300 AAC BLACKOUT SEMI-AUTO RIFLE - UXR ELITE RIFLE SYSTEM 300 BLACKOUT 14.5"BBL (1)30RD MAG BLK**

[Firearms](#) > [Rifles](#) > [Semi-Auto](#)

UXR THE NEW PROPRIETARY UXR, OR "USER XCHANGE RIFLE", IS THE PINNACLE OF FIREARM INNOVATION. THIS REVOLUTIONARY SYSTEM OFFERS UNMATCHED MODULARITY AND PERFORMANCE. FEATURES: XCHANGE Buttstock Module: Picatinny/1913/STANAG Rail mount interface, foldable with 6 position adjustable length of pull for 2.5" travel, ambidextrous LOP button and QD sling cups, 1" webbing sling slot mount, comfort-shoot rubber buttpad, and completed with a 2 position, height-adjustable cheek rest. Reversible Folding Stock Mount: Choose your preferred side for folding the XCHANGE Buttstock Module. XCHANGE Fire Control Housing Module: ergonomically designed UXR pistol grip also compatible with other AR15 style grips, ambidextrous QD sling cups, and oversized trigger guard. XCHANGE Fire Control Module: Housing compatible with most AR15 triggers. XCHANGE Magazine Well Module: Easily exchange modules for 5.56 NATO or 7.62 NATO magazines, complete with ambidextrous magazine release button and bolt stop/release 7075 Aluminum Receiver: Serialized upper receiver; universally compatible with multiple caliber configurations. XCHANGE Titanium Trunnion: Return-to-zero-barrel clamp for precision modularity. STANAG Top Rail: 18" usable length for optics and accessory mounts. XCHANGE Handguard: Toolless and replaceable MLOK handguard for length customization. Ambidextrous Folding Charging Handle: Snag-free and configurable for left or right handed users. XCHANGE Barrel Exchange System: Swap calibers and barrel lengths rapidly with standard tooling, while maintaining repeatability and accuracy. Ambidextrous Rocker Valve/Modified Long-Stroke Gas System: Select 3 gas settings effortlessly. XCHANGE Evacuation Chamber: Supports suppressed and high rate of fire by removing noxious gasses from the operator's face and keeping the operating system cleaner. Taper Muzzle Shoulder Lock: Perfect alignment and accessory lock for muzzle devices. Universal Recoil Spring: Adaptable to various calibers and configurations. Universal Bolt Carrier Group: Quick exchange bolt head assemblies for easy caliber conversions 14.5 inch models feature a pinned and welded muzzle device to bring the barrel overall length over 16 inches.



## **Attributes**

- Name: [UXR ELITE RIFLE SYSTEM 300 BLACKOUT 14.5"BBL \(1\)30RD MAG BLK](#)
- Manufacturer: [PRIMARY WEAPONS](#)
- Product no.: 430108088
- Mfr. No.: U2E14RB11-1F
- Action Type: Semi-Auto
- Barrel Length: 14.5"
- Capacity: 30+1-Round
- Cartridge: 300 AAC Blackout
- Finish: Black
- Front Sight: None
- Length: NA
- Magazine Included: 1 x 30-Round

- Magazine Type: Removable
- Make: Primary Weapons System
- Model: UXR Elite
- Muzzle: Compensator
- Rear Sight: None
- Stock Material: Synthetic
- Weight: NA
- Delivery weight: 4.536kg
- Shipping height: 102mm
- Shipping width: 305mm
- Shipping length: 940mm
- UPC: 811154031785

## **Item details**

Made in USA

US export classification: 0A506.a

# Table of Contents

- Startpage
- UXR Elite Rifle System Safety Instruction Guide
- About Us

# UXR Elite Rifle System Safety Instruction Guide

## Introduction

Thank you for choosing the UXR Elite Rifle System 300 AAC Blackout SemiAuto Rifle. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your firearm. Please read and understand this manual before using the product.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store firearms securely and out of reach of children and unauthorized users.
- Use appropriate hearing and eye protection when shooting.
- Regularly inspect the firearm for any signs of wear or damage.
- Do not use ammunition not specified for this firearm.
- Follow all local laws and regulations regarding firearm ownership and use.

## Specific Safety Precautions for Use

- Ensure that the rifle is unloaded before handling or cleaning.
- Use the XCHANGE Fire Control Module and other components as specified in the manual to avoid malfunctions.
- Be cautious when using the adjustable buttstock and cheek rest to prevent pinching or injury.
- When swapping barrels or calibers, ensure that all components are properly secured and compatible.
- When using the Ambidextrous Folding Charging Handle, ensure that it is fully engaged before firing.
- If the rifle fails to fire or malfunctions, follow the manufacturer's instructions for clearing the malfunction safely.
- Avoid using the rifle in adverse weather conditions unless it is specifically designed for such use.

## Instructions for Installation and Usage

### Installation

#### 1. Assemble the Rifle:

- Ensure the rifle is unloaded.
- Attach the XCHANGE Buttstock Module to the receiver by aligning the mounting points and securing it with the provided hardware.
- Install the XCHANGE Handguard by sliding it onto the barrel nut and securing it as per the instructions.
- Attach any optics or accessories to the STANAG Top Rail as needed.

#### 2. Load the Magazine:

- Insert the magazine into the magazine well until it clicks into place.
- Ensure the magazine release button operates correctly.

#### 3. Adjust the Buttstock:

- Adjust the length of pull by pressing the ambidextrous LOP button and sliding the buttstock to the desired position.

## Usage

### 1. Firing the Rifle:

- Ensure the rifle is pointed downrange.
- Load the firearm by pulling back the charging handle and releasing a round into the chamber.
- Keep your finger off the trigger until ready to fire.
- Aim at your target and squeeze the trigger smoothly.

### 2. PostFiring:

- After firing, keep the rifle pointed in a safe direction.
- Eject the magazine and clear the chamber before handling.
- Inspect the firearm for any signs of malfunction.

## Disposal Instructions

When disposing of the UXR Elite Rifle System, follow these guidelines:

- Ensure the firearm is unloaded before disposal.
- Check local laws and regulations regarding the disposal of firearms.
- If possible, return the firearm to a licensed dealer or manufacturer for safe disposal.
- Do not discard firearms in regular trash or recycling.

## Contact Information for Further Support

For any safety inquiries, product support, or assistance, please contact the manufacturer or your local authorized dealer. Ensure you have your product details and any relevant information ready for a more efficient response.

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your UXR Elite Rifle System. Always prioritize safety and responsible firearm handling.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)