

UXR ELITE RIFLE SYSTEM 8.6 BLACKOUT SEMI-AUTO RIFLE - UXR ELITE RIFLE SYSTEM 8.6 BLACKOUT 14.5"BBL (1)20RD MAG BLK

UXR THE NEW PROPRIETARY UXR, OR "USER XCHANGE RIFLE", IS THE PINNACLE OF FIREARM INNOVATION. THIS REVOLUTIONARY SYSTEM OFFERS UNMATCHED MODULARITY AND PERFORMANCE. FEATURES:

XCHANGE Buttstock Module: Picatinny/1913/STANAG Rail mount interface, foldable with 6 position adjustable length of pull for 2.5" travel, ambidextrous LOP button and QD sling cups, 1" webbing sling slot mount, comfort-shoot rubber buttpad, and completed with a 2 position, height-adjustable cheek rest.

Reversible Folding Stock Mount: Choose your preferred side for folding the XCHANGE Buttstock Module.

XCHANGE Fire Control Housing Module: ergonomically designed UXR pistol grip also compatible with other AR15 style grips, ambidextrous QD sling cups, and oversized trigger guard.

XCHANGE Fire Control Module: Housing compatible with most AR15 triggers.

XCHANGE Magazine Well Module: Easily exchange modules for 5.56 NATO or 7.62 NATO magazines, complete with ambidextrous magazine release button and bolt stop/release

7075 Aluminum Receiver: Serialized upper receiver; universally compatible with multiple caliber configurations.

XCHANGE Titanium Trunnion: Return-to-zero-barrel clamp for precision modularity.

STANAG Top Rail: 18" usable length for optics and accessory mounts.

XCHANGE Handguard: Toolless and replaceable MLOK handguard for length customization.

Ambidextrous Folding Charging Handle: Snag-free and configurable for left or right handed users.

XCHANGE Barrel Exchange System: Swap calibers and barrel lengths rapidly with standard tooling, while maintaining repeatability and accuracy.

Ambidextrous Rocker Valve/Modified Long-Stroke Gas System: Select 3 gas settings effortlessly.

XCHANGE Evacuation Chamber: Supports suppressed and high rate of fire by removing noxious gasses from the operator's face and keeping the operating system cleaner.

Taper Muzzle Shoulder Lock: Perfect alignment and accessory lock for muzzle devices.

Universal Recoil Spring: Adaptable to various calibers and configurations.

Universal Bolt Carrier Group: Quick exchange bolt head assemblies for easy caliber conversions



Attributes

- Name: UXR ELITE RIFLE SYSTEM 8.6 BLACKOUT 14.5"BBL (1)20RD MAG BLK
- Manufacturer: PRIMARY WEAPONS
- Product no.: 430108090
- Mfr. No.: U2E14RG11-1F
- Action Type: Semi-Auto
- Barrel Length: 14.5"
- Capacity: 20+1-Round
- Cartridge: 8.6 Blackout
- Finish: Black
- Front Sight: None
- Length: NA
- Magazine Included: 1 x 20-Round
- Magazine Type: Removable
- Make: Primary Weapons System
- Model: UXR Elite
- Muzzle: Compensator
- Rear Sight: None
- Stock Material: Synthetic
- Weight: NA
- Delivery weight: 4.536kg
- Shipping height: 102mm
- Shipping width: 305mm
- Shipping length: 940mm
- UPC: 811154031808

Item details

Made in USA

US export classification: 0A506.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das UXR Elite Rifle System 8.6 Blackout](#)
- [English: UXR Elite Rifle System Safety Instruction Guide](#)
- [Italiano: Guida alla Sicurezza per il Sistema di Fucile UXR Elite 8.6 Blackout](#)

Sicherheitshinweise für das UXR Elite Rifle System

8.6 Blackout

Einleitung

Herzlich willkommen! Vielen Dank, dass Sie sich für das UXR Elite Rifle System 8.6 Blackout entschieden haben. Dieses Produkt wurde unter höchsten Sicherheitsstandards entwickelt. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt in einwandfreiem Zustand ist, bevor Sie es verwenden.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und unbefugten Personen.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Informieren Sie sich über die örtlichen Gesetze und Vorschriften zum Besitz und zur Verwendung von Feuerwaffen.
- Melden Sie unsichere Produkte oder Vorfälle umgehend den zuständigen Behörden.
- Prüfen Sie regelmäßig auf RückrufUpdates auf der EU Safety GatePlattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Vermeiden Sie den Kontakt mit heißen Oberflächen, insbesondere während und nach dem Schießen.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Ohrenschutz und Schutzbrille.
- Achten Sie darauf, dass die Waffe stets in einem sicheren Zustand ist, wenn sie nicht verwendet wird.
- Halten Sie den Abzug nicht gedrückt, während Sie die Waffe laden oder entladen.
- Verwenden Sie nur die empfohlenen Munitionstypen für das UXR Elite Rifle System.
- Prüfen Sie vor jedem Gebrauch die Waffe auf Anzeichen von Beschädigungen oder Abnutzung.

Anweisungen für Installation und Nutzung

Installation

- Stellen Sie sicher, dass der Arbeitsbereich sauber und frei von Ablenkungen ist.
- Befestigen Sie das XCHANGE Schulterstützenmodul gemäß der Bedienungsanleitung.
- Montieren Sie das XCHANGE Handguard und stellen Sie sicher, dass alle Schrauben fest angezogen sind.
- Überprüfen Sie die korrekte Montage des XCHANGE Feuerkontrollmodul und der anderen Module.

Nutzung

- Laden Sie die Waffe nur in einem sicheren Bereich, der für das Schießen vorgesehen ist.
- Stellen Sie sicher, dass das Magazin ordnungsgemäß eingesetzt ist und die Waffe sicher ist, bevor Sie sie abfeuern.
- Wählen Sie die gewünschte Gaseinstellung des Modifizierten LanghubGassystems vor dem Schießen.
- Nach dem Schießen entladen Sie die Waffe vollständig und reinigen Sie sie gemäß den Anweisungen.

Entsorgungsanweisungen

- Entsorgen Sie alle Verpackungsmaterialien gemäß den örtlichen Vorschriften für Abfallentsorgung.
- Entsorgen Sie das Produkt nicht im normalen Hausmüll. Erkundigen Sie sich nach speziellen Entsorgungsmöglichkeiten für Waffen und Munition in Ihrer Region.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie bei Fragen oder Unsicherheiten Hilfe in Anspruch nehmen.

Vielen Dank, dass Sie sich die Zeit genommen haben, diese Sicherheitshinweise zu lesen. Ihre Sicherheit hat oberste Priorität.

UXR Elite Rifle System Safety Instruction Guide

Introduction

Thank you for choosing the UXR Elite Rifle System 8.6 Blackout SemiAuto Rifle. This guide provides essential safety information and instructions to ensure the safe use and maintenance of your firearm. Please read this guide carefully before using the product.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Store the firearm securely, out of reach of children and unauthorized users.
- Always be aware of your target and what lies beyond it.
- Use appropriate eye and ear protection when handling or firing the firearm.
- Do not consume alcohol or drugs before or while using the firearm.
- Ensure that the firearm is clean and properly maintained before each use.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure that you are familiar with the operation of the UXR Elite Rifle System before use.
- Use only the recommended ammunition (8.6 Blackout) for this firearm.
- Do not modify the firearm in any way that may affect its safety or performance.
- Be aware of the firearm's features, including the XCHANGE Fire Control Module and the Ambidextrous Rocker Valve, and understand how they operate.
- When using the XCHANGE Barrel Exchange System, ensure the firearm is unloaded and pointed in a safe direction.
- Always engage the safety mechanism when the firearm is not in use.
- If a malfunction occurs, follow proper clearing procedures before attempting to fire again.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure the firearm is unloaded before installing any accessories.
- Attach accessories to the Picatinny/1913/STANAG rail mount interface as per the manufacturer's instructions.
- Adjust the XCHANGE Buttstock Module to your desired length of pull before use.

2. Loading the Firearm:

- Ensure the firearm is pointed in a safe direction.
- Insert the 20round magazine into the magazine well until it clicks into place.
- Pull the charging handle to the rear and release it to chamber a round.

3. Firing the Firearm:

- Ensure you have a proper stance and grip on the firearm.
- Aim at your target and ensure it is safe to fire.
- Disengage the safety mechanism and squeeze the trigger smoothly.

4. Unloading the Firearm:

- Point the firearm in a safe direction.
- Engage the safety mechanism.
- Remove the magazine and pull the charging handle to eject any chambered round.

5. Maintenance:

- Regularly clean the firearm according to the manufacturer's guidelines.
- Inspect all components for wear or damage before use.

Disposal Instructions

- Dispose of the firearm and any ammunition in accordance with local laws and regulations.
- Do not dispose of the firearm in regular waste. Contact a licensed firearms dealer for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the UXR Elite Rifle System, please refer to the manufacturer's support resources or contact your local firearms dealer.

Please ensure that you follow these safety guidelines and instructions to promote a safe and enjoyable experience with your UXR Elite Rifle System. Remember, safety is the responsibility of every firearm owner.

Guida alla Sicurezza per il Sistema di Fucile UXR Elite

8.6 Blackout

Introduzione

Grazie per aver scelto il Sistema di Fucile UXR Elite 8.6 Blackout. Questo prodotto è progettato per offrire prestazioni eccezionali e modularità. Tuttavia, è fondamentale seguire le linee guida di sicurezza per garantire un utilizzo sicuro e responsabile. Questa guida è conforme alla Regolamentazione Generale sulla Sicurezza dei Prodotti dell'UE (GPSR) e fornisce informazioni essenziali per l'uso corretto e sicuro del prodotto.

Linee Guida Generali sulla Sicurezza

- Assicurati di leggere e comprendere tutte le istruzioni prima dell'uso.
- Conserva questa guida in un luogo accessibile per future consultazioni.
- Non utilizzare il prodotto in condizioni di scarsa visibilità o in ambienti pericolosi.
- Verifica regolarmente il prodotto per eventuali segni di usura o danni.
- Non utilizzare il prodotto se presenta difetti visibili o se non funziona correttamente.
- Tieni il prodotto lontano dalla portata di bambini e persone non autorizzate.
- Segnala immediatamente eventuali incidenti o malfunzionamenti alle autorità competenti.

Precauzioni di Sicurezza Specifiche per l'Uso

- Indossa sempre occhiali protettivi e protezioni per le orecchie durante l'uso.
- Assicurati che l'arma sia scarica prima di eseguire qualsiasi manutenzione o modifica.
- Non puntare mai l'arma verso persone o animali.
- Utilizza solo munizioni compatibili con il calibro specificato (8.6 Blackout).
- Segui sempre le leggi locali e nazionali riguardanti l'uso e il possesso di armi.
- Non modificare il prodotto senza consultare un professionista qualificato.
- Durante il trasporto, assicurati che l'arma sia in una custodia sicura e che sia scarica.

Istruzioni per l'Installazione e l'Uso

1. Assemblaggio del Fucile:

- Controlla che tutte le parti siano presenti e in buone condizioni.
- Segui le istruzioni del produttore per l'assemblaggio del fucile, assicurandoti che ogni componente sia montato correttamente.

2. Controllo della Sicurezza:

- Prima di utilizzare il fucile, verifica il funzionamento del sistema di sicurezza.
- Esegui un controllo visivo per assicurarti che non ci siano ostruzioni nel canna.

3. Caricamento del Fucile:

- Utilizza solo caricatori raccomandati (1 x 20Round).
- Inserisci il caricatore nel fucile seguendo le istruzioni del produttore.

4. Mira e Sparo:

- Scegli un'area di tiro sicura e autorizzata.
- Imposta il fucile in modo che sia stabile e mira con attenzione al bersaglio.
- Attiva il grilletto solo quando sei pronto a sparare.

5. Manutenzione:

- Pulisci il fucile regolarmente per garantire prestazioni ottimali.
- Segui le istruzioni di manutenzione fornite dal produttore.

Istruzioni per lo Smaltimento

- Segui le normative locali per lo smaltimento delle armi e dei componenti.
- Non abbandonare il prodotto in luoghi pubblici o in natura.
- Consulta un professionista per il corretto smaltimento di componenti pericolosi o non funzionanti.

Informazioni di Contatto per Ulteriori Supporto

Per ulteriori informazioni sulla sicurezza del prodotto, consultare il sito web ufficiale del produttore o contattare il servizio clienti. Assicurati di avere il numero di serie del prodotto a portata di mano per un'assistenza più rapida.

Conclusione

Seguendo queste linee guida di sicurezza, puoi garantire un'esperienza di utilizzo sicura e responsabile del Sistema di Fucile UXR Elite 8.6 Blackout. Ricorda di rimanere sempre informato sulle normative locali riguardanti l'uso delle armi e di segnalare eventuali problemi o incidenti alle autorità competenti. La sicurezza è la priorità numero uno.