

RETRO 4X/COLT 4X SCOPE SPARE PARTS - BROWNELLS RETRO 4X/COLT 4X WINDAGE CAP

Spare Parts for the Brownells Retro 4x Scope, as well as the Colt Retro 4x Scope. Available items include: Mount Screw Windage Cap Elevation Cap Carry Handle Clamp All components are original Retro 4x Scope Manufacturer supplied parts, so you can be confident in the fit & finish.



Attributes

- Name: BROWNELLS RETRO 4X/COLT 4X WINDAGE CAP
- Manufacturer: BROWNELLS
- Product no.: 430108971
- Mfr. No.: NONE
- Color: -
- Delivery weight: 0.045kg
- UPC: 050806024434

Item details

Made in USA

Table of Contents

- [Startpage](#)
- English: BROWNELLS RETRO 4X/COLT 4X SCOPE SPARE PARTS SAFETY INSTRUCTIONS

BROWNELLS RETRO 4X/COLT 4X SCOPE SPARE PARTS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Brownells Retro 4x Scope Spare Parts. This guide provides essential safety information and instructions to ensure safe and effective use of the product. Please read this manual carefully before using the spare parts to ensure a safe experience.

General Safety Guidelines

- Ensure that all components are used in accordance with the manufacturer's specifications.
- Regularly inspect parts for wear or damage before use.
- Keep spare parts out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Mount Screw:** Ensure that the mount screw is tightened properly to prevent the scope from becoming loose during use.
- **Windage Cap:** Avoid overtightening the windage cap, as this may damage the internal components of the scope.
- **Elevation Cap:** Handle the elevation cap with care to prevent misalignment of the scope.
- **Carry Handle Clamp:** Ensure that the carry handle clamp is securely attached to avoid accidental detachment during transport or use.

Instructions for Installation and Usage

1. Mounting the Scope:

- Select an appropriate mounting location on your firearm.
- Align the mount screw with the designated hole on the scope.
- Tighten the mount screw gently but securely.

2. Adjusting Windage and Elevation:

- Remove the windage cap and elevation cap before making adjustments.
- Use a suitable tool to adjust the windage and elevation settings as necessary.
- Replace the windage and elevation caps after adjustments are made to protect the internal mechanisms.

3. Using the Carry Handle Clamp:

- Attach the carry handle clamp to the designated area on your firearm.
- Ensure that the clamp is tightened securely to prevent movement during use.

4. Regular Maintenance:

- Clean the components regularly with a soft, dry cloth.
- Avoid using any harsh chemicals that may damage the finish of the parts.

Disposal Instructions

- Dispose of any damaged or worn parts in accordance with local regulations.
- Do not dispose of parts in regular household waste if they contain hazardous materials.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any inquiries regarding safety concerns or product information, please refer to the manufacturer's website or customer service resources.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.