

FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMI-AUTO RIFLE - FREEDOM RIFLE RECCE 6MM ARC 16"BBL (1)8RD MAG BLACK

GFR 6MM ARC Recce Rifle The Geissele Freedom Rifle (GFR) 16" Recce features the latest weapon technology, available exclusively from Geissele Automatics. Designed and Engineered from the ground up, the GFR is the next evolution of the AR15 platform. The 6MM ARC GFR Recce barrels are Chrome-lined, precision machined, and cold hammer forged using the highest quality materials to ensure consistency and quality. These barrels undergo High-Pressure Testing (HPT) and Magnetic Particle Inspection (MPI) to ensure accuracy and reliability. Geissele CHF barrels are an excellent choice for duty weapons, competition guns, and everything in between. Geissele's Anti-Strike Super Compact Gas Block is a modified gas block and was developed for the USG to give more clearance between the gas block and rail. This allows the rail to deflect further in a drop without striking the gas block, which increases the life span of the rail overall. The GFR platform of rifles features the exclusive GFR-E trigger. This trigger is an enhancement of the SSAE trigger with a standard M4 curve. Engineered with precision in mind, the GFR-E provides the smooth first stage and predictably crisp break shooters have come to expect from a Geissele two-stage trigger. Even with minimal lubrication, the proprietary Nanoweapon Coating enhances corrosion resistance, keeps the fire control group running smoothly, and breaks cleanly — even after heavy use. At the heart of the GFR platform is the Nanoweapon Coated 6MM ARC Reliability Enhanced Bolt Carrier Group (REBCG) with features that provide increased corrosion and wear resistance, increased carrier stability, and optimized cartridge-feeding performance. The 6MM ARC REBCG has a chrome lined gas key with properly torqued and staked screws, advanced tool steel cam pin, extended carrier rails, and a purpose-built 6MM ARC GFR Stressproof Bolt. The bolt is forged — not machined from bar stock — to optimize the grain structure of the specially developed Carpenter 158+ steel. This is conducive to cleaner material that is also more resistant to fatigue. Each bolt is not only the subject of thorough quality inspection at each stage but is also high-pressure tested (HPT) and magnetic-particle inspected (MPI). These resilient bolts are designed to significantly increase the service life of the 6MM ARC semi-auto platform bolt, allowing it to reach the full potential of the cartridge. Even the upper receiver itself has been improved upon. The GFR uppers have properly heat-treated steel cam races riveted into place intended to provide steel-on-steel contact with the cam pin while the system is cycling. This prolongs the upper's lifespan while maintaining tolerances. The forward assist has also been relocated further forward which allows for more working space to operate the charging handle while a magnified optic is installed up top on the 1913 Picatinny rail. Each GFR comes equipped with the ambidextrous Geissele Super Charging Handle to assure the user has proper purchase of the dual-contoured levers when charging the weapon. The GFR Recce features the addition of a HUXWRX Flash Hider-QD 6MM ARC suppressor-ready muzzle device. The Nanoweapon-coated HUXWRX Flash Hider-QD muzzle device is compatible with the HUXWRX FLOW 6 k suppressor, FLOW 762 Ti suppressor, or Blastphemy blast deflector (available separately). The renowned MK16 Super Modular Rail with center alignment tab comes standard on the GFR and mates with a notch in the upper receiver, just the same as the Super Duty lineup. This removes any chance of handguard rotation during use and ensures confidence in anything mounted to the 1913 Picatinny top or the radial M-LOK sections. Similar to the Super Duty line, the GFR lower receivers are precision machined from forged 7075-T6 aluminum and use all of the familiar high-quality Geissele lower parts such as the Maritime Bolt Catch, checkered takedown pins, and stainless magazine catch. Every GFR has a non-adjustable spring-loaded tensioning plunger installed to provide a tight fit with the upper receiver, which mitigates wobble when the upper and lower are mated together. The magazine well has also been improved with a more aggressive flare that has been optimized for use with Geissele's dedicated 6MM ARC magazines. Every GFR also comes with a Super 42 Buffer system installed, which provides silky-smooth shooting right out of the box, and a new reduced-angle Geissele Grip to provide users with a more modern primary point



of contact. The Geissele BF stock features four QD sling swivel sockets. It encompasses a shrouded adjustment trigger preventing any snagging or unintentional repositioning and offers a comfortable cheek weld for optimized eye relief. SPECIFICATIONS: LENGTH COLLAPSED: 34 3/8" LENGTH EXTENDED: 37 5/8" WEIGHT: 7 lbs 1 oz CALIBER: 6MM ARC COLOR: Luna Black or DDC LOWER RECEIVER: GFR Lower Receiver UPPER RECEIVER: GFR Upper Receiver W/ Enhanced Cam Race BCG: GFR Bolt Carrier Group w/ 6MM ARC Bolt RAIL: 15" MK16 Center Tab (Luna Black) TRIGGER: GFR-E Standard M4 Bow BARREL: 16.25" 6MM ARC, Cold Hammer Forged Chamberless GAS SYSTEM: Rifle Length GAS BLOCK: Antistrike super Compact Gas Block CHARGING HANDLE: Geissele Super Charging Handle MUZZLE: HUX WRX Flash Hider QD-6 SAFTEY: Super Configurable Safety Selector BUFFER TUBE: Premium Mil-Spec 6 position Buffer Tube BUFFER ASSEMBLY: Super-42 w/ H2 Buffer STOCK: Geissele BF Buttstock GRIP: Geissele A17 Reduced Angle Grip

Attributes

- Name: FREEDOM RIFLE RECCE 6MM ARC 16"BBL (1)8RD MAG BLACK
- Manufacturer: GEISSELE AUTOMATICS LLC
- Product no.: 430110168
- Mfr. No.: 05-1521B
- Action Type: Semi-Auto
- Barrel Length: 16"
- Capacity: 8+1-Round
- Cartridge: 6 mm ARC
- Finish: Luna Black
- Front Sight: None
- Length: 34.375"
- Magazine Included: 1 x 8-Round
- Magazine Type: Removable
- Make: Geissele
- Model: Freedom Rifle Recce
- Muzzle: Flash Hider
- Rear Sight: None
- Stock Material: Polymer
- Weight: 7.063 lbs
- Delivery weight: 4.763kg
- Shipping height: 102mm
- Shipping width: 292mm
- Shipping length: 1,105mm
- UPC: 810081134248

Item details

Made in USA

US export classification: 0A506.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das FREEDOM RIFLE \(GFR\) RECCE 6MM ARC SEMIAUTO RIFLE](#)
- [English: Safety Instruction Guide for the FREEDOM RIFLE \(GFR\) RECCE 6MM ARC SEMIAUTO RIFLE](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per il Fucile FREEDOM RIFLE \(GFR\) RECCE 6MM ARC](#)

Sicherheitshinweise für das FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE

Einführung

Herzlichen Glückwunsch zum Kauf Ihres FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE. Dieses Produkt wurde mit modernster Waffentechnologie entwickelt, um Ihnen ein sicheres und präzises Schießerlebnis zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und verantwortungsvoll verwenden.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das GFR nur in Übereinstimmung mit den geltenden Gesetzen und Vorschriften.
- Halten Sie das Gewehr immer in einem sicheren Zustand, wenn es nicht in Gebrauch ist.
- Stellen Sie sicher, dass die Waffe nicht geladen ist, bevor Sie sie reinigen oder transportieren.
- Bewahren Sie die Waffe und Munition an einem sicheren Ort auf, der für Kinder unzugänglich ist.
- Tragen Sie beim Schießen immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Informieren Sie sich über die Sicherheitsvorschriften und -praktiken für den Umgang mit Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Überprüfen Sie vor jedem Gebrauch, ob das Gewehr in gutem Zustand ist und keine sichtbaren Schäden aufweist.
- Verwenden Sie nur die vom Hersteller empfohlenen 6MM ARCMunition.
- Achten Sie beim Laden des Gewehrs darauf, dass sich niemand im Schussbereich befindet.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind zu schießen.
- Vermeiden Sie es, das Gewehr auf Menschen oder Tiere zu richten, auch wenn Sie glauben, dass es nicht geladen ist.
- Nutzen Sie das Gewehr nur auf zugelassenen Schießständen oder in geeigneten Bereichen.

Anweisungen für Installation und Nutzung

1. Installation des Gewehrs:

- Entfernen Sie das Gewehr vorsichtig aus der Verpackung.
- Überprüfen Sie, ob alle Teile vorhanden sind, einschließlich des Gewehrs, des Magazins und der Bedienungsanleitung.
- Installieren Sie das Gewehr gemäß den Anweisungen des Herstellers.

2. Laden des Gewehrs:

- Stellen Sie sicher, dass der Sicherheitshebel in der "Sicherheit"Position ist.
- Führen Sie das Magazin in den Magazinbereich ein, bis es einrastet.
- Ziehen Sie den Ladehebel zurück, um eine Patrone in die Kammer zu laden.

3. Schießen:

- Nehmen Sie eine stabile Schießposition ein.
- Stellen Sie sicher, dass der Schießbereich frei von Hindernissen ist.
- Betätigen Sie den Abzug sanft, um den Schuss abzugeben.

4. Reinigung und Wartung:

- Reinigen Sie das Gewehr regelmäßig, um optimale Leistung sicherzustellen.
- Verwenden Sie geeignete Reinigungsmittel und Werkzeuge, um Beschädigungen zu vermeiden.
- Überprüfen Sie nach der Reinigung, ob das Gewehr ordnungsgemäß funktioniert, bevor Sie es wieder verwenden.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Wenn das Gewehr nicht mehr verwendet wird, bringen Sie es zu einem autorisierten Händler oder einer Fachwerkstatt zur Entsorgung.
- Stellen Sie sicher, dass das Gewehr vor der Entsorgung entladen und sicher aufbewahrt wird.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie bei Fragen oder Bedenken bezüglich der Sicherheit des Produkts nicht zögern, Hilfe zu suchen.

Schlussfolgerung

Das FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE ist ein hochwertiges Produkt, das Ihnen viele Jahre Freude bereiten kann, wenn es sicher und verantwortungsbewusst verwendet wird. Befolgen Sie diese Sicherheitshinweise, um ein sicheres Schießerlebnis zu gewährleisten.

Safety Instruction Guide for the FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE

Introduction

Thank you for choosing the FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE. This guide provides essential safety instructions and information to ensure the safe use, maintenance, and disposal of your rifle. It is crucial to read and understand these guidelines to minimize risks and ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Use the rifle only for its intended purpose and in accordance with local laws and regulations.
- Regularly inspect the rifle for any signs of wear or damage before use.
- Always wear appropriate eye and ear protection when operating the rifle.
- Be aware of your surroundings and ensure a safe shooting environment.
- Do not use the rifle if you are under the influence of drugs or alcohol.
- Follow all manufacturer instructions and guidelines when using and maintaining the rifle.

Specific Safety Precautions for Use

- Ensure the safety selector is in the "Safe" position until you are ready to fire.
- Only load ammunition that is specified for the 6MM ARC caliber.
- Keep your finger off the trigger until you are ready to shoot.
- Never point the rifle at anything you do not intend to shoot.
- Be cautious of potential ricochets and ensure a proper backstop is in place.
- If a misfire occurs, keep the rifle pointed downrange for at least 30 seconds before attempting to clear the malfunction.
- Do not modify or alter the rifle in any way that may compromise its safety or performance.

Instructions for Installation and Usage

1. Unboxing and Inspection

- Carefully remove the rifle from its packaging.
- Inspect all components for damage or defects.
- Ensure that all accessories, such as the magazine and charging handle, are included.

2. Loading the Rifle

- Ensure the rifle is in the "Safe" position.
- Insert the magazine into the magazine well until it clicks into place.
- Pull the charging handle to the rear and release it to chamber a round.

3. Firing the Rifle

- Position yourself in a stable shooting stance.
- Aim at your target and ensure your line of sight is clear.
- Place your finger on the trigger only when ready to fire.
- Squeeze the trigger gently to fire the rifle.

4. Clearing Malfunctions

- In case of a jam or misfire, keep the rifle pointed downrange.
- Wait 30 seconds before attempting to clear the malfunction.
- Follow the manufacturer's instructions for clearing common issues.

5. Cleaning and Maintenance

- Regularly clean the rifle according to the manufacturer's guidelines.
- Use appropriate cleaning solvents and tools to maintain performance.
- Inspect all parts for wear and replace any damaged components.

Disposal Instructions

- Dispose of any used ammunition and firearm parts in accordance with local laws and regulations.
- Do not discard the rifle in regular household waste.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE, please refer to the manufacturer's website or contact customer support for assistance.

Conclusion

By following these safety instructions, you will help ensure a safe and enjoyable experience with your FREEDOM RIFLE (GFR) RECCE 6MM ARC SEMIAUTO RIFLE. Always prioritize safety and adhere to all guidelines and regulations. Thank you for your commitment to responsible firearm ownership.

Guida alle Istruzioni di Sicurezza per il Fucile FREEDOM RIFLE (GFR) RECCE 6MM ARC

Introduzione

Grazie per aver scelto il Fucile FREEDOM RIFLE (GFR) RECCE 6MM ARC. Questo prodotto è progettato per garantire prestazioni elevate e sicurezza durante l'uso. È fondamentale seguire tutte le istruzioni di sicurezza e le linee guida fornite in questo documento per garantire un utilizzo corretto e sicuro del fucile.

Linee Guida Generali di Sicurezza

- Assicurarsi di leggere attentamente tutte le istruzioni prima di utilizzare il fucile.
- Tenere il fucile in un luogo sicuro e fuori dalla portata di bambini e persone non autorizzate.
- Non puntare mai il fucile verso persone o animali.
- Assicurarsi che l'arma sia sempre considerata carica, anche se si pensa che sia scarica.
- Utilizzare solo munizioni appropriate per il Fucile GFR 6MM ARC.
- Indossare sempre occhiali di protezione e protezioni per le orecchie durante l'uso del fucile.
- Non utilizzare il fucile sotto l'effetto di alcol o sostanze stupefacenti.
- Seguire tutte le leggi e i regolamenti locali riguardanti l'uso e la registrazione delle armi da fuoco.

Precauzioni di Sicurezza Specifiche per l'Uso

- Verificare sempre che l'arma sia scarica prima di effettuare qualsiasi manutenzione o pulizia.
- Non modificare il fucile in alcun modo. Qualsiasi modifica non autorizzata può compromettere la sicurezza e le prestazioni dell'arma.
- Utilizzare accessori e ricambi originali Geissele Automatics per garantire la compatibilità e la sicurezza.
- Non utilizzare il fucile in condizioni meteorologiche estreme senza adeguate misure di protezione.
- Assicurarsi che il dispositivo di bocca HUXWRX Flash HiderQD sia correttamente installato prima dell'uso.
- Non lasciare mai il fucile incustodito durante l'uso o la pulizia.

Istruzioni per l'Installazione e l'Uso

Installazione

1. Controllo del Contenuto della Confezione

- Verificare che tutti i componenti siano presenti: Fucile GFR, maniglia di carica Geissele Super, dispositivo di bocca HUXWRX, e manuale d'uso.

2. Montaggio del Dispositivo di Bocca

- Assicurarsi che il dispositivo di bocca HUXWRX Flash HiderQD sia installato correttamente sul fucile prima dell'uso.

3. Controllo del Sistema Gas

- Verificare che il blocco gas sia correttamente posizionato e che non ci siano ostruzioni.

Uso

1. Caricamento

- Inserire il caricatore da 8 colpi nel pozzetto del caricatore, assicurandosi che sia ben fissato.
- Tirare indietro la maniglia di carica e rilasciarla per caricare un colpo nella camera.

2. Sparo

- Puntare in sicurezza verso il bersaglio.
- Attivare il selettore di sicurezza in posizione "FIRE" prima di sparare.
- Premere il grilletto con un movimento controllato.

3. Scarico

- Dopo l'uso, rimuovere il caricatore e controllare visivamente che non ci siano colpi nella camera.
- Posizionare il selettore di sicurezza in posizione "SAFE".

Istruzioni per lo Smaltimento

- Seguire le leggi locali per lo smaltimento delle armi da fuoco e delle munizioni.
- Non smaltire mai munizioni nel normale rifiuto domestico.
- Contattare un'autorità locale competente per la corretta gestione e smaltimento delle armi non più utilizzabili.

Contatti per Ulteriori Supporto

Per domande o preoccupazioni relative alla sicurezza del Fucile FREEDOM RIFLE (GFR) RECCE 6MM ARC, si prega di contattare il servizio clienti di Geissele Automatics. Assicurarsi di avere a disposizione il numero di serie del prodotto e le informazioni sull'acquisto.

Nota: Questo documento è stato redatto per rispettare il Regolamento Generale sulla Sicurezza dei Prodotti dell'UE (GPSR) e garantire la sicurezza dei consumatori. Si prega di segnalare eventuali prodotti non sicuri o incidenti alle autorità competenti. Controllare regolarmente gli aggiornamenti sui richiami attraverso la piattaforma Safety Gate dell'UE.