

SLIDE CATCH LEVERS FOR SIG SAUER® P320 - TYRANT CNC SLIDE CATCH LEVER FOR SIG SAUER P320 GOLD

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

SLIDE CATCH LEVER FOR SIG SAUER® P320 Introducing the first-ever Sig Sauer Extended Slide catch lever to be a two-piece unit made from steel! Made from 304 grade steel Sig Sauer's drop-in replacement Sig Sauer slide stop is the perfect upgrade for your pistol. The Sig Sauer P320 extended slide release adds surface area and a raised texture that greatly improves usability for all! It is the perfect upgrade for concealed carry AND competition. Never again will your thumb slip while manipulating your Sig Sauer slide catch lever! What is it? This drop-in replacement Sig Sauer extended slide stop release lever has a surface area extended over the OEM size. Why use it? One of the main flaws of the Sig Sauer Factory release lever is that it offers very little surface area and/or texture. This results in the operator occasionally slipping when attempting to manipulate the lever. The Sig Sauer P320 slide release offers an extended AND raised surface area to ensure easy manipulation of the Sig Sauer slide. It is easy to install, functions great, and looks fantastic! Features All steel construction Extended controls PVD Coated for corrosion resistance Tyrant CNC Proprietary stamped 'bridge' for rigidity (actually works as an ambidextrous release unlike others) Does not come with spring Works on 9/40/357 models Works on Flux Defense 'Flux Raider' Chassis systems



Attributes

- Name: [TYRANT CNC SLIDE CATCH LEVER FOR SIG SAUER P320 GOLD](#)
- Manufacturer: [TYRANT CNC](#)
- Product no.: 430112620
- Mfr. No.: TD-320SCL-GOLD
- Caliber: 9 mm Luger
- Finish: Gold
- Model: P320
- Weapon type: Sig Sauer
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 6mm
- Shipping length: 114mm
- UPC: 612789318919

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for SLIDE CATCH LEVERS FOR SIG SAUER® P320
- About Us

Safety Instruction Guide for SLIDE CATCH LEVERS FOR SIG SAUER® P320

Introduction

Thank you for purchasing the SLIDE CATCH LEVER FOR SIG SAUER® P320 by TYRANT CNC. This product is designed to enhance the functionality of your firearm while ensuring safety during use. Please read this safety instruction guide carefully to ensure proper installation, usage, and maintenance of the slide catch lever.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Ensure that the firearm is pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Store the firearm and accessories in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your firearm and accessories for any signs of wear or damage.
- If you notice any irregularities or issues, do not use the firearm until it has been inspected by a qualified gunsmith.
- Always follow local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure that the slide catch lever is compatible with your specific model of the Sig Sauer P320 before installation.
- Avoid using the slide catch lever if it appears damaged or defective.
- Do not attempt to modify or alter the slide catch lever in any way.
- Use the lever only for its intended purpose; do not use it for any other function.
- When manipulating the slide catch lever, ensure that your hands are dry and free from oils or lubricants to prevent slipping.
- Always wear appropriate eye and ear protection when handling firearms.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure the firearm is unloaded. Remove the magazine and visually inspect the chamber.
2. **Remove the OEM Slide Catch Lever:** Using a suitable tool, carefully remove the existing slide catch lever from your Sig Sauer P320.
3. **Install the New Slide Catch Lever:**
 - Align the new SLIDE CATCH LEVER with the mounting point on the firearm.
 - Press it into place until it is securely fitted.
 - Ensure that the lever moves freely and does not obstruct any other components.
4. **Check Functionality:** After installation, perform a function check to ensure that the lever operates correctly without any hindrance.

Usage

- To engage the slide catch lever, use your thumb to press down on the lever while the slide is in the rear position.
- To release the slide, pull back on the slide and allow it to move forward, ensuring that the lever is fully disengaged.
- Practice using the slide catch lever in a safe environment until you are comfortable with its operation.

Disposal Instructions

- Dispose of any packaging materials in accordance with local waste disposal regulations.
- If the slide catch lever needs to be replaced or disposed of, ensure that it is done so in a manner that prevents unauthorized access or use.
- Do not throw away the product in regular household waste. Check for recycling options specific to metal components.

Contact Information for Further Support

For any safety inquiries or support related to the SLIDE CATCH LEVER FOR SIG SAUER® P320, please refer to the manufacturer's contact information provided with your product packaging.

By following these safety instructions, you can ensure the safe and effective use of your SLIDE CATCH LEVER FOR SIG SAUER® P320. Always prioritize safety and responsible handling of firearms. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk