

SLIDE COVER PLATE FOR GLOCK® 43X/48 - SLIDE COVER PLATE FOR GLOCK 43X/48 BLACK

The Tyrant Designs Glock 43x & Glock 48 compatible slide cover plate is a 3D CNC machined back plate with a chevron design and chamfered edges. Meant for the Glock 43x & Glock 48 and made from aerospace grade aluminum, this anodized back plate adds a subtle but sophisticated appearance to your Glock. Mix and match it with their other Glock components, or let it stand alone as the final touch to your Glock 43x or Glock 48. Platform: Glock Designed For Models: G43X, G48 Glock Generation: Crossover FEATURES Chevron Pattern texture Perfect profile match Smooth chamfered edges NO TOOLS NECESSARY

NO IMAGE
AVAILABLE

Attributes

- Name: SLIDE COVER PLATE FOR GLOCK 43X/48 BLACK
- Manufacturer: TYRANT CNC
- Product no.: 430112942
- Mfr. No.: TD-G43X-48SP-BLACK
- Make: Glock
- Model: 43X,48
- Delivery weight: 0.009kg
- Shipping height: 102mm
- Shipping width: 6mm
- Shipping length: 114mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for SLIDE COVER PLATE FOR GLOCK® 43X/48](#)

Safety Instruction Guide for SLIDE COVER PLATE FOR GLOCK® 43X/48

Introduction

Thank you for choosing the SLIDE COVER PLATE FOR GLOCK® 43X/48. This product is designed to enhance the appearance of your Glock while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use and maintain your product safely.

General Safety Guidelines

- Always ensure that your firearm is unloaded before installing or handling the slide cover plate.
- Inspect the slide cover plate for any damage before use. Do not use if damaged.
- Keep the product out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding firearm modifications.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the slide cover plate is compatible with Glock models G43X and G48.
- Avoid using excessive force during installation to prevent damage to the slide cover plate or the firearm.
- Do not modify the slide cover plate in any way, as this may compromise safety.
- Regularly inspect the slide cover plate for signs of wear or loosening, and replace if necessary.
- Do not expose the slide cover plate to extreme temperatures or harsh chemicals, as this may affect its performance.

Instructions for Installation and Usage

1. Preparation:

- Ensure your Glock 43X or Glock 48 is unloaded and pointed in a safe direction.
- Gather necessary tools if required (none are typically needed for installation).

2. Installation:

- Align the slide cover plate with the back of the slide on your Glock.
- Gently press the slide cover plate into place until it clicks securely.
- Check that the slide cover plate is firmly attached and does not move.

3. Usage:

- Once installed, the slide cover plate can remain on your Glock during use.
- Regularly check the fit of the slide cover plate to ensure it remains secure.

4. PostInstallation:

- Store your firearm in a safe and secure location, away from children and unauthorized users.
- Keep the slide cover plate clean and free from debris to maintain its appearance and functionality.

Disposal Instructions

- Dispose of any damaged or worn slide cover plates in accordance with local waste disposal regulations.
- If the product is no longer needed, consider recycling materials where possible.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the SLIDE COVER PLATE FOR GLOCK® 43X/48, please refer to the manufacturer's contact information provided with your product packaging.

Thank you for your attention to these safety instructions. Enjoy your enhanced Glock experience!