

UXR ELITE RIFLE SYSTEM 223 WYLDE SEMI-AUTO RIFLE - UXR ELITE RIFLE SYSTEM 223 WYLDE 16" BBL (1)30RD MAG BLACK

UXR THE NEW PROPRIETARY UXR, OR "USER XCHANGE RIFLE", IS THE PINNACLE OF FIREARM INNOVATION. THIS REVOLUTIONARY SYSTEM OFFERS UNMATCHED MODULARITY AND PERFORMANCE. FEATURES:

XCHANGE Buttstock Module: Picatinny/1913/STANAG Rail mount interface, foldable with 6 position adjustable length of pull for 2.5" travel, ambidextrous LOP button and QD sling cups, 1" webbing sling slot mount, comfort-shoot rubber buttpad, and completed with a 2 position, height-adjustable cheek rest.

Reversible Folding Stock Mount: Choose your preferred side for folding the XCHANGE Buttstock Module.

XCHANGE Fire Control Housing Module: ergonomically designed UXR pistol grip also compatible with other AR15 style grips, ambidextrous QD sling cups, and oversized trigger guard.

XCHANGE Fire Control Module: Housing compatible with most AR15 triggers.

XCHANGE Magazine Well Module: Easily exchange modules for 5.56 NATO or 7.62 NATO magazines, complete with ambidextrous magazine release button and bolt stop/release

7075 Aluminum Receiver: Serialized upper receiver; universally compatible with multiple caliber configurations.

XCHANGE Titanium Trunnion: Return-to-zero-barrel clamp for precision modularity.

STANAG Top Rail: 18" usable length for optics and accessory mounts.

XCHANGE Handguard: Toolless and replaceable MLOK handguard for length customization.

Ambidextrous Folding Charging Handle: Snag-free and configurable for left or right handed users.

XCHANGE Barrel Exchange System: Swap calibers and barrel lengths rapidly with standard tooling, while maintaining repeatability and accuracy.

Ambidextrous Rocker Valve/Modified Long-Stroke Gas System: Select 3 gas settings effortlessly.

XCHANGE Evacuation Chamber: Supports suppressed and high rate of fire by removing noxious gasses from the operator's face and keeping the operating system cleaner.

Taper Muzzle Shoulder Lock: Perfect alignment and accessory lock for muzzle devices.

Universal Recoil Spring: Adaptable to various calibers and configurations.

Universal Bolt Carrier Group: Quick exchange bolt head assemblies for easy caliber conversions



Attributes

- Name: UXR ELITE RIFLE SYSTEM 223 WYLDE 16" BBL (1)30RD MAG BLACK
- Manufacturer: PRIMARY WEAPONS
- Product no.: 430113190
- Mfr. No.: UXR-223-16
- Action Type: Semi-Auto
- Barrel Length: 16"
- Capacity: 30+1-Round
- Cartridge: 223 Wylde
- Finish: Black
- Front Sight: None
- Length: NA
- Magazine Included: 1 x 30-Round
- Magazine Type: Removable
- Make: Primary Weapons System
- Model: UXR
- Muzzle: Compensator
- Rear Sight: None
- Stock Material: Synthetic
- Weight: NA
- Delivery weight: 8.391kg
- Shipping height: 102mm
- Shipping width: 305mm
- Shipping length: 940mm
- UPC: 811154032843

Item details

Made in USA

US export classification: 0A506.a

Table of Contents

- [Startpage](#)
- [English: UXR ELITE RIFLE SYSTEM Safety Instruction Guide](#)

UXR ELITE RIFLE SYSTEM Safety Instruction Guide

Introduction

Thank you for purchasing the UXR Elite Rifle System. This guide provides important safety information to ensure the safe and effective use of your firearm. Please read this guide thoroughly before using the product.

General Safety Guidelines

- Always treat the rifle as if it is loaded, even if you believe it to be unloaded.
- Keep the muzzle pointed in a safe direction at all times.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Use only manufacturer-approved accessories and modifications.
- Regularly inspect the rifle for signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Attend a firearm safety course if you are a new user or require a refresher.

Specific Safety Precautions for Use

- Ensure that you are familiar with the rifle's operation and features before handling it.
- Always wear appropriate safety gear, including eye and ear protection, when shooting.
- Do not load the rifle until you are ready to shoot.
- Avoid distractions while handling or operating the rifle.
- Never shoot at hard surfaces or water, as bullets can ricochet.
- Be aware of your surroundings and ensure a safe shooting environment.
- Do not use the rifle under the influence of drugs or alcohol.

Instructions for Installation and Usage

Installation

1. **Assembly:** Follow the manufacturer's instructions for assembling the UXR Elite Rifle System. Ensure all components are securely attached.
2. **Magazine Insertion:** To insert the magazine, align it with the magazine well and push it upward until it clicks into place.
3. **Loading:** Load the rifle by pulling back the charging handle, ensuring the chamber is clear, and then inserting the desired ammunition into the magazine.

Usage

1. **Firing:**
 - Ensure the safety is in the "fire" position before pulling the trigger.
 - Aim at your target, and ensure your backstop is safe.
 - Pull the trigger smoothly to fire the rifle.
2. **Unloading:**
 - Remove the magazine by pressing the magazine release button.
 - Pull back the charging handle to eject any round in the chamber.
 - Visually and physically inspect the chamber to ensure it is empty.

Disposal Instructions

- Dispose of the UXR Elite Rifle System in accordance with local laws and regulations.
- Do not discard the rifle in regular waste. Contact local authorities for proper disposal methods.
- Ensure all ammunition is removed before disposal.

Contact Information for Further Support

For any inquiries regarding safety, operation, or maintenance of the UXR Elite Rifle System, please contact the manufacturer or your local authorized dealer.

Please ensure you understand and follow these guidelines to maximize your safety and the safety of others while using the UXR Elite Rifle System. Your safety is paramount.