

LUBE-A-MATIC HEATER - RCBS LUBE-A-MATIC HEATER

[Reloading](#) > [Bullet Casting](#) > [Lube Sizers & Heaters](#)

Warms Hard Lubes for Easy Application To Lead Bullets

The RCBS Lube-A-Matic® (LAM) Heater mounts to your Lube-A-Matic® bullet sizer to keep the bullet lube at just the right temperature for steady flow and thorough, consistent application of lube to case lead bullets. Designed for today's high-temperature lubes, the Lube-A-Matic® (LAM) Heater has a built-in temperature adjustment control that lets you set the proper flow without runniness. Bump up or dial back the heat as needed for the particular lube you're using. Mounts to RCBS LAM sizer - Lyman, SAECO & other brands, too. Rheostat control for precise temperature adjustment. Plugs into standard 110/120 volt outlet. The RCBS Lube-A-Matic (LAM) Heater is drilled and tapped for mounting on the RCBS Lube-A-Matic® Sizer, as well as SAECO, Lyman, and lead bullet sizers from other manufacturers.



The RCBS Lube-A-Matic (LAM) Heater mounts to your Lube-A-Matic bullet sizer to keep the bullet lube at just the right temperature for steady flow and thorough, consistent application of lube to case lead bullets. Designed for today's high-temperature lubes, the Lube-A-Matic (LAM) Heater has a built-in temperature adjustment control that lets you set the proper flow without runniness. Bump up or dial back the heat as needed for the particular lube you're using. Mounts to RCBS LAM sizer - Lyman, SAECO & other brands, too. Rheostat control for precise temperature adjustment. Plugs into standard 110/120 volt outlet. The RCBS Lube-A-Matic (LAM) Heater is drilled and tapped for mounting on the RCBS Lube-A-Matic Sizer, as well as SAECO, Lyman, and lead bullet sizers from other manufacturers.

Attributes

- Name: [RCBS LUBE-A-MATIC HEATER](#)
- Manufacturer: [RCBS](#)
- Product no.: 747000028
- Mfr. No.: 80006
- Delivery weight: 0.953kg
- Shipping height: 51mm
- Shipping width: 127mm
- Shipping length: 203mm
- UPC: 604544621143

Table of Contents

- Startpage
- RCBS LubeAMatic Heater Safety Instruction Guide
- About Us

RCBS LubeAMatic Heater Safety Instruction Guide

Introduction

Thank you for choosing the RCBS LubeAMatic Heater. This product is designed to enhance your reloading experience by maintaining the optimal temperature for bullet lube application. Please read this safety instruction guide carefully to ensure safe and effective use of the heater.

General Safety Guidelines

- Always ensure that the heater is used in accordance with the manufacturer's instructions.
- Keep the heater out of reach of children and vulnerable individuals.
- Do not use the heater in wet or damp environments to avoid electrical hazards.
- Regularly inspect the heater for any signs of damage or wear before each use.
- If you notice any unusual odors, smoke, or malfunctions, unplug the heater immediately and discontinue use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the heater is properly mounted to the RCBS LubeAMatic Sizer before use.
- Use only compatible lubes that are designed for high-temperature applications.
- Avoid overloading the heater by exceeding the recommended temperature settings.
- Do not leave the heater unattended while in use.
- Always unplug the heater when not in use or before performing any maintenance.
- Use caution when adjusting the temperature settings to avoid burns.

Instructions for Installation and Usage

1. Installation:

- Carefully unpack the RCBS LubeAMatic Heater and check for any visible damage.
- Mount the heater securely onto your RCBS LubeAMatic Sizer, ensuring that it is aligned properly.
- Ensure that the heater is drilled and tapped for mounting on the sizer as per the manufacturer's guidelines.

2. Usage:

- Plug the heater into a standard 110/120 volt outlet.
- Turn on the heater and adjust the rheostat control to the desired temperature setting based on the lube you are using.
- Allow the heater to warm up for a few minutes before applying lube to the bullets.
- Monitor the temperature regularly to ensure it remains within the recommended range.

Disposal Instructions

- Dispose of the heater in accordance with local regulations regarding electronic waste.
- Do not dispose of the heater with regular household waste.
- If the heater is no longer functional, consider contacting a recycling center that accepts electronic appliances.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact details provided with your product packaging or visit the official website.

Thank you for prioritizing safety while using the RCBS LubeAMatic Heater. Enjoy your reloading process!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk