

SINGLE STAGE PRESS E-Z PRIME - MEC RELOADING E-Z PRIME "V" FOR 600 JR. MARK V & VERSA MEC 700 10 GAUGE

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

E-Z Prime "V" for 600 Jr. Mark V & Versa MEC 700 (not available in .410)



Attributes

- Name: [MEC RELOADING E-Z PRIME "V" FOR 600 JR. MARK V & VERSA MEC 700 10 GAUGE](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019385
- Mfr. No.: 285CA10
- Delivery weight: 0.637kg
- Shipping height: 89mm
- Shipping width: 148mm
- Shipping length: 152mm
- UPC: 098489013376

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for EZ Prime "V" for 600 Jr. Mark V & Versa MEC 700
- About Us

Safety Instruction Guide for EZ Prime "V" for 600 Jr. Mark V & Versa MEC 700

Introduction

Thank you for choosing the EZ Prime "V" for your MEC Reloading equipment. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read this document carefully before using the EZ Prime "V".

General Safety Guidelines

- Always read and understand the instruction manual before using the product.
- Keep the product out of the reach of children and vulnerable individuals.
- Ensure the work area is wellventilated and free from distractions.
- Inspect the product for any damage or wear before each use.
- Do not use the product for any purpose other than its intended use.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety goggles and gloves.
- Ensure that the reloading press is securely mounted to a stable surface before use.
- Do not exceed the recommended load specifications for your reloading equipment.
- Handle all components with care to avoid injury or damage.
- Keep hands and other body parts clear of moving parts during operation.
- Do not leave the product unattended while in use.
- Store the product in a dry and safe location when not in use.

Instructions for Installation and Usage

Installation

1. **Select a Suitable Location:** Choose a sturdy, flat surface for installation that is free from clutter.
2. **Secure the Press:** Use bolts or screws to firmly attach the EZ Prime "V" to the work surface.
3. **Check Alignment:** Ensure that the press is aligned correctly with your reloading equipment.

Usage

1. **Prepare the Equipment:** Ensure all necessary components are ready and within reach.
2. **Load the Primer:** Follow the manufacturer's instructions to load the primer into the EZ Prime "V".
3. **Perform the Reloading Process:**
 - Position the shell casing in the press.
 - Apply pressure to activate the priming mechanism.
 - Inspect the casing to ensure the primer is seated properly.
4. **Clean Up:** After use, clean the press and surrounding area to remove any debris or residues.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local waste disposal regulations.
- Do not dispose of the product in regular household waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the EZ Prime "V", please refer to the manufacturer's customer service resources.

Thank you for your attention to these safety guidelines. Your safety is our priority. Enjoy your reloading experience with the EZ Prime "V"!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk