Dominion Viewer/Menu Screen

The BOG camera menu and image viewer works universally as a spare or secondary viewer for the 18 MP black flash and 22 MP dual sensor infrared cameras This item allows users to quickly change menu settings or swap SD cards and batteries while checking cameras, requiring minimal time at the camera site, but simply ejecting one viewer and replacing it with the new viewer.

NO IMAGE AVAILABLE

Attributes

- Name: [BOG Dominion Viewer/Menu Screen](#)
- Manufacturer: [BOG](#)
- Product no.: EU1001661
- Mfr. No.: 1116334
- Delivery weight: 0.03kg
- Shipping height: 74mm
- Shipping width: 28mm
- Shipping length: 114mm
- UPC: 661120080497

Table of Contents

BOG Dominion Viewer/Menu Screen Safety Instruction Guide

Introduction

Thank you for choosing the BOG Dominion Viewer/Menu Screen. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before using the device.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as a secondary viewer for BOG cameras.
- Keep the viewer out of reach of children and vulnerable individuals.
- Avoid exposure to extreme temperatures, moisture, or direct sunlight to prevent damage.
- Regularly check the product for any signs of wear or damage before use.
- Do not attempt to repair or modify the product. Contact a qualified service provider if repairs are needed.
- Always follow local regulations regarding electronic device disposal.

Specific Safety Precautions for Use

- **Battery Safety**:

  - Use only the recommended type of batteries.
  - Do not mix old and new batteries or different types of batteries.
  - Dispose of batteries properly according to local regulations.

- **SD Card Handling**:

  - Always handle SD cards with clean, dry hands.
  - Ensure the SD card is inserted correctly before use.
  - Do not remove the SD card while the camera is in operation.

- **Camera Interaction**:

  - Always power off the camera before swapping the viewer or making any adjustments.
  - Avoid touching the camera lens to prevent damage or dirt accumulation.

- **Electrical Safety**:

  - Do not expose the viewer to water or other liquids.
  - Ensure that all connections are secure and free from dust or debris.

Instructions for Installation and Usage

1. **Installation**:

   - Ensure that the camera is powered off.
   - Remove the existing viewer by gently ejecting it from the camera.
   - Align the new viewer with the camera's connection port and firmly insert it until it clicks into place.

2. **Usage**:

   - Power on the camera after the new viewer is securely attached.

- Use the viewer to navigate the camera menu and check images.
- To change settings, follow the onscreen prompts using the viewer interface.

3. **Battery Replacement**:

   - To replace the battery, power off the camera.
   - Open the battery compartment and remove the old battery.
   - Insert a new battery, ensuring correct polarity.
   - Close the compartment securely before powering on the camera.

Disposal Instructions

- Dispose of the BOG Dominion Viewer/Menu Screen and its components in accordance with local waste management regulations.
- Do not dispose of electronic devices in regular household waste.
- Check for local recycling programs that accept electronic waste.

Contact Information for Further Support

For any safety inquiries, concerns, or to report unsafe products, please contact the designated EUbased contact point for this product. Ensure you have the product details and any relevant information ready for assistance.

Thank you for following these safety instructions. Your safety and satisfaction are our top priorities. Enjoy using your BOG Dominion Viewer/Menu Screen!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk