

Magnum Carrier Assembly for Pile Driver Bullet Puller

[Reloading](#) > [Case Preparation](#) > [Bullet Pullers](#)

This is an accessory for Pile Driver Bullet Puller, for cartridges up to 338 Lapua length.

NO IMAGE
AVAILABLE

Attributes

- Name: [Magnum Carrier Assembly for Pile Driver Bullet Puller](#)
- Manufacturer: [Frankford Arsenal](#)
- Product no.: EU1001776
- Mfr. No.: 1132857
- Delivery weight: 0.09kg
- Shipping height: 102mm
- Shipping width: 51mm
- Shipping length: 236mm
- UPC: 661120103714

Table of Contents

- Startpage
- Frankford Arsenal Magnum Carrier Assembly for Pile Driver Bullet Puller Safety Instructions
- About Us

Frankford Arsenal Magnum Carrier Assembly for Pile Driver Bullet Puller Safety Instructions

Introduction

Thank you for choosing the Frankford Arsenal Magnum Carrier Assembly for your Pile Driver Bullet Puller. This accessory is designed for use with cartridges up to 338 Lapua length. To ensure your safety and the proper functioning of the product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that all users are aware of the safety guidelines before using the product.
- Always use the Magnum Carrier Assembly in accordance with the manufacturer's instructions.
- Store the product in a secure location away from children and pets.
- Inspect the product before each use for any signs of damage or wear.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use this product only with compatible cartridges as specified by the manufacturer.
- Wear appropriate safety gear, including eye protection, when using the bullet puller.
- Keep hands and other body parts clear of moving parts during operation.
- Do not use the Magnum Carrier Assembly if it appears damaged or malfunctioning.
- Ensure that the work area is clean and free from distractions while using the product.
- Follow all local regulations regarding the handling of ammunition and reloading equipment.

Instructions for Installation and Usage

1. Installation Steps:

- Ensure the Pile Driver Bullet Puller is securely mounted and stable.
- Attach the Magnum Carrier Assembly to the Pile Driver Bullet Puller according to the manufacturer's instructions.
- Ensure that the assembly is locked in place before use.

2. Usage Steps:

- Select the cartridge you wish to pull and ensure it is compatible with the Magnum Carrier Assembly.
- Insert the cartridge into the Magnum Carrier Assembly.
- Operate the Pile Driver Bullet Puller according to the manufacturer's guidelines, ensuring all safety precautions are followed.
- After use, remove the cartridge and inspect the Magnum Carrier Assembly for any signs of wear or damage.

Disposal Instructions

- Dispose of the Magnum Carrier Assembly in accordance with local waste disposal regulations.
- Do not dispose of the assembly in regular household waste if it is damaged or defective; consult local authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of the Frankford Arsenal Magnum Carrier Assembly, please refer to the manufacturer's contact information provided with the product packaging or visit their official website for support resources.

Thank you for prioritizing safety while using the Frankford Arsenal Magnum Carrier Assembly for Pile Driver Bullet Puller. Your adherence to these guidelines helps ensure a safe and effective experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk