

# Gym Sack

[Shooting Accessories](#) > [Brownells Gear](#)

Introducing the Brownells Europe gym sack! This stylish and functional bag is made from high quality bio-burlap, and features the Brownells Europe logo.

Perfect for the fitness enthusiast or anyone on the go, this sack has plenty of room to store all your gear. The drawstring closure makes it easy to open and close, and adjustable shoulder straps make it comfortable to carry. Whether you're headed to the shooting range or just running errands, this gym sack is a great choice. Order yours today!



## Attributes

- Name: [Gym Sack](#)
- Manufacturer: [BROWNELLS EUROPE](#)
- Product no.: EU2009767
- Mfr. No.:
- Delivery weight: 0.2kg
- Shipping height: 20mm
- Shipping width: 430mm
- Shipping length: 340mm

# Table of Contents

- Startpage
- Gym Sack Safety Instruction Guide
- About Us

# Gym Sack Safety Instruction Guide

## Introduction

Thank you for choosing the Brownells Europe gym sack. This guide provides important safety instructions and guidelines to ensure your safe and enjoyable use of the product. Please read this document carefully before using the gym sack.

## General Safety Guidelines

- Ensure that the gym sack is used only for its intended purpose of carrying personal items and gear.
- Regularly inspect the gym sack for any signs of damage or wear, such as frayed straps or torn fabric.
- Keep the gym sack away from sharp objects that may puncture or tear the material.
- Avoid overloading the gym sack to prevent strain on the straps and potential breakage.
- Store the gym sack in a cool, dry place when not in use to maintain its quality.

## Specific Safety Precautions for Use

- The gym sack is designed for adults and older children. Do not allow young children to use the sack unsupervised.
- Avoid using the gym sack in extreme weather conditions, such as heavy rain or snow, as this may affect the durability of the material.
- When using the drawstring closure, ensure that it is securely fastened to avoid accidental opening during use.
- Adjust the shoulder straps properly to ensure a comfortable fit and to prevent the sack from slipping off your shoulders.

## Instructions for Installation and Usage

- **Unpacking:** Remove the gym sack from its packaging. Inspect for any damage before use.
- **Adjusting the Straps:**
  1. Hold the gym sack in front of you.
  2. Locate the adjustable shoulder straps on either side.
  3. Pull the straps to lengthen or shorten them according to your comfort.
- **Using the Drawstring Closure:**
  1. Open the gym sack by pulling the drawstring apart.
  2. Place your items inside the sack.
  3. Pull the drawstring to close the top securely.
- **Carrying:** Place the gym sack over your shoulder ensuring that the weight is evenly distributed. Adjust the straps as needed for comfort.

## Disposal Instructions

- When the gym sack reaches the end of its life cycle, please dispose of it responsibly.
- Check local regulations for proper disposal methods for textile products.
- If the gym sack is damaged beyond repair, consider recycling the material if possible.

## Contact Information for Further Support

For any safety inquiries or additional support, please refer to the contact point provided by the manufacturer or retailer where you purchased the gym sack.

## **Conclusion**

By following these safety instructions, you can ensure a safe and enjoyable experience with your Brownells Europe gym sack. Always prioritize safety and care for your product to maximize its lifespan and functionality. Thank you for your attention!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)