

Fototrappola PNI Hunting 400C



Table of Contents

- Startpage
- Safety Instructions for Fototrappola PNI Hunting 400C
- About Us

Safety Instructions for Fototrappola PNI Hunting 400C

Introduction

Thank you for choosing the Fototrappola PNI Hunting 400C. To ensure your safety and the safe operation of this product, please read and follow these safety instructions carefully. This guide is designed to help you understand how to use the product safely and effectively while complying with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read the user manual before using the product.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for any signs of damage or wear.
- Do not use the product if it appears to be damaged or malfunctioning.
- Follow all local regulations regarding the use of hunting equipment.
- Ensure that the product is used only for its intended purpose.

Specific Safety Precautions for Use

- Ensure the product is set up in a safe location away from public areas and livestock.
- Always check the area where the product will be used for potential hazards, such as obstacles or dangerous wildlife.
- Use appropriate protective gear, such as gloves and safety glasses, when handling the product.
- Do not modify the product in any way; alterations can lead to unsafe conditions.
- Keep the product clean and free from debris to ensure proper functioning.
- Be aware of your surroundings when using the product, especially when it is in operation.

Instructions for Installation and Usage

1. Installation:

- Choose a suitable location that is stable and secure.
- Ensure the camera is mounted at the correct height and angle for optimal performance.
- Follow the manufacturer's instructions for mounting the camera securely.
- Ensure that the camera is not obstructed by branches or other objects.

2. Usage:

- Turn on the camera and set the desired settings according to your needs.
- Regularly check battery levels and replace batteries as needed.
- Review captured images and videos periodically to ensure the product is functioning correctly.
- If you notice any issues, consult the troubleshooting section of the user manual.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic waste.
- Remove batteries and dispose of them properly at designated recycling centers.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Fototrappola PNI Hunting 400C, please refer to the customer support section of the manufacturer's website or contact your local retailer for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Fototrappola PNI Hunting 400C. Thank you for your attention to these important safety guidelines.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

Sede Legale enbsp; Operativanbsp;

Brownells Italia Srlnbsp;

Via Dante Alighieri 163

25068nbsp; Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it