

LASER BORESIGHTER - SL-100 LASER BORESIGHTER

[Gunsmith Tools & Supplies](#) > [Sight & Scope Installation Tools](#) > [Laser Boresighters](#)

Gets You Close To Point Of Aim Without Firing A Shot

Saves range time and ammo; highly accurate laser system lets you zero your scope to point-of-aim at 100 yards, before you go to the range. Quick and easy to use, just place the special laser target 25 feet away and aim the laser at it, then adjust the scope till the crosshairs align with the target. Works equally well with red dot scopes and iron sights. Laser is mounted to a cone shaped, aluminum spud. An O-ring and a powerful magnet hold the spud centered in the bore. No special adapters to buy and no metal contacts the rifling. A system of adapters and O-rings lets one unit fit all firearms from .22 to .50 caliber, plus 12 and 20 gauge shotguns. Also includes the SRL-100 adapter that slips over the Boresighter's lens to convert it into a highly accurate Scope Reticle Leveler by refocusing the laser to a horizontal beam for precise crosshair alignment. SL-100 Standard Model for use indoors, where you have control over ambient lighting. SL-150 Ultra-Mag has an ultra-bright Red 635mm laser for better visibility in bright, ambient light conditions. SL-500 Ultra-Mag uses a super-bright green laser for maximum visibility of the sighting dot in daylight and very bright ambient light.



Attributes

- Name: [SL-100 LASER BORESIGHTER](#)
- Manufacturer: [SITE-LITE](#)
- Product no.: 100000843
- Mfr. No.: 18001
- Delivery weight: 0.386kg
- Shipping height: 53mm
- Shipping width: 155mm
- Shipping length: 251mm
- UPC: 703952180003

Table of Contents

- Startpage
- LASER BORESIGHTER SL100 Safety Instruction Guide
- About Us

LASER BORESIGHTER SL100 Safety Instruction Guide

Introduction

Thank you for choosing the LASER BORESIGHTER SL100. This product is designed to assist you in accurately zeroing your scope before heading to the range, saving you time and ammunition. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always treat the laser boresighter as if it were a loaded firearm.
- Never point the laser at anyone's eyes or reflective surfaces.
- Keep the device out of reach of children and unauthorized users.
- Use the boresighter only in accordance with the provided instructions.
- Ensure that all components are in good condition before use.
- Regularly check for any signs of wear or damage.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is not intended for use by individuals under 18 years of age without adult supervision.
- **Environment:** Use the boresighter in a controlled environment to avoid distractions and ensure safety.
- **Laser Safety:** The laser emitted is classified as a Class 2 laser. Avoid direct eye exposure when the device is in use.
- **Firearm Safety:** Always ensure that your firearm is unloaded before attaching the boresighter. Follow standard firearm safety practices at all times.
- **Magnet Precautions:** The device contains a powerful magnet. Keep it away from electronic devices and magnetic media to avoid damage.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather all components: the boresighter, adapters, Orings, and target cards.

2. Installation:

- Select the appropriate adapter for your firearm caliber.
- Attach the adapter securely to the boresighter.
- Insert the boresighter into the bore of the firearm, ensuring it fits snugly.

3. Setup:

- Position the special laser target 25 feet away from the firearm.
- Power on the boresighter to activate the laser.

4. Adjustment:

- Aim the laser at the target.
- Adjust the scope until the crosshairs align with the laser dot on the target.
- Repeat the process as necessary to ensure accuracy.

5. Storage:

- After use, remove the boresighter from the firearm.
- Store the device and all components in the provided plastic storage case to prevent damage.

Disposal Instructions

- Dispose of the LASER BORESIGHTER SL100 and its components in accordance with local regulations.
- Do not dispose of batteries in regular household waste. Follow local guidelines for battery disposal or recycling.

Contact Information for Further Support

For any safety inquiries or support regarding the LASER BORESIGHTER SL100, please refer to the manufacturer's contact information provided with the product packaging.

By following these safety instructions, you can ensure a safe and effective experience with your LASER BORESIGHTER SL100. Always prioritize safety when handling firearms and related equipment. Thank you for your attention to these important guidelines.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at