

LASER BORESIGHTER - SITE-LITE SL-150 ULTRA-MAG LASER BORESIGHTER

[Gunsmith Tools](#) > [Sight & Scope Installation Tools](#) > [Laser Boresighters](#)

Gets You Close To Point Of Aim Without Firing A Shot

Saves range time and ammo; highly accurate laser system lets you zero your scope to point-of-aim at 100 yards, before you go to the range. Quick and easy to use, just place the special laser target 25 feet away and aim the laser at it, then adjust the scope till the crosshairs align with the target. Works equally well with red dot scopes and iron sights. Laser is mounted to a cone shaped, aluminum spud. An O-ring and a powerful magnet hold the spud centered in the bore. No special adapters to buy and no metal contacts the rifling. A system of adapters and O-rings lets one unit fit all firearms from .22 to .50 caliber, plus 12 and 20 gauge shotguns. Also includes the SRL-100 adapter that slips over the Boresighter's lens to convert it into a highly accurate Scope Reticle Leveler by refocusing the laser to a horizontal beam for precise crosshair alignment. SL-100 Standard Model for use indoors, where you have control over ambient lighting. SL-150 Ultra-Mag has an ultra-bright Red 635mm laser for better visibility in bright, ambient light conditions. SL-500 Ultra-Mag uses a super-bright green laser for maximum visibility of the sighting dot in daylight and very bright ambient light.



Attributes

- Name: [SITE-LITE SL-150 ULTRA-MAG LASER BORESIGHTER](#)
- Manufacturer: [SITE-LITE](#)
- Product no.: 100002429
- Mfr. No.: 24500
- Delivery weight: 0.454kg
- Shipping height: 51mm
- Shipping width: 152mm
- Shipping length: 241mm
- UPC: 703952240004

Table of Contents

- Startpage
- Safety Instruction Guide for LASER BORESIGHTER SITELITE SL150 ULTRAMAG LASER BORESIGHTER
- About Us

Safety Instruction Guide for LASER BORESIGHTER SITELITE SL150 ULTRAMAG LASER BORESIGHTER

Introduction

Thank you for choosing the LASER BORESIGHTER SITELITE SL150 ULTRAMAG LASER BORESIGHTER. This guide provides essential safety instructions to ensure the safe and effective use of your laser boresighter. Please read this guide thoroughly before using the product.

General Safety Guidelines

- Always handle the laser boresighter with care.
- Do not point the laser at yourself or others.
- Keep the laser away from children and unauthorized users.
- Use the product only as intended and according to the provided instructions.
- Ensure that the laser boresighter is used in a safe environment, free from distractions.
- Regularly inspect the product for any signs of damage or wear before use.
- If the product is damaged, discontinue use immediately and seek replacement parts or service.

Specific Safety Precautions for Use

- **Eye Safety:** The laser beam can cause eye injuries. Always wear appropriate eye protection when using the device.
- **Environmental Awareness:** Be aware of your surroundings. Ensure that no reflective surfaces are nearby that could redirect the laser beam.
- **Battery Safety:** Use only the specified batteries for your device. Do not mix old and new batteries or different battery types.
- **Storage:** Store the laser boresighter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Distraction:** Avoid using the laser boresighter in crowded or noisy environments where distractions may occur.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction before installing the laser boresighter.
- Select the appropriate adapter for your firearm caliber from the included adapters.
- Attach the laser boresighter securely to the firearm's bore using the O-ring and magnet to hold it in place.

2. Usage:

- Place the special laser target 25 feet away from your shooting position.
- Turn on the laser boresighter and aim the laser at the target.
- Adjust your scope until the crosshairs align with the laser dot on the target.
- Repeat the adjustment process as necessary to ensure accuracy.

3. After Use:

- Turn off the laser boresighter and remove it from the firearm.
- Store the device and all accessories in the provided plastic storage case.

Disposal Instructions

- Dispose of the laser boresighter and its components in accordance with local regulations for electronic waste.
- Remove batteries before disposal and recycle them according to local battery recycling programs.

Contact Information for Further Support

For any questions or concerns regarding the LASER BORESIGHTER SITELITE SL150 ULTRAMAG LASER BORESIGHTER, please contact the manufacturer or your local distributor for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your LASER BORESIGHTER SITELITE SL150 ULTRAMAG LASER BORESIGHTER. Thank you for your attention to safety, and enjoy your product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk