

LASER BORESIGHTER - SIGHTMARK 40 S&W BORESIGHTER

[Gunsmith Tools & Supplies](#) > [Sight & Scope Installation Tools](#) > [Laser Boresighters](#)

Chamber-Mounted Laser Helps You Sight In Rifle Or Pistol Without Firing A Shot

Easy-to-use, self-contained boresighting system fits in the chamber of your rifle or pistol and projects a powerful red laser beam aligned with the bore axis for sighting to the point-of-aim without firing a shot. Works with scopes, holographic red dot sights, and "iron" sights. Durable, machined brass housing looks like a cartridge case but actually contains the entire laser system and batteries. Insert the batteries and screw the cap on the housing to turn on the laser; remove the batteries to turn off. Insert the entire assembly into the chamber, gently close the action, and aim at a target 20-30 yards away. Adjust windage and elevation of the scope or sights so point-of-aim is zeroed on the dot, compensating for sight offset to prevent gun from shooting high. Go to the range for test shots and final sight adjustments. Store boresighter in the included nylon carrying case that fits easily in a pocket, tool kit, or range bag. Available in a variety of calibers, listed below.



Attributes

- Name: [SIGHTMARK 40 S&W BORESIGHTER](#)
- Manufacturer: [SIGHTMARK](#)
- Product no.: 100004017
- Mfr. No.: SM39016
- Cartridge: 40 S&W
- Delivery weight: 0.091kg
- UPC: 810119011220

Table of Contents

- Startpage
- Safety Instruction Guide for the LASER BORESIGHTER SIGHTMARK 40 S&W BORESIGHTER
- About Us

Safety Instruction Guide for the LASER BORESIGHTER SIGHTMARK 40 S&W BORESIGHTER

Introduction

Thank you for choosing the LASER BORESIGHTER SIGHTMARK 40 S&W BORESIGHTER. This guide provides essential safety instructions and usage guidelines to ensure safe operation and maintenance of your boresighter. Please read this manual carefully before using the product.

General Safety Guidelines

- Ensure the product is used only as intended and in accordance with these instructions.
- Always treat firearms with respect and follow standard firearm safety procedures.
- Keep the boresighter out of reach of children and unauthorized users.
- Regularly check the boresighter for any signs of damage or wear. Do not use if damaged.
- Store the boresighter in a safe and secure place when not in use.
- Dispose of batteries and the boresighter responsibly, following local regulations.

Specific Safety Precautions for Use

- Do not point the laser beam at anyone's eyes or reflective surfaces.
- Ensure the firearm is unloaded before inserting the boresighter.
- Always aim the firearm in a safe direction when using the boresighter.
- Do not use the boresighter while the firearm is in motion or if the action is not securely closed.
- Be aware of your surroundings and ensure that no one is within the line of sight when using the boresighter.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded. Check the chamber and magazine.
- Gather the necessary items: LASER BORESIGHTER, batteries, and a target.

2. Battery Installation

- Open the housing cap of the boresighter.
- Insert the (2) AG5 button cell batteries into the housing, ensuring correct polarity.
- Screw the cap back onto the housing to turn on the laser.

3. Boresighter Insertion

- Insert the entire boresighter assembly into the chamber of the firearm.
- Gently close the action of the firearm without forcing it.

4. Aiming at Target

- Aim the firearm at a target located 2030 yards away.
- Observe the red dot projected by the laser on the target.

5. Adjusting Sights

- Adjust the windage and elevation settings of your scope or sights so that the point of aim is aligned with the laser dot.
- This adjustment compensates for any sight offset to ensure accurate shooting.

6. Final Checks

- After adjustments, remove the boresighter from the chamber.
- Store the boresighter in the included nylon carrying case.

Disposal Instructions

- Dispose of used batteries according to local regulations for battery disposal.
- If the boresighter is no longer functioning or needed, follow local guidelines for electronic waste disposal.
- Do not dispose of the boresighter in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the LASER BORESIGHTER SIGHTMARK 40 S&W BORESIGHTER, please refer to the manufacturer's website or customer support resources.

By following these safety instructions, you can ensure a safe and effective experience with your LASER BORESIGHTER. Thank you for your attention to safety and responsible firearm use.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu