

LASER BORESIGHTER - 357 MAGNUM/38 SPECIAL BORESIGHTER

[Gunsmith Tools & Supplies](#) > [Sight & Scope Installation Tools](#) > [Laser Boresighters](#)

Chamber-Mounted Laser Helps You Sight In Rifle Or Pistol Without Firing A Shot

Easy-to-use, self-contained boresighting system fits in the chamber of your rifle or pistol and projects a powerful red laser beam aligned with the bore axis for sighting to the point-of-aim without firing a shot. Works with scopes, holographic red dot sights, and "iron" sights. Durable, machined brass housing looks like a cartridge case but actually contains the entire laser system and batteries. Insert the batteries and screw the cap on the housing to turn on the laser; remove the batteries to turn off. Insert the entire assembly into the chamber, gently close the action, and aim at a target 20-30 yards away. Adjust windage and elevation of the scope or sights so point-of-aim is zeroed on the dot, compensating for sight offset to prevent gun from shooting high. Go to the range for test shots and final sight adjustments. Store boresighter in the included nylon carrying case that fits easily in a pocket, tool kit, or range bag. Available in a variety of calibers, listed below.



Attributes

- Name: [357 MAGNUM/38 SPECIAL BORESIGHTER](#)
- Manufacturer: [SIGHTMARK](#)
- Product no.: 100047551
- Mfr. No.: SM39018
- Cartridge: 38 Special,357 Magnum
- Delivery weight: 0.05kg
- Shipping height: 25mm
- Shipping width: 127mm
- Shipping length: 191mm
- UPC: 810119011244

Table of Contents

- Startpage
- LASER BORESIGHTER 357 MAGNUM/38 SPECIAL BORESIGHTER Safety Instructions
- About Us

LASER BORESIGHTER 357 MAGNUM/38 SPECIAL BORESIGHTER Safety Instructions

Introduction

Thank you for purchasing the LASER BORESIGHTER 357 MAGNUM/38 SPECIAL BORESIGHTER. This product is designed to assist in sighting your rifle or pistol accurately without firing a shot. Please read this safety instruction guide carefully to ensure safe and proper use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat the boresighter as if it is a loaded firearm.
- Keep the boresighter and all accessories out of reach of children and unauthorized users.
- Do not use the boresighter if it appears damaged or has been modified in any way.
- Ensure the boresighter is used in a safe environment, free from distractions and hazards.
- Always wear appropriate eye protection when using the boresighter.
- Report any unsafe products or accidents to the relevant authorities immediately.
- Check for recall updates on the EU's Safety Gate platform regularly.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before inserting the boresighter into the chamber.
- Do not point the boresighter at any person or animal.
- Avoid using the boresighter in wet or damp conditions to prevent damage.
- Do not attempt to disassemble the boresighter as it may cause malfunction or injury.
- Use only the recommended batteries (AG5 button cell batteries) for the boresighter.
- Always store the boresighter in the included carrying case when not in use.

Instructions for Installation and Usage

1. Insert Batteries:

- Open the brass housing by unscrewing the cap.
- Insert the AG5 button cell batteries, ensuring correct polarity.
- Screw the cap back on to turn on the laser.

2. Insert Boresighter:

- Ensure the firearm is pointed in a safe direction.
- Insert the entire boresighter assembly into the chamber of your rifle or pistol.
- Gently close the action of the firearm.

3. Aiming:

- Aim at a target located 2030 yards away.
- Observe the red laser dot projected by the boresighter.

4. Adjusting Sights:

- Adjust the windage and elevation of your scope or sights so that the pointofaim is aligned with the laser dot.
- Compensate for any sight offset to prevent the firearm from shooting high.

5. Testing:

- After adjustments, go to the shooting range for test shots.
- Make final sight adjustments as necessary.

6. Turning Off:

- Remove the batteries from the boresighter to turn off the laser when not in use.

Disposal Instructions

- Dispose of the boresighter and batteries in accordance with local regulations.
- Do not dispose of batteries in household waste. Instead, take them to a designated battery recycling point.

Contact Information for Further Support

For any inquiries or further assistance regarding the LASER BORESIGHTER, please refer to the manufacturer's contact details provided on the packaging or product documentation.

By following these safety instructions, you can ensure a safe and effective experience with your LASER BORESIGHTER. Thank you for your attention to these important guidelines.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at