

FOXTROT RIFLE/PISTOL SHOOTING REST - BIRCHWOOD CASEY FOXTROT RIFLE/PISTOL SHOOTING REST

[Shooting Accessories](#) > [Shooting Rests](#) > [Rifle Rests](#)

KEY FEATURES PADDED FRONT AND REAR NON-MARRING MATERIAL
COMFORTABLE AND DURABLE ADJUSTABLE ELEVATION FITS MOST RIFLES
DETACHABLE REAR FOR USE WITH HANDGUNS REMOVEABLE CENTER
SECTION FOR UNLIMITED ADJUSTMENT AND VERSATILITY



Attributes

- Name: [BIRCHWOOD CASEY FOXTROT RIFLE/PISTOL SHOOTING REST](#)
- Manufacturer: [BIRCHWOOD CASEY](#)
- Product no.: 100048021
- Mfr. No.: BC-CSR
- Material: Steel
- Style: Rest
- Delivery weight: 1.869kg
- Shipping height: 191mm
- Shipping width: 275mm
- Shipping length: 311mm
- UPC: 888151031506

Table of Contents

- [Startpage](#)
- [FOXTROT RIFLE/PISTOL SHOOTING REST SAFETY INSTRUCTIONS](#)
- [About Us](#)

FOXTROT RIFLE/PISTOL SHOOTING REST SAFETY INSTRUCTIONS

Introduction

Thank you for purchasing the Birchwood Casey Foxtrot Rifle/Pistol Shooting Rest. This guide provides essential safety instructions and guidelines to ensure the safe use and maintenance of your shooting rest. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure that the shooting rest is used only for its intended purpose.
- Always handle firearms with care and treat them as if they are loaded.
- Keep the shooting rest and all firearms out of reach of children and unauthorized users.
- Regularly inspect the shooting rest for any signs of damage or wear before each use.
- Follow all local laws and regulations regarding firearm usage and safety.

Specific Safety Precautions for Use

- Use the shooting rest on a stable and level surface to prevent tipping.
- Do not exceed the weight limit of the shooting rest; check the manufacturer's specifications.
- Ensure that the padded front and rear are properly positioned to avoid slipping during use.
- When using the detachable rear for handguns, ensure it is securely attached before use.
- Adjust the elevation carefully to avoid sudden movements that may lead to accidents.
- Always keep the shooting rest clear of any obstructions while in use.

Instructions for Installation and Usage

1. Assembly:

- Unpack all components of the shooting rest.
- Attach the padded front and rear sections according to the manufacturer's instructions.
- Ensure all connections are secure before use.

2. Adjusting Elevation:

- Locate the adjustment mechanism on the shooting rest.
- Turn the adjustment knob or lever to raise or lower the rest as needed.
- Test the stability after making adjustments.

3. Using with Rifles:

- Place the rifle securely on the padded front and rear sections.
- Ensure the rifle is stable and aligned before aiming or shooting.

4. Using with Handguns:

- Detach the rear section as needed and attach it securely for handgun use.
- Position the handgun on the rest and ensure it is stable before aiming.

5. PostUse Care:

- After use, clean the shooting rest to remove any debris or residue.
- Store the shooting rest in a safe and dry location away from children.

Disposal Instructions

- Dispose of the shooting rest in accordance with local regulations.
- If the product is damaged beyond repair, consider recycling materials where applicable.
- Do not dispose of the product in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of the Foxtrot Rifle/Pistol Shooting Rest, please refer to the manufacturer's contact information provided with the product packaging.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Birchwood Casey Foxtrot Rifle/Pistol Shooting Rest. Always prioritize safety and responsibility when handling firearms. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk