

HEADSPACE GAUGE-FIELD GAUGE - FORSTER PRODUCTS, INC. 220 SWIFT FIELD GAUGE

[Reloading](#) > [Measuring Tools](#) > [Case Gauges & Headspace Tools](#)

Forster Headspace Gages are used to determine whether your rifle headspace is correct and within SAAMI specifications. These gages are made to chamber in your rifle similar to a cartridge. Available in "GO", "NO GO", and Field Gage lengths.



Attributes

- Name: [FORSTER PRODUCTS, INC. 220 SWIFT FIELD GAUGE](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 749003164
- Mfr. No.: HG0220F
- Cartridge: 220 Swift
- Color: -
- Height: -
- Length: -
- Material: -
- Model Number: -
- Style: -
- Weight: -
- Width: -
- Delivery weight: 0.045kg
- Shipping height: 13mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 757253004223

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for HEADSPACE GAUGEFIELD GAUGE](#)
- [About Us](#)

Safety Instruction Guide for HEADSPACE GAUGEFIELD GAUGE

Introduction

Thank you for choosing the HEADSPACE GAUGEFIELD GAUGE by Forster Products, Inc. This product is designed to help you determine whether your rifle headspace is correct and within SAAMI specifications. Proper use of this gauge is essential for ensuring the safety and functionality of your firearm. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always follow the manufacturer's instructions for use.
- Ensure that the gauge is appropriate for the specific cartridge you are using.
- Inspect the gauge for any signs of damage before use.
- Keep the gauge out of reach of children and unauthorized users.
- Use the gauge only for its intended purpose.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that your rifle is unloaded before using the gauge.
- Avoid using the gauge in wet or damp conditions to prevent rust and corrosion.
- Do not force the gauge into the chamber; it should fit smoothly.
- Wear safety glasses while using the gauge to protect your eyes from potential debris.
- Avoid contact with sharp edges on the gauge to prevent cuts or injuries.
- If you are unsure about the proper use of the gauge, seek assistance from a qualified professional.

Instructions for Installation and Usage

1. Preparation

- Ensure your rifle is completely unloaded.
- Gather all necessary tools and materials for use.

2. Using the Gauge

- Select the appropriate gauge for your cartridge (220 Swift).
- Insert the gauge into the chamber of your rifle, ensuring it is aligned correctly.
- Gently push the gauge into the chamber until it is fully seated.
- Check the gauge position:
 - If the "GO" gauge fits, your headspace is within specifications.
 - If the "NO GO" gauge fits, your headspace is excessive.
 - If the Field Gauge fits, consult a qualified gunsmith for further evaluation.

3. PostUse Care

- Remove the gauge from the chamber carefully.
- Clean the gauge after use to remove any debris or residue.
- Store the gauge in a dry place, away from moisture.

Disposal Instructions

- Dispose of the gauge according to local regulations.
- If the gauge is damaged or no longer functional, do not attempt to repair it. Instead, follow your local waste disposal guidelines for hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the use of the HEADSPACE GAUGEFIELD GAUGE, please refer to the manufacturer's website or contact their customer support for assistance.

Thank you for prioritizing safety and compliance while using the HEADSPACE GAUGEFIELD GAUGE. Your attention to these guidelines will help ensure a safe and enjoyable experience with your firearm.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk