# STANDARD BULLET SEATING MICROMETERS - #36 STANDARD BULLET SEATING MICROMETER

Redding Competition Seating Dies deliver the precision and accuracy preferred by the most discriminating handloaders. Now you can easily covert your conventional seating die to a precision micrometer seating die for use with STD (standard) bullets for precise, repeatable bullet seating depths to within 1/1000th of an inch and potential world-record accuracy. Designed for all seating dies that use a seat plug with ½-20 threads. Easily changes from one die to another, just match the number on your current seating plug to the corresponding bullet seating micrometer number. View Redding Micrometer Reference Chart here.



#### **Attributes**

Name: #36 STANDARD BULLET SEATING MICROMETER

Manufacturer: REDDINGProduct no.: 749017211

Mfr. No.: 09096Cartridge: -

Delivery weight: 0.07kg
Shipping height: 19mm
Shipping width: 19mm
Shipping length: 89mm
UPC: 611760090967

#### Item details

Made in USA

# **Table of Contents**

- Startpage
- English: Safety Instruction Guide for STANDARD BULLET SEATING MICROMETERS #36

# Safety Instruction Guide for STANDARD BULLET SEATING MICROMETERS #36

#### Introduction

Thank you for choosing the Redding Competition Seating Die with the STANDARD BULLET SEATING MICROMETER. This product is designed to enhance your reloading experience by providing precision and accuracy. To ensure your safety and the safe use of this product, please follow the guidelines outlined in this document.

### **General Safety Guidelines**

- Always read and understand the product instructions before use.
- Ensure you are using the product in a wellventilated area.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear.
- Store the product in a dry and safe location when not in use.
- Report any unsafe conditions or incidents to the appropriate authorities.

## **Specific Safety Precautions for Use**

- Use the micrometer seating die only with compatible seating dies that have a seat plug with ½20 threads.
- Ensure that the micrometer is securely attached to the die before use.
- Avoid applying excessive force when adjusting the micrometer settings.
- Do not attempt to modify or disassemble the micrometer or its components.
- Always wear appropriate eye protection when reloading ammunition.
- Follow all local laws and regulations regarding ammunition reloading.

# Instructions for Installation and Usage

#### 1. Installation:

- Ensure the reloading press is securely mounted and stable.
- Remove the existing seating plug from your seating die.
- Match the number on your current seating plug with the corresponding bullet seating micrometer number
- Screw the micrometer seating die into the seating die using the ½20 threads.
- Tighten securely, but do not overtighten.

#### 2. Usage:

- Set the desired bullet seating depth by adjusting the micrometer dial.
- Load the bullet into the die and operate the reloading press according to your standard procedures.
- After seating the bullet, check the depth using a caliper for accuracy.
- Make adjustments as necessary, ensuring to return to the desired depth settings.

# **Disposal Instructions**

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available.
- Remove any hazardous materials before disposal, if applicable.

# **Contact Information for Further Support**

For any safety inquiries or additional support, please refer to the contact information provided with your product packaging or visit the manufacturer's website.

#### Conclusion

By following these safety instructions and guidelines, the STANDARD BULLET SEATING MICROMETER.	you can ensure a safe and effective reloading experience with Thank you for your attention to safety, and happy reloading!