

9000HN HYDRAULIC SHOTSHELL RELOADER - MEC RELOADING MEC 9000HN SERIES SHOTSHELL PRESS 16 GAUGE

[Reloading](#) > [Reloading Presses](#) > [Shotshell Presses](#)

The MEC 9000HN comes complete with the hydraulic pump and hose. Hydraulics allow the operator to insert empty shells and wads and the reloader does the rest. With each complete downstroke of the foot pedal, all reloading operations are performed at all six stations. The 9000HN has all the innovative features found on the 9000GN, plus automatic indexing and finished-shell ejection for quicker and easier reloading.



Attributes

- Name: [MEC RELOADING MEC 9000HN SERIES SHOTSHELL PRESS 16 GAUGE](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019485
- Mfr. No.: 9000HN16
- Delivery weight: 30.391kg
- Shipping height: 587mm
- Shipping width: 448mm
- Shipping length: 527mm
- UPC: 098489029179

Item details

Made in USA

Table of Contents

- Startpage
- MEC 9000HN Hydraulic Shotshell Reloader Safety Instruction Guide
- About Us

MEC 9000HN Hydraulic Shotshell Reloader Safety Instruction Guide

Introduction

Thank you for choosing the MEC 9000HN Hydraulic Shotshell Reloader. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your reloader. Please read this manual carefully before operating the product.

General Safety Guidelines

- Always ensure the reloader is used in accordance with the manufacturer's instructions.
- Keep the work area clean and welllit to avoid accidents.
- Use personal protective equipment (PPE) such as safety glasses and gloves while operating the reloader.
- Ensure that children and pets are kept away from the reloading area.
- Regularly inspect the reloader for any signs of wear or damage. Do not use if any parts are damaged.
- Follow all local laws and regulations regarding the reloading of ammunition.

Specific Safety Precautions for Use

- Ensure that the hydraulic pump and hose are properly connected before use.
- Do not exceed the recommended pressure limits of the hydraulic system.
- Always use the appropriate gauge of shotshells as specified by the manufacturer.
- Never attempt to reload ammunition while under the influence of drugs or alcohol.
- Do not place any body parts near moving parts during operation.
- Be aware of your surroundings and ensure no one is in the vicinity of the reloader during operation.

Instructions for Installation and Usage

1. Installation:

- Place the MEC 9000HN on a stable and level surface.
- Connect the hydraulic pump to the reloader, ensuring all connections are secure.
- Attach the hose to the hydraulic pump and check for leaks.
- Ensure the reloader is plugged into a suitable power source if required.

2. Usage:

- Load empty shells and wads into the designated stations.
- Press the foot pedal to initiate the reloading process. All six stations will operate simultaneously.
- Monitor the reloading process closely and be ready to stop if any irregularities occur.
- Once reloading is complete, ensure all finished shells are ejected properly.
- Regularly clean the reloader to maintain optimal performance.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of the reloader in regular household waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or operation of the MEC 9000HN Hydraulic Shotshell Reloader, please refer to the manufacturer's contact information provided with the product packaging.

By following these guidelines, you can ensure a safe and efficient reloading experience with your MEC 9000HN Hydraulic Shotshell Reloader. Always prioritize safety and compliance with local regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk